

- Manuals.plus /
- › AXIAOLIFH /
- › AXIAOLIFH ZL02D Smart Watch User Manual

AXIAOLIFH ZL02D

AXIAOLIFH ZL02D Smart Watch User Manual

MODEL: ZL02 / ZL02D

1. INTRODUCTION

Thank you for choosing the AXIAOLIFH ZL02D Smart Watch. This manual provides detailed instructions on how to set up, operate, and maintain your new smartwatch. Please read this manual carefully before using the device to ensure proper functionality and a satisfying user experience.

The ZL02D Smart Watch is designed to be a versatile companion for your daily life, offering features such as heart rate monitoring, blood pressure measurement, sleep tracking, smart notifications, and various sports modes, all within a sleek, lightweight, and waterproof design.

2. PRODUCT OVERVIEW



The ZL02D Smart Watch features a round dial with a clear display and a comfortable silicone strap.

SMART WATCH

Stylish wrist is different

Wear without
feeling

Health
steward

Sports
partner

Youth
accessories

Weather
forecast



Experience a stylish and comfortable wear with the ZL02D's modern design, available in multiple colors.

Ultra-thin body Craftsmanship

The case is thin and light, lightweight design, one piece,
highlight the exquisite craftsmanship



The watch boasts an ultra-thin body and exquisite craftsmanship, ensuring a premium feel.

Lightweight design Ultra-light and non-sense

The body of the bracelet is ultra-thin, lightweight design
With flexible silicone strap, comfortable and breathable to wear
Bring you a super clear and senseless wearing experience



Designed for a super clear and non-feeling wearing experience, thanks to its lightweight and flexible silicone strap.

Retina HD large screen Freezing time

Feature

1.28-inch high-definition large screen, vivid and vivid display details,
2.5D integrated curved glass, following the fashion trend,
Slim and moist, soft and elegant



1.28 inch
HD color screen



240ppi
High resolution



2.5D glass



Full screen
touch



Equipped with a 1.28-inch high-definition large screen and 2.5D curved glass for vivid display details and a sleek look.

3. SETUP

3.1 Charging the Device

Before first use, please fully charge your smartwatch.

- Connect the charging cable to the charging contacts on the back of the watch.
- Plug the USB end of the cable into a standard USB power adapter (5V/1A recommended) or a computer's USB port.
- The watch screen will indicate charging status. A full charge typically takes about 2-3 hours.

3.2 App Installation and Pairing

The ZL02D Smart Watch is compatible with Android devices. To unlock its full potential, download and install the companion app.

- **Download the App:** Search for "DaFit" in the Google Play Store on your Android smartphone and install it.
- **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
- **Pairing:** Open the DaFit app, navigate to the device section, and search for your ZL02D watch. Select your watch from the list to pair. Follow any on-screen prompts to complete the pairing process.
- **Permissions:** Grant necessary permissions to the app for features like notifications, health data synchronization, etc.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

- **Touch Screen:** Swipe left/right to navigate between different functions and screens. Swipe up/down to access quick settings or notifications.
- **Side Button:** Press the side button to wake up the screen, return to the home screen, or access the main menu.

4.2 Health Monitoring

The ZL02D Smart Watch can monitor various health indicators. **Please note: Measurement data is for reference only and cannot be used as medical data.**

- **Heart Rate:** Access the heart rate function on the watch to measure your current heart rate. Data will synchronize with the DaFit app.
- **Blood Pressure:** Access the blood pressure function to take a measurement. Ensure the watch is worn correctly for accurate readings.
- **Sleep Tracking:** Wear the watch to bed, and it will automatically track your sleep patterns, including deep sleep, light sleep, and awake times. View detailed reports in the DaFit app.

4.3 Smart Features

- **Smart Reminders/Notifications:** Once paired with your smartphone, the watch can receive notifications for calls, messages, and app alerts.
- **Bluetooth Call:** The watch supports Bluetooth calls. You can answer or reject incoming calls directly from your wrist.

incoming call One-click rejection

After the APP is connected and paired, you can directly refuse to answer the call on the bracelet anytime, anywhere, and experience the convenient life brought by smart wear



Conveniently manage incoming calls directly from your ZL02D smartwatch.

4.4 Sports Modes

The watch includes various sports modes to track your activities. Select the desired sport mode before starting your workout to record data such as steps, distance, calories burned, and heart rate during exercise.

4.5 Weather Forecast

Stay informed about the weather directly from your wrist.

Weather forecast

Your weather steward, real-time weather conditions, provide convenience for your work and travel



Your personal weather steward, providing real-time weather conditions for your convenience.

5.1 Cleaning

- Regularly clean your watch and strap to prevent skin irritation and maintain hygiene.
- Wipe the watch screen and body with a soft, lint-free cloth. If necessary, dampen the cloth slightly with water.
- Do not use harsh chemicals, abrasive cleaners, or solvents.

5.2 Water Resistance

The ZL02D Smart Watch features an IP67 professional waterproof design.

IP67 waterproof

IP67 professional waterproof design, splashing and washing hands are easy to wear and worry-free



IP67 professional waterproof design means splashing water and washing hands will not affect wearing, providing worry-free use.

- It is resistant to splashes, rain, and brief immersion in water (up to 1 meter for 30 minutes).
- Avoid wearing the watch during hot showers, sauna, or diving, as steam and high water pressure can compromise the seal.
- After contact with water, especially saltwater, dry the watch thoroughly.

6. TROUBLESHOOTING

Problem	Solution
Watch does not turn on	Ensure the watch is fully charged. If it still doesn't turn on, try resetting it by pressing and holding the side button for 10-15 seconds.
Cannot pair with phone	Make sure Bluetooth is enabled on your phone and the watch is within range. Restart both the watch and phone. Ensure the DaFit app has Bluetooth permissions.
Inaccurate health data	Ensure the watch is worn snugly on your wrist, about one finger's width from your wrist bone. Avoid excessive movement during measurement. Remember, data is for reference only.
Notifications not received	Check if the watch is connected to the app. Ensure notification permissions are granted to the DaFit app in your phone's settings. Verify that app notifications are enabled within the DaFit app.
Short battery life	Reduce screen brightness, turn off unnecessary features like continuous heart rate monitoring if not needed, and limit frequent screen wake-ups.

7. SPECIFICATIONS

Size and Parameter





Display	1.28 inch full fit full touch screen 240*240px
Operation	Full touch and side buttons
CPU	GR5515
Bluetooth	Bluetooth 4.0 (Support Bluetooth 5.0)
Waterproof	IP67 waterproof
Heart rate sensor	HRS3300
Acceleration sensor	SC7A20
Battery	200mAh
Strap	Silica gel
System	IOS9.0+ and Android5.0+

Detailed dimensions and key parameters of the ZL02D Smart Watch.

Feature	Detail
Model	ZL02 / ZL02D
Display	1.28-inch HD Color Screen, 240*240px, 2.5D Curved Glass
Operation Mode	Full Touch Screen + Side Button
CPU	GR5515
Connectivity	Bluetooth 4.0 (Support Bluetooth 5.0)
Waterproof Rating	IP67 Professional Waterproof

Feature	Detail
Battery Capacity	220 mAh (200 mAh in some specifications)
Strap Material	Silicone Strap
Compatible Platform	Android 5.0+ (Operating System: Android Wear 2.9)
Memory Storage	128 MB
Product Size	45.5mm (Diameter) x 10mm (Thickness)
Weight	Approx. 35g

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.
Manufacturer: AXIAOLIFH

© 2025 AXIAOLIFH. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0F32GRVXH>

More documents and user manuals: <https://manuals.plus/>