

## Fromann SN43B01-02-03

# Fromann Adjustable Full Bed Base Frame User Manual

Model: SN43B01-02-03

## 1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Fromann Adjustable Full Bed Base Frame. Please read this guide thoroughly before assembly and operation to ensure proper functionality and to prevent injury.

## 2. SAFETY INFORMATION

Always adhere to the following safety guidelines:

- Follow all assembly instructions carefully to avoid injury.
- Keep the remote control out of reach of children to prevent accidental operation.
- Do not exceed the weight limit of 750 lbs (340 kg) for the bed base to ensure safe operation and prevent damage.
- Be cautious of moving parts and electrical components to avoid injury.
- Always unplug the bed base before making any adjustments or performing maintenance.

## 3. SETUP AND ASSEMBLY

The adjustable bed base is designed for straightforward assembly. It is recommended to have two people for setup due to the weight of the frame (approximately 130 lbs).

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Unfold the Frame:** Place the folded frame in the desired location. Unfold the frame and secure the two safety pins.
3. **Install Legs:** Screw in the six adjustable legs. The legs offer adjustable height options.
4. **Flip the Bed:** With assistance, carefully flip the bed base over so it rests on its legs.
5. **Connect Power:** Install the two 9V batteries (if applicable) and connect the control box. Plug the power cord into a grounded electrical outlet.
6. **Attach Mattress Retainer Bars:** Secure the mattress retainer bars at the foot of the bed.



Figure 3.1: Adjustable bed legs and frame structure. The legs can be adjusted for height.

Your browser does not support the video tag.

Video 3.1: This video demonstrates the assembly process and initial setup of the adjustable bed base, including unfolding the frame and attaching components.

## 4. OPERATING INSTRUCTIONS

Your Frommann Adjustable Bed Base is controlled by a wireless remote. The remote comes pre-paired with the bed base.

### 4.1 Remote Control Functions



Figure 4.1: The wireless remote control for the adjustable bed base, showing all buttons and their functions.

- **Child Lock:** Press to activate/deactivate the child lock feature, preventing accidental adjustments.
- **Memory A/B/C:** Press and hold to save a custom position. Press briefly to recall a saved position.
- **Lumbar Up/Down:** Adjusts the lumbar support bar for spinal alignment.
- **Head Up/Down:** Adjusts the head section elevation (0-68°).
- **Foot Up/Down:** Adjusts the foot section elevation (0-38°).
- **Headrest Up/Down:** Adjusts the pillow tilt (up to 38°).
- **Flat:** Returns the bed to a completely flat position.
- **Zero Gravity (ZG):** Activates the Zero Gravity preset position, elevating the head and feet to reduce pressure.
- **Anti-Snore:** Activates the Anti-Snore preset position, slightly raising the head to open airways.
- **Massage Settings (Wave, Timer, Intensity):** Controls the massage functions. Multiple professional massage modes are available.
- **Underbed Light:** Turns the gentle under-bed lighting on or off. The light automatically turns off after five minutes.

## 4.2 USB Charging Ports

The bed base includes dual USB-C fast charging ports located on both sides for convenient device charging.



Figure 4.2: Key features of the adjustable bed base, highlighting USB-C ports, massage function, and various adjustable positions.

## 5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your adjustable bed base.

- **Cleaning:** Wipe the frame with a damp cloth. Avoid harsh chemicals.
- **Motor Inspection:** Periodically check the motor and electrical connections for any loose wires or damage. Ensure the power cord is not pinched or tangled.
- **Lubrication:** Moving parts are generally self-lubricating and do not require additional lubrication.
- **Mattress Retainer Bars:** Ensure these are securely in place to prevent mattress shifting.

## 6. TROUBLESHOOTING

If you encounter issues with your adjustable bed base, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bed does not operate	Power cord unplugged; Remote batteries low/dead; Child lock activated.	Ensure power cord is securely plugged in. Replace remote batteries. Deactivate child lock on remote.
Motor runs but no movement	Obstruction under bed; Mechanism jammed.	Check for obstructions and remove. Unplug unit for 30 seconds, then plug back in.
Remote not responding	Remote not paired; Batteries low/dead.	Replace remote batteries. Refer to pairing instructions in the full manual (if available) or contact support.
Unusual noise during operation	Loose components; Obstruction.	Inspect for loose bolts or components and tighten. Check for any objects caught in the mechanism.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	SN43B01-02-03
Size	Full (52.3" x 73.8")
Material	Metal
Item Weight	130 pounds
Product Dimensions	73.8 x 52.3 x 14 inches
Weight Capacity	750 lbs
Head Elevation	0-68°
Leg Elevation	0-38°
Pillow Tilt	0-38°
Lumbar Support	0-40°
Special Features	Adjustable, Massage, USB Charging (USB-C), Underbed Lighting, Zero Gravity Mode, Memory Positions, Child Lock

## 8. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Fromann customer support. This product typically includes a 90-day return policy.

If you require assistance with assembly, operation, or troubleshooting that is not covered in this manual, please contact Fromann customer support through the retailer where the product was purchased or visit the official Fromann website.

