

[Manuals.plus](#) /

› [MelodySusie](#) /

› MelodySusie P-ART09F Cordless UV Nail Lamp User Manual

MelodySusie P-ART09F

MelodySusie P-ART09F Cordless UV Nail Lamp User Manual

MODEL: P-ART09F

1. Introduction

The MelodySusie P-ART09F Cordless UV Nail Lamp is a versatile and portable device designed for curing gel nail polishes and assisting with precise nail art. Featuring a 2-in-1 handheld and foldable stand design, it offers flexibility for various nail applications. This manual provides essential information for safe and effective use of your device.

Easy Carrying to Everywhere



5.4x1.8x0.8 in



Small &
Portable



The compact design allows for easy portability, fitting into small bags or pouches.

2. Product Features

- **5W UV LED Cordless Mini Nail Lamp:** Combines adjustable lighting, a foldable stand, and a lightweight design for

precise nail work.

- **2-in-1 Handheld and Stand Design:** Allows flexible use on any nail table setup.
- **Dual Light Source:** Equipped with 4 upgraded high-performance UV light beads for fast, efficient curing of all soft gels, especially medium-low viscosity gels, rhinestone glue, solid nail glue, and liner gel. Additionally, 5 extra LED beads provide soft, eye-friendly lighting for precise nail design.
- **Rechargeable Battery:** Powered by a 1000mAh rechargeable battery, providing 2-3 hours of cordless use on a full charge.
- **Timer Settings:** Two convenient timer settings (30s / 60s) for controlled curing.
- **Adjustable Curing Head:** Ensures stable and precise DIY nail work.



The lamp features both UV curing beads and LED lighting beads for versatile use.



Switch between lighting mode for visibility and curing mode for gel application.



The device is powered by a 1000mAh rechargeable battery, offering extended cordless operation.

Your browser does not support the video tag.

This video demonstrates the versatility and ease of use of the mini nail lamp for DIY nail enthusiasts.

3. Package Contents

Please check the package for the following items:

- 1 x MelodySusie P-ART09F Cordless UV Nail Lamp
- 1 x USB Charging Cable
- 1 x User Manual

4. Safety Information

To ensure safe operation and prevent damage, please read and follow these safety guidelines:

- Read all instructions thoroughly before using the device.
- Keep the device out of reach of children.
- Do not look directly into the UV/LED light during operation to prevent eye strain or damage.
- Avoid prolonged direct skin exposure to the UV light.
- Use the lamp only with compatible gel nail polishes.
- Do not attempt to disassemble, repair, or modify the device. Contact customer support if service is needed.
- Charge the device only with the provided USB cable or a certified equivalent.
- Do not expose the device to water or excessive moisture.

5. Setup

1. **Unpack:** Carefully remove the UV nail lamp and all accessories from the packaging.
2. **Initial Charge:** Connect the device to a power source using the provided USB charging cable. Ensure the device is fully charged before its first use.
3. **Familiarization:** Identify the ON/OFF button, touch switch, rotatable lampshade, folding bracket, and USB charging port.
4. **Prepare for Use (Stand Mode):** To use the lamp in stand mode, gently open the folding bracket until it forms a stable base. Adjust the rotatable lampshade to direct the light as needed.



The folding bracket design allows for easy setup on a desktop, freeing your hands for nail art.

6. Operating Instructions

1. **Power On/Off:** Long press the ON/OFF button for two seconds to turn the device on. Press the ON/OFF button once to shut down when the device is in a power-on state.
2. **Switching Modes (Lighting/Curing):** Short press the touch switch to toggle between the lighting mode (using the 5 LED beads for ambient brightness) and the curing mode (using the 4 UV beads for gel curing).
3. **Timer Settings:** In curing mode, the default timer is 30 seconds. Double-click the touch switch quickly to set a 60-second timer.
4. **Using the Stand:** Open the folding bracket and set it to the desired angle. This allows for hands-free operation, ideal for nail art creation under the lighting mode or flash curing.
5. **Handheld Use:** For targeted curing or lighting, hold the lamp directly over the nail. This is particularly useful for flash curing single nails or rhinestones.
6. **Application Tips:**
 - For detailed nail art creation, utilize the lighting mode to enhance visibility.
 - For flash curing or repairing a single nail, use the curing mode with the appropriate timer setting.
 - For full-hand gel curing, it is recommended to use a larger UV lamp for optimal results.



The lamp can be used handheld or with its folding bracket for convenience.



The lighting mode provides clear visibility for intricate nail work, reducing errors.

Your browser does not support the video tag.

This video demonstrates the flash curing capability of the MelodySusie P-ART09F lamp with its fold-out stand.

7. Maintenance

- **Cleaning:** Clean the surface of the lamp with a soft, dry cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish or internal components.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Before Cleaning/Storage:** Always ensure the device is turned off and unplugged from its charging cable before cleaning or storing.

8. Troubleshooting

Problem	Possible Cause	Solution
Device not turning on	Low battery or no charge.	Charge the device fully using the provided USB cable.
Light not working	Incorrect mode selected (e.g., lighting mode when curing is needed) or device is off.	Ensure the device is powered on and the correct mode (curing or lighting) is selected via the touch switch.
Gel not curing properly	Incompatible gel polish, insufficient curing time, or incorrect distance from the light.	Ensure you are using gel polishes compatible with UV/LED lamps. Increase curing time or adjust the lamp's position for optimal light exposure.
Device feels hot during use	Prolonged continuous use or lack of ventilation.	Discontinue use and allow the device to cool down. Ensure the ventilation holes are not obstructed.

9. Specifications

- **Model Number:** P-ART09F
- **Dimensions:** 5.35"D x 0.87"W x 4.25"H
- **Material:** Plastic
- **Battery Capacity:** 1000mAh
- **Power:** 5W
- **Light Source:** 4 UV Curing Lamp Beads, 5 Lighting LED Beads
- **Timer Settings:** 30s / 60s
- **Manufacturer:** MelodySusie

Art09F Cordless Mini Nail Lamp



Long Lasting



2 Light Sources



Deep Penetration

Key components and features of the P-ART09F lamp.

10. Warranty and Customer Support

- **Warranty:** This product comes with a 1-year manufacturer's warranty.
- **Customer Support:** For any issues, defects, repair, replacement, or troubleshooting solutions, please reach out to MelodySusie customer support through your Amazon order page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question