

COMHOMA CH227

COMHOMA CH227 Ergonomic Leather Office Chair User Manual

Model: CH227

1. INTRODUCTION

Thank you for choosing the COMHOMA CH227 Ergonomic Leather Office Chair. This chair is designed to provide comfort and support for extended periods of sitting, whether for work, gaming, or relaxation. It features built-in lumbar support, a winged backrest, and adjustable armrests to enhance your seating experience. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure optimal use and longevity of your chair.



Image 1.1: The COMHOMA CH227 Ergonomic Leather Office Chair in white, showcasing its design and flip-up armrests.

2. SAFETY INFORMATION

- Ensure all screws and bolts are securely tightened before initial use and periodically check for looseness.

- Do not stand on the chair or use it as a step stool.
- Do not exceed the maximum weight capacity of 300 pounds (136 kg).
- Keep children away from moving parts during assembly and adjustment.
- Avoid exposing the chair to direct sunlight or extreme temperatures to prevent material degradation.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Backrest
- Seat Cushion
- Armrests (2)
- Gas Lift Cylinder
- Star Base
- Casters (5)
- Mechanism Plate
- Hardware Kit (screws, washers, Allen wrench)

STURDIER & DURABLE

01



90° FLIP-UP ARMRESTS

02



Silent PU wheel

03



Bifuma & SGS Certified-L3 Gas Lift

04



Sturdy Metal Base



Image 3.1: Key components of the chair, including 90° flip-up armrests, silent PU wheels, BIFMA & SGS-certified Class 3 gas lift, and a sturdy metal base.

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes 20-30 minutes. Follow these steps carefully:

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they click into place.
2. **Install Gas Lift:** Place the gas lift cylinder into the center hole of the star base.
3. **Attach Mechanism Plate to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with screws using the provided Allen wrench.
4. **Connect Armrests to Seat:** Attach the armrests to the sides of the seat cushion using the designated screws. Do not fully tighten yet.
5. **Connect Backrest to Seat and Armrests:** Align the backrest with the seat and armrests. Secure the backrest to

the seat and armrests using the remaining screws. Once all screws are in place, tighten all armrest and backrest screws evenly.

6. **Place Seat Assembly onto Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.

For visual guidance, refer to the assembly diagrams included in your physical manual.

5. OPERATING INSTRUCTIONS

5.1. Adjusting Chair Height

To adjust the chair's height, locate the lever on the right side, beneath the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up and pull the lever up. Release the lever at your desired height.

5.2. Adjusting Recline/Tilt

The chair features a tilt-lock mechanism and reclining tilt control. To recline, pull the lever on the left side, beneath the seat, outwards. Lean back to your desired angle (between 90° and 120°). Push the lever inwards to lock the recline position. To return to an upright position, unlock the lever and lean forward.

90°-120° SMOOTH ROCKING

Adjustable Bbackrest



Image 5.1: Illustration of the chair's smooth rocking function, allowing adjustment between 90 and 120 degrees.

5.3. Using Flip-Up Armrests

The armrests can be flipped up by rotating them upwards, allowing you to push the chair closer to your desk or save space when not in use. To lower them, simply rotate them back down into position.

90° FLIP-UP ARMRESTS



Image 5.2: Demonstrates the 90° flip-up armrests, showing how they can be positioned down for support or up to save space.

6. MAINTENANCE

6.1. Cleaning

- Wipe clean with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the faux leather.
- For spills, blot immediately with a clean, dry cloth.

6.2. General Care

- Periodically check all bolts and screws to ensure they are tight.
- Avoid placing heavy or sharp objects on the chair that could cause damage.
- Keep the chair away from heat sources and direct sunlight to prevent fading and cracking of the material.

7. TROUBLESHOOTING

Issue	Possible Cause	Solution
Chair does not adjust height	Gas lift lever not engaged; Gas lift cylinder faulty	Ensure lever is fully pulled up. If issue persists, contact support for gas lift replacement.
Chair wobbles	Loose screws; Uneven floor	Tighten all assembly screws. Move chair to a level surface.
Casters not rolling smoothly	Debris in casters; Damaged casters	Clean any hair or debris from caster wheels. Replace damaged casters if necessary.
Squeaking noise	Loose connections; Lack of lubrication	Tighten all screws. Apply a small amount of silicone lubricant to moving parts if needed.

8. SPECIFICATIONS

Feature	Detail
Model Name	CH227
Brand	COMHOMA
Color	White
Product Dimensions (D x W x H)	20.08" x 25.59" x 41.73"
Seat Depth	18.11 inches
Maximum Weight Recommendation	300 Pounds (136 kg)
Back Style	Wing Back
Special Features	Adjustable Height, Arm Rest, Ergonomic, Reclining (90°-120°), Rolling
Arm Style	Adjustable (Flip-up)
Finish Type	Leather (Faux Leather)
Item Weight	29.1 pounds (13.2 kg)
Gas Lift Certification	SGS-certified Class 3
Casters	BIFMA-certified Silent PU wheels

19.88IN EXTRA-WIDE

Small chair, Strong support, Springy cushion



Image 8.1: Detailed dimensions of the COMHOMA CH227 chair and its 300 lbs weight capacity.

9. WARRANTY AND SUPPORT

The COMHOMA CH227 Ergonomic Leather Office Chair comes with a one-year repair service from the date of purchase. This warranty covers manufacturing defects and material flaws under normal use.

For any questions, concerns, or warranty claims, please refer to the contact information provided in your product packaging or visit the official COMHOMA website for customer support details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question