

[Manuals.plus](#) /

› [COLAMY](#) /

› COLAMY 6269-01 Counter Height Bar Stool Instruction Manual

## COLAMY 6269-01

# COLAMY 6269-01 Counter Height Bar Stool Instruction Manual

Model: 6269-01

## INTRODUCTION

---

Thank you for choosing the COLAMY 6269-01 Counter Height Bar Stool. This manual provides detailed instructions for the proper assembly, safe use, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: COLAMY 6269-01 Counter Height Bar Stool in a modern kitchen with a white island.

## SAFETY INFORMATION

---

- **Maximum Weight Limit:** Do not exceed the maximum weight limit of **250 lbs (113 kg)**. Exceeding this limit may result in damage to the stool or personal injury.
- **Stability:** Always ensure the stool is placed on a flat, stable surface.
- **Footrest Use:** Utilize the integrated footrest for added stability and to prevent accidental tipping, especially when getting on or off the stool.
- **Assembly:** Follow all assembly instructions precisely. Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten fasteners as needed.
- **Children:** Supervise children around the bar stools to prevent falls or misuse.
- **Moving:** Lift the stool when moving it; do not drag, as this can damage the legs or floor.

## PACKAGE CONTENTS

---

Before assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact COLAMY customer service.

## MODERN COUNTER HEIGHT BAR STOOLS



Ergonomic  
Backrest



Comfortable  
Breathable Fabric



High Density  
Sponge



Comfort Seat  
Cushion

Image: Detailed diagram of package contents and product dimensions.

### Parts List:

- Seat Cushion (A) x 1
- Back Cushion (B) x 1
- Upper Leg (C) x 1
- Lower Leg (D) x 1
- Wood Strip (E) x 3
- X-Metal Plate (F) x 1
- Screw Bag (G) x 1 (Contains various bolts, screws, and Allen wrench)

### SPECIFICATIONS

<b>Product Dimensions (D x W x H)</b>	20.47" x 22.05" x 37.4"
<b>Seat Height</b>	25.59"
<b>Seat Depth</b>	19.49"
<b>Backrest Height</b>	11.81"
<b>Color</b>	Beige
<b>Brand</b>	COLAMY
<b>Style</b>	Counter Height Bar Stools
<b>Furniture Finish</b>	Fabric, Sponge, Wood
<b>Leg Style</b>	Straight
<b>Maximum Weight Recommendation</b>	250 Pounds
<b>Assembly Required</b>	Yes
<b>Item Weight</b>	16.87 pounds
<b>Model Number</b>	6269-01

## ◆◆ PRODUCT DIMENSION ◆◆



Image: Front and side view with detailed measurements of the bar stool.

## ASSEMBLY INSTRUCTIONS

Please follow these steps carefully. It is recommended to assemble the stool on a soft, clean surface to prevent scratches. Do not fully tighten bolts until instructed.

### Tools Required:

- Allen Wrench (included in Screw Bag G)

#### 1. Step 1: Assemble the Leg Frame Base

Install upper leg C and lower leg D. Then, place the X-metal plate F on the bottom of the legs cross connection. Use four M6\*20mm bolts (from Screw Bag G) to attach. Tighten the bolts to 50%.



Image: Diagram for Step 1 and 2 of assembly.

**2. Step 2: Attach Wood Strips to Leg Frame**

Attach the front wood strip E, back wood strip E, and middle wood strip E to the leg frame. Pay attention to the screw holes direction on the strips, aligning them for your reference. Tighten to 50%.

**3. Step 3: Secure Wood Strips with Screws**

Insert six M4\*35mm wood screws (from Screw Bag G) into the screw holes on the wood strips. Tighten to 50%.



Image: Diagram for Step 3 and 4 of assembly.

**4. Step 4: Attach Seat Cushion**

Attach the seat cushion A to the finished wood frame using four M6\*30mm bolts, spring washers, and flat washers (from Screw Bag G). Tighten to 50%.

**5. Step 5: Attach Back Cushion**

Attach the back cushion B to the finished frame using two M6\*20mm bolts (from Screw Bag G). Tighten to 50%.



Image: Diagram for Step 5, 6, and 7 of assembly.

#### 6. Step 6: Final Tightening

Once all components are in place and aligned, tighten all screws and bolts to 100%. Ensure all connections are firm and secure.

#### 7. Step 7: Adjust Foot Nails

Adjust the foot nails at the bottom of the legs to level the chair and ensure stability on uneven surfaces. Your chair is now successfully installed.

## USAGE AND CARE

### Proper Usage:

- Ensure the stool is fully assembled and all fasteners are tight before each use.
- Always sit centrally on the seat to distribute weight evenly.
- Use the footrest for comfort and stability.
- Avoid standing on the stool or using it as a ladder.
- Do not rock excessively on the stool.

### Maintenance:

- **Cleaning:** Wipe the wood frame with a dry cloth. For the upholstered fabric, spot clean with a mild detergent and damp cloth as needed. Avoid harsh chemicals.
- **Fasteners:** Periodically check all bolts and screws and re-tighten them to ensure the stool remains stable and secure.
- **Environment:** Avoid prolonged exposure to direct sunlight or extreme humidity, which can damage the wood and fabric.
- **Weight Capacity:** Adhere strictly to the 250 lbs maximum weight recommendation.

## ◆◆ PRODUCT DISPLAY ◆◆



Image: Visual representation of ergonomic backrest, breathable fabric, high-density sponge, and comfort seat cushion.



Image: Visual representation of sturdy rubberwood frame, comfortable footrest, 250 lbs weight capacity, and anti-slip protectors.

## TROUBLESHOOTING

---

If you encounter any issues with your COLAMY bar stool, please refer to the following common solutions:

- **Wobbling Stool:**
  - Ensure all assembly bolts and screws are fully tightened.
  - Adjust the foot nails at the bottom of each leg to level the stool on uneven floors.
  - Verify that the stool is placed on a flat, stable surface.
- **Creaking Noises:**
  - Re-tighten all assembly hardware. Over time, fasteners can loosen, causing creaking.
- **Damaged or Missing Parts:**
  - Do not attempt to use the stool with damaged or missing parts. Contact COLAMY customer service for replacements.

## WARRANTY AND SUPPORT

---

COLAMY products are designed for quality and durability. For specific warranty information, please refer to the documentation provided at the time of purchase or visit the official COLAMY website. If you require assistance with assembly, parts, or have any questions, please contact COLAMY customer support.

**Contact Information:** Please refer to your purchase receipt or the COLAMY official website for the most current customer service contact details.