



Manuals.plus /

- › Culanta /
- › Culanta U1 Full Body Massage Chair Instruction Manual

Culanta U1

Culanta U1 Full Body Massage Chair

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Culanta U1 Full Body Massage Chair. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new massage chair. Please read it thoroughly before operation and retain it for future reference.



Image: The Culanta U1 Full Body Massage Chair, showcasing its design and color scheme.

Important Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- Always use the control panel or knob to adjust the angle of the massage chair.
- Be cautious when using the zero-gravity function to avoid falling or losing balance.
- Do not exceed the maximum weight limit of 139 pounds.
- Ensure the power cable is properly connected and not damaged.
- Keep children and pets away from the chair during operation.
- Avoid placing the chair in damp environments or near water sources.

Product Overview and Key Features

The Culanta U1 Massage Chair is designed to provide a comprehensive and customizable massage experience. Key features include:

Intelligent Body Scan and Automatic Programs

Upon startup, the chair automatically detects the user's body type to customize the massage. It offers 5 automatic massage programs:

- **RELAX:** Gentle massage for overall relaxation.
- **DEEP TISSUE:** More intense massage to target deeper muscle knots.
- **THAI:** Combines stretching and pressure point massage.
- **STRETCH:** Focuses on elongating muscles and improving flexibility.
- **SLEEP:** Soothing massage designed to promote rest.



Image: The massage chair's display showing available automatic and manual massage modes.

SL-Track Massage System

The ergonomic 135cm "SL" shape track ensures full coverage from the head to the legs, allowing for a thorough and personalized massage along the natural curvature of your spine.

Full Body Massage

Full Body Airbag Massage & Waist and calf Heating & Foot Roller Massage



Image: Visual representation of the SL-Track, showing its extended reach for full body massage.

Full Body Airbag Compression

The chair features full coverage air compression for a deep kneading experience across various body parts, including shoulders, arms, and calves.

SL-Track Massager Chair

Ergonomic Natural Curvature



Image: Illustration of the full body airbag massage system.

Zero-Gravity Recline

Experience a weightless sensation with the one-touch zero-gravity function. The chair reclines to distribute body weight evenly, reducing pressure on the spine and enhancing the massage effect. The angle can also be adjusted manually via the control panel or knob.

Zero Gravity Mode



Image: The Zero Gravity Mode, illustrating the chair's recline positions.

Foot Rollers and Airbags

The foot area provides a soothing kneading massage with airbags and rollers that stimulate acupressure points. The footrest can be effortlessly extended by gently pushing your feet forward.



Image: Detailed view of the footrest airbags and rollers.

Thermotherapy Heating

The chair incorporates thermotherapy heating in the lumbar and calf areas to help accelerate blood circulation and provide deeper relaxation. The heating effect gradually increases over approximately 30 minutes for an optimal experience.

Setup

The Culanta U1 Massage Chair comes pre-assembled, requiring minimal setup. Follow these steps for initial placement and connection:

1. **Unboxing:** Carefully remove the chair from its packaging.
2. **Placement:** Position the chair in your desired location. Ensure there is adequate space around the chair for reclining and footrest extension. The chair dimensions are 56.7"D x 29.08"W x 41.7"H.
3. **Power Connection:** Connect the power cable to a suitable electrical outlet.
4. **Control Panel Setup:** Attach the display screen/control panel as indicated in the packaging.



Image: The chair's 'one-piece and installation-free' design, highlighting ease of movement.

Operating Instructions

Your Culanta U1 Massage Chair is operated via an intuitive control panel. Familiarize yourself with its functions for an optimal massage experience.

Control Panel Overview



Control Panel



Image: The control panel, displaying options for various massage settings.

Starting a Massage

1. Sit comfortably in the chair.
2. Press the power button on the control panel to turn on the chair.
3. The chair will perform a one-minute human body inspection to customize the massage. During this time, the control panel cannot be adjusted.
4. Select an automatic program (RELAX, DEEP TISSUE, THAI, STRETCH, SLEEP) or choose a manual mode.

Adjusting Settings

- **Air Intensity:** Adjust the strength of the airbag compression.
- **Speed/Width:** For manual modes, adjust the speed or width of the massage rollers.
- **Heating:** Activate or deactivate the lumbar and calf heating function.
- **Zero Gravity:** Press the 'Zero' button to activate the zero-gravity recline.
- **Foot Roller:** Control the intensity of the foot rollers.
- **Timing:** Set the duration of your massage session.

Official Product Video

Your browser does not support the video tag.

Video: An official overview of the Culanta Massage Chair, demonstrating its features and operation.

Maintenance

Proper care and maintenance will ensure the longevity and optimal performance of your massage chair.

- **Cleaning:** Wipe clean the faux leather surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, unplug the chair and cover it to protect from dust.
- **Inspection:** Periodically check the power cord and connections for any signs of wear or damage.

Troubleshooting

If you encounter any issues with your Culanta U1 Massage Chair, please refer to the following common solutions:

- **Chair not powering on:** Ensure the power cable is securely plugged into both the chair and the wall outlet. Check if the outlet is functional.
- **Massage function not working:** Verify that the chair has completed its initial body scan. Ensure no objects are obstructing the massage rollers.
- **Heating not felt immediately:** The heating function gradually increases over approximately 30 minutes. Allow sufficient time for the heat to become noticeable.
- **Unusual noises:** If you hear unusual noises, immediately turn off the chair and unplug it. Contact customer support for assistance.

For issues not listed here, please contact Culanta customer support.

Specifications

Feature	Detail
Brand	Culanta
Model Name	U1
Product Dimensions	56.7"D x 29.08"W x 41.7"H
Item Weight	139 pounds
Material	Faux Leather, Foam
Special Features	Airbags, Foot Rollers, Heated, Reclining, Zero Gravity, SL-Track
Assembly	No assembly required (Product comes pre-assembled)
Recommended Uses	Relaxing, Sleeping

Warranty and Support

We hope you will enjoy your Culanta U1 Massage Chair. If you are not satisfied or have any questions about the massage chair, please contact our customer service team for assistance. We are committed to providing timely support for any inquiries you may have.

For customer support, please refer to the contact information provided with your purchase or visit the official Culanta website.