

## KOIPSSE V03

# KOIPSSE AI Smart Camera Glasses V03 User Manual

Model: V03 | Brand: KOIPSSE

## 1. PRODUCT OVERVIEW

The KOIPSSE AI Smart Camera Glasses V03 are designed for hands-free capture of 1080P HD video and photos, featuring real-time translation, and an integrated AI voice assistant. These glasses are suitable for various outdoor and indoor activities, offering a blend of advanced technology and stylish design.

### What's in the Box

- Magnetic charging cable
- 16 countries instruction manual
- Glasses cleaning cloth
- AI Smart Camera Glasses

### Key Features

- **1080P HD Video & Photo Recording:** Capture high-definition videos and crisp photos hands-free.
- **Real-Time Voice Translation:** Instantly break language barriers with multi-language support.
- **Built-in AI Voice Assistant:** Control functions, get information, and interact using voice commands.
- **Durable and Lightweight Design:** Engineered for comfort and resilience in various environments.
- **Sleek, Modern Aesthetic:** Combines advanced technology with a fashionable appearance for everyday wear.



Image: The KOIPSSE AI Smart Camera Glasses V03 in black, shown with its magnetic charging cable, highlighting the integrated camera lens.

## 2. SETUP GUIDE

---

### 2.1 Charging the Glasses

Before initial use, ensure your glasses are fully charged. Connect the magnetic charging cable to the charging port located on the glasses' temple and plug the USB end into a compatible power adapter or computer USB port. The indicator light will show charging status.

### 2.2 App Installation

1. Open the instruction manual included in your product packaging.
2. Scan the QR code provided in the manual using your smartphone's camera. This will direct you to download the "HeyCyan" application.
3. Alternatively, search for "HeyCyan" directly in your device's app store (Apple App Store or Google Play Store) and proceed with the download.
4. Upon opening the app for the first time, you will be prompted to grant necessary permissions, including access to WLAN & Cellular data, Bluetooth, and image permissions. Please allow these to ensure full functionality.
5. You may skip the registration/login process if you prefer not to create an account.

### 2.3 Device Pairing

Follow these steps to pair your glasses with the "HeyCyan" app:

1. Ensure the "HeyCyan" app is open on your smartphone and ready to connect.

2. Turn on the glasses by pressing and holding the button on the right temple for a few seconds until you hear an audible confirmation sound.
3. In the app, click the "Connect device" button. The app will scan for available devices.
4. Select "V03\_3224" (or the specific device ID displayed for your glasses) from the list and click "Connect".
5. A Bluetooth pairing request will appear on your phone. Confirm by clicking "Pair".
6. Once connected, the app will display a successful binding page, indicating that your glasses are ready for use.

Your browser does not support the video tag.

Video: A tutorial demonstrating the process of connecting the KOIPSSE AI Smart Camera Glasses V03 to a mobile phone via the "HeyCyan" app, including app download, pairing, and initial setup steps.

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Taking Photos and Recording Videos

The glasses enable hands-free photo and video capture. Specific button presses are detailed in the app's tutorial, which may pop up automatically upon first connection or can be accessed via the app's homepage.

- **To take a photo:** Typically, a single tap on the right button of the glasses.
- **To start video recording:** Typically, a double tap on the left button of the glasses.
- **To stop video recording:** Typically, another double tap on the left button.

An indicator light on the outside of the glasses will flash to confirm recording status.

### 3.2 Accessing and Importing Media

Media captured by the glasses can be imported to your smartphone:

1. In the "HeyCyan" app, navigate to the "Album" section.
2. If new media (photos, videos, recordings) is available on the glasses, the app will prompt you with a notification to import. Click the "Import" button.
3. During the synchronization process, a WiFi hotspot connection request will appear. Click "Join" to allow the transfer.
4. If this is your first time importing, you may be prompted to obtain image permissions. Click "Allow".
5. The media files will be synchronized from the glasses to the app.
6. To automatically save imported media to your phone's system album, click on the settings icon (gear icon) in the upper right corner of the "Album" section and enable the "Auto save" option.

Your browser does not support the video tag.

Video: A demonstration of how to synchronize captured pictures and videos from the KOIPSSE AI Smart Camera Glasses V03 to the "HeyCyan" mobile application, including the import process and auto-save settings.

### 3.3 AI Voice Assistant

The integrated AI voice assistant can be activated and used for various smart functions:

- **Wake-up:** Say "Hey Cyan" or tap the left button on the glasses.
- **Commands:** Ask questions or give commands for tasks such as getting directions, checking the weather, or controlling media playback.

- **Image Recognition:** Utilize voice commands to analyze objects in your field of view, providing information or targeted responses.

### 3.4 Touchpad Gestures

The glasses feature touchpad gestures for convenient control of music playback and volume adjustments. Specific gestures are typically detailed within the app's tutorial or user interface.

- **Play/Pause music:** (Refer to app for specific gesture, e.g., single tap on temple).
- **Switch songs:** (Refer to app for specific gesture, e.g., swipe forward/backward on temple).
- **Adjust volume:** (Refer to app for specific gesture, e.g., swipe up/down on temple).



Image: A man wearing the KOIPSSE AI Smart Camera Glasses V03, with a visual representation of the AI voice assistant responding to a command, illustrating the voice control feature.

## 4. MAINTENANCE

### 4.1 Cleaning

To maintain the clarity of your lenses and the condition of your glasses, use the provided glasses cleaning cloth. Gently wipe the lenses and frame. Avoid using abrasive materials or harsh chemical cleaners, as

these can damage the coatings and materials.

## 4.2 Lens Replacement

The lenses of your KOIPSSE AI Smart Camera Glasses V03 can be replaced. Follow these steps carefully to avoid damage or injury:

1. First, carefully remove the built-in lenses from the frame.
2. When installing new lenses, ensure you check that the left and right lenses are not installed in reverse. Insert the new lenses from the inside of the temple.
3. Fix one side of the lens into the frame first. For the other side, wrap the lens with a soft cloth for protection, and then gently press it into the frame until it is securely in place. Be careful to avoid injury during this process.

Your browser does not support the video tag.

Video: A step-by-step guide on how to replace the lenses in the KOIPSSE AI Smart Camera Glasses V03, demonstrating the removal of existing lenses and the careful insertion of new ones.

## 5. TROUBLESHOOTING

---

### 5.1 Connection Issues

- **Glasses not turning on/indicator light not flashing:** Ensure the glasses are fully charged. Connect them to the magnetic charging cable and a power source.
- **App not detecting glasses:** Verify that Bluetooth is enabled on your smartphone and the glasses are within close proximity. Try restarting both the glasses and the "HeyCyan" app.
- **Bluetooth pairing failed:** Ensure no other devices are actively connected to the glasses. Forget the device in your phone's Bluetooth settings and attempt to pair again.

### 5.2 Media Transfer Problems

- **Importing media is slow or fails:** Ensure a stable Wi-Fi connection during the import process. Check if the "HeyCyan" app has all necessary image and media permissions granted on your phone.
- **No new media detected:** Confirm that photos or videos were successfully captured by the glasses. Check the glasses' internal memory capacity.

### 5.3 Battery Life

- **Short battery life:** Continuous video recording and heavy use of AI features can significantly reduce battery duration. Ensure the glasses are fully charged before extended use.

### 5.4 General Issues

- **Device unresponsive:** If the glasses become unresponsive, try rebooting them through the "HeyCyan" app settings.
- **Persistent problems:** As a last resort, you can restore the glasses to factory settings via the app. Note that this will erase all data and settings.

## 6. SPECIFICATIONS

---

<b>Feature</b>	<b>Detail</b>
Model Number	V03
Item Weight	8.4 ounces
Package Dimensions	9.92 x 3.39 x 3.15 inches
Battery Type	1 Nonstandard Battery (Lithium Polymer)
Battery Capacity	220 Milliamp Hours
Memory Storage Capacity	4 GB
Connectivity Technology	Bluetooth, Wi-Fi
Wireless Communication Standard	802.11n, Bluetooth
Special Features	Audio Recording, Camera, Music Player, Video Recording, Voice Control
Operating System	Ubuntu Touch
Manufacturer	Shenzhen Chuangshengda Electronics Co., Ltd.
Screen Size	3 Inches (Standing screen display size)
GPS	No GPS
Shape	Oval

# AI shooting glasses

Reshaping Your Vision Experience

Shooting | Image Recognition | Dialogue | Translation | Recording | Listening to Music



Image: The KOIPSSE AI Smart Camera Glasses V03, emphasizing its 500W 1080P camera capabilities for high-quality recording.

## 7. WARRANTY AND SUPPORT

For detailed warranty information regarding your KOIPSSE AI Smart Camera Glasses V03, please refer to the specific documentation included in your product packaging. This document outlines the terms and conditions of your warranty coverage.

Should you require technical assistance, have questions about product functionality, or need to report an issue, please visit the official KOIPSSE website or contact their dedicated customer support team. Contact details are typically provided in the product's original packaging or on the manufacturer's website.