

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [amseatec](#) /

› [amseatec Criss Cross Chair with Armrests & Wheels \(Model LY-8267\) Instruction Manual](#)

amseatec LY-8267

amseatec Criss Cross Chair with Armrests & Wheels Instruction Manual

Model: LY-8267

INTRODUCTION

Thank you for choosing the amseatec Criss Cross Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new chair. Please read it thoroughly before use and retain it for future reference.

IMPORTANT SAFETY INFORMATION

WARNING: Do not exceed the maximum weight limit of 300 pounds. Always use the adjustable features carefully and according to the instructions provided.

- Ensure all components are securely fastened before use.
- Keep hands and fingers clear of moving parts during adjustment.
- Do not stand on the chair.
- Use on a level surface to prevent tipping.

PACKAGE CONTENTS

Verify that all parts listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Seat Cushion
- Backrest
- 5-position Adjustable Armrests (pre-attached to seat base)
- Power Gas Lift
- Star Base with Wheels
- Assembly Hardware (bolts, wrench)
- Instruction Manual

Your browser does not support the video tag.

Video: Official amseatec assembly guide for the Criss Cross Chair, demonstrating the quick and simple setup process.

ASSEMBLY INSTRUCTIONS

Assembly is quick and easy, typically taking less than 15 minutes for one person.

1. **Attach Wheels to Star Base:** Insert each of the 5 wheels firmly into the holes on the star base until they click into place.
2. **Insert Gas Lift:** Place the decorative cover over the center hole of the assembled star base. Insert the power gas lift into the center hole of the star base.
3. **Attach Seat to Gas Lift:** Carefully align the mechanism on the underside of the seat with the top of the gas lift. Press down firmly until the seat is securely attached. Ensure the "FRONT" label on the mechanism faces forward.
4. **Attach Backrest:** Align the backrest with the designated slots on the seat base and secure with the provided bolts using the included wrench.

OPERATING INSTRUCTIONS

- **Height Adjustment:** To adjust the chair height, pull the lever located under the seat upwards while applying or releasing weight from the seat. Release the lever at the desired height.
- **Armrest Adjustment (5-Gear):** The armrests feature a 5-gear adjustable mechanism. Gently push the armrest inwards towards the seat to disengage the lock, then move it to the desired position (e.g., fully upright, angled, or completely flat). Release to lock into place. This allows for cross-legged sitting or creating space for pets.
- **Rocking Function & Tension:** The chair supports a rocking function. Use the lever under the seat to enable/disable rocking. A resistance knob is also available to adjust the tension of the rocking motion.
- **360° Swivel & Wheels:** The chair features a smooth 360° swivel and durable wheels for easy movement across various floor types, including carpet and hard floors.

Your browser does not support the video tag.

Video: A short preview demonstrating the adjustable armrests and swivel function of the amseatec Criss Cross Chair.

FEATURES

- **5-Gear Adjustable Armrests:** Provides full angle arm support for cross-legged sitting and enhances overall sitting experience.
- **Pet-Friendly Design:** Adjustable armrests create space for pets, and the widened seat accommodates both cross-legged sitting and pet resting.
- **Stable and Comfortable Seat:** Robust engineered wood base with dual-layer memory foam cushioning (plush top, supportive lower layer) and a wide steel base for stability.
- **Premium PU Leather Cover:** Upholstered with waterproof, cat scratch-proof, and wear-resistant PU leather, easy to wipe clean.



Image: The amseatec Criss Cross Chair in pink, showcasing its wide seat and adjustable armrests in an upright position.



Image: A woman sitting comfortably cross-legged in the chair with a cat beside her, demonstrating the pet-friendly and spacious design.

MAINTENANCE

- **Cleaning:** Wipe clean with a damp cloth. Avoid harsh chemicals that may damage the PU leather.
- **Regular Checks:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten if necessary.
- **Wheel Care:** Keep wheels free of debris to ensure smooth rolling.

TROUBLESHOOTING

If you encounter any issues, please refer to the following common solutions:

- **Chair not adjusting height:** Ensure the gas lift lever is fully engaged and that there is no obstruction. If the issue persists, contact customer support.

- **Armrests not locking:** Ensure the armrest is pushed inwards completely before attempting to position it. If it still doesn't lock, check for any obstructions in the gear mechanism.
- **Squeaking/Noises:** Check and tighten all assembly bolts. Lubricate moving parts if necessary.

SPECIFICATIONS

Brand	amseatec
Model Name	LY-8267
Product Dimensions	27.2"D x 32.7"W x 36.5"H
Item Weight	40.8 pounds
Maximum Weight Recommendation	300 Pounds
Material	Premium PU Leather, High-density Supportive Foam, Engineered Wood, Steel
Special Features	Adjustable Height, 5-Gear Adjustable Armrests, Pet-Friendly, Swivel, Rocking Function

WARRANTY & SUPPORT

The amseatec Criss Cross Chair comes with a **5-year warranty**. For any questions, technical support, or warranty claims, please contact amseatec customer service through their official website or the retailer where the product was purchased. 24/7 Text Support is also available.