

LAUDLIFE BW618-NEW

LAUDLIFE Foldable Food Warming Mat

MODEL: BW618-NEW

[Introduction](#)

[Safety Instructions](#)

[Features](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

1. Introduction

Thank you for choosing the LAUDLIFE Foldable Food Warming Mat. This manual provides essential information for the safe and efficient use of your new appliance. Please read it thoroughly before first use and retain it for future reference.

This food warming mat is designed to keep cooked food warm for extended periods, making it ideal for daily meals, gatherings, and special occasions. Its foldable design and advanced heating technology ensure convenience and performance.



Image 1.1: The LAUDLIFE Foldable Food Warming Mat in use, displaying various dishes being kept warm. The mat is beige and features a control panel on one side.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs if provided.
- To protect against electrical hazards, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause

injuries.

- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This warming mat features an automatic power-off protection mechanism that activates after 5 hours of continuous use to prevent accidents.
- A child lock function is integrated to prevent accidental changes to settings or operation by children.
- The bottom temperature of the warming mat reaches approximately 122°F (50°C). While this is below the fracture threshold for granite and quartz, it is recommended to avoid direct placement on granite or quartz countertops for optimal care and to prevent potential issues.

3. Product Features

The LAUDLIFE Foldable Food Warming Mat is equipped with several features designed for convenience and performance:

- **Efficient & Even Heating:** Crafted with nano silicone material for excellent heat retention and rapid stereo heat transfer, ensuring food stays warm and flavorful.
- **7 Temperature Settings:** Offers a range of 40-100°C (104-212°F) to suit various food warming needs.
- **Extended Warming:** Capable of maintaining food warmth for up to 99 hours.
- **Versatile Applications:** Suitable for keeping daily meals warm, fermenting dough, thawing frozen foods, and serving at family dinners, gatherings, and events.
- **Tableware Compatibility:** Designed to be compatible with various materials including metal, ceramic, glass, and enamel.
- **Dual Safety Settings:** Includes a 5-hour automatic power-off function and a child lock design for enhanced safety.
- **Foldable Design:** Allows for easy storage and portability.
- **Easy to Clean:** Features an oil-resistant surface that can be wiped clean with a cloth.
- **Quick Heating:** Achieves full-surface heating in approximately 8 seconds.

Support Various Tableware



Nano Silicone



7-Level Modes



timing



LCD Display



Image 3.1: The warming mat demonstrating compatibility with various tableware materials such as enamelware, ceramic, glass, plastic, and stainless steel. The image also highlights the mat's dimensions (23.6 inches by 15.7 inches).

Full-Surface Heating in 8S

Solve All Heating Needs In One Heating



Image 3.2: A diagram showing the internal heating elements and rapid heat distribution across the entire surface of the LAUDLIFE warming mat, achieving full heating in 8 seconds, contrasted with other warming devices that have localized heating spots.

4. Setup

1. **Unpack:** Carefully remove the warming mat and all accessories from the packaging.
2. **Placement:** Unroll the warming mat and place it on a stable, flat, and heat-resistant surface. Ensure there is adequate space around the mat for ventilation. Avoid placing directly on granite or quartz countertops if possible, or use a protective layer underneath.
3. **Connect Power:** Insert the detachable power cord into the designated port on the warming mat's

control panel. Then, plug the power cord into a standard electrical outlet.

4. **Initial Cleaning:** Before first use, wipe the surface of the mat with a damp cloth to remove any dust or residue from manufacturing. Ensure the mat is completely dry before plugging it in.

5. Operating Instructions

Familiarize yourself with the control panel for optimal use.



Image 5.1: A close-up of the control panel on the LAUDLIFE warming mat, showing the power button, temperature adjustment buttons (+/-), timer button, and child lock button. The image also illustrates the 7 temperature levels with corresponding Celsius and Fahrenheit values.

1. **Power On/Off:** Press the power button () on the control panel to turn the mat on or off. The display will illuminate when powered on.
2. **Adjusting Temperature:**
 - Once powered on, use the + and - buttons to cycle through the 7 available temperature settings.
 - The temperature range is 40-100°C (104-212°F). Select the desired temperature based on the food type and desired warmth.
3. **Setting the Timer:**
 - Press the timer button (⌚) to activate the timer function.
 - Use the + and - buttons to set the desired warming duration, up to 99 hours.
 - The display will show the remaining time.
4. **Child Lock Function:**
 - To activate the child lock, press and hold the child lock button () for a few seconds until the lock indicator appears on the display.
 - When the child lock is active, other buttons will be unresponsive, preventing accidental changes.
 - To deactivate, press and hold the child lock button again until the indicator disappears.
5. **Automatic Power-Off:** The mat is equipped with an automatic safety shut-off feature that will turn off the device after 5 hours of continuous operation. This is a safety measure and cannot be disabled.

Keeping Warm & Delicious

Endless Warmth for Endless Gatherings



Image 5.2: A family enjoying a meal, with various dishes placed on the LAUDLIFE warming mat, illustrating its use for extended warming during gatherings. The image highlights the 0-99 hours warming capability.

Versatile Uses:

Beyond keeping food warm, the mat can be used for:

- **Defrosting Food:** Use a lower temperature setting to gently thaw frozen items.
- **Fermenting Dough:** Provides a consistent warm environment for dough rising.
- **Warming Milk/Beverages:** Place bottles or cups directly on the mat to warm their contents.
- **Warming Facial Masks:** Can be used to gently warm beauty products.

Adaptable Throughout the Seasons

More than A Simple Warming Tray



Image 5.3: The LAUDLIFE warming mat showcasing its adaptability for various tasks beyond food warming, including warming facial masks, defrosting food, fermenting dough, and warming milk.

6. Care and Maintenance

1. Cleaning:

- Always unplug the warming mat from the power outlet and allow it to cool completely before cleaning.
- The mat features an oil-resistant surface. Wipe the surface with a soft, damp cloth. For stubborn stains, a mild detergent can be used.
- Do not immerse the mat or its power cord in water or any other liquid.

- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the surface.
- Ensure the mat is completely dry before storing or reconnecting to power.

2. Storage:

- The mat is foldable for compact storage. Once cool and clean, gently roll it up.
- The power cord is detachable for easier storage.
- Store the mat in a dry, cool place, away from direct sunlight and extreme temperatures.

Easy to Clean & Storage



Image 6.1: The LAUDLIFE warming mat demonstrating its easy cleaning process with a cloth wiping an oil-resistant surface, and its compact roll-up storage in a drawer, highlighting the 74-inch detachable power cord.

7. Troubleshooting

If you encounter issues with your LAUDLIFE Foldable Food Warming Mat, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Mat does not turn on.	No power supply; Power cord not properly connected; Unit is off.	Ensure the power cord is securely plugged into both the mat and a working electrical outlet. Press the power button to turn on.
Mat is not heating.	Temperature setting is too low; Automatic power-off activated; Faulty unit.	Increase the temperature setting. Check if 5 hours of continuous use have passed (auto-off). If problem persists, contact customer support.
Controls are unresponsive.	Child lock is active.	Deactivate the child lock by pressing and holding the child lock button.
Food is not staying warm enough.	Incorrect temperature setting; Food container not suitable for warming.	Increase the temperature setting. Ensure food containers are made of compatible materials (metal, ceramic, glass, enamel) and have lids to retain heat.

If the issue persists after attempting these solutions, please contact LAUDLIFE customer support for further assistance.

8. Specifications

Feature	Specification
Model Number	BW618-NEW
Dimensions (Unfolded)	Approx. 24 x 16 inches (60.96 x 40.64 cm)
Package Dimensions	16.3 x 4.9 x 4.9 inches
Item Weight	1.43 pounds (0.65 kg)
Material	Nano Silicone
Color	Beige
Temperature Settings	7 levels (40-100°C / 104-212°F)
Timer Range	Up to 99 hours
Safety Features	5-hour auto-off, Child Lock
UPC	762032059783

9. Warranty and Customer Support

LAUDLIFE is committed to providing high-quality products. For warranty information, technical support, or any questions regarding your Foldable Food Warming Mat, please contact LAUDLIFE customer service through the retailer where the product was purchased or visit the official LAUDLIFE website.

Please have your model number (BW618-NEW) and purchase details ready when contacting support.