

Cecotec PrecisionCare Aluminium Pro

Cecotec PrecisionCare Aluminium Pro Rotary Shaver User Manual

Model: PrecisionCare Aluminium Pro

[Overview](#) [Setup](#) [Operation](#) [Safety Information](#) [Product](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. SAFETY INFORMATION

Please read all instructions carefully before using the Cecotec PrecisionCare Aluminium Pro Rotary Shaver. Retain this manual for future reference.

- Do not use the shaver near heat sources or liquids.
- Do not charge the shaver during use.
- Do not immerse the shaver completely in water for extended periods, despite its IPX6 rating.
- Keep out of reach of children.
- Use with care to avoid cuts or skin irritation.
- Ensure the charging base and power adapter remain dry.
- Only use the original charging base and adapter provided with the device.

2. PRODUCT OVERVIEW

The Cecotec PrecisionCare Aluminium Pro is a rotary shaver designed for a smooth and precise shave. It features high-quality titanium blades, an LCD screen for battery status, and a durable, water-resistant design.

Key Features:

- **Titanium Blades:** Ensures durability and a sharp, efficient cut.
- **Double Blade Technology:** Provides a closer and more precise shave.
- **80 Minutes Autonomy:** Long-lasting battery for multiple shaves.
- **LCD Screen:** Displays remaining battery life and other indicators.

- **IPX6 Water Resistance:** Allows for wet shaving and easy cleaning under running water.
- **8000 RPM Motor:** Powerful performance for effective hair removal.

Package Contents:

- 1 x Cecotec PrecisionCare Aluminium Pro Shaver
- 1 x User Manual
- 1 x Charging Base
- 1 x Blade Lubricating Oil
- 1 x Cleaning Brush

3. SETUP

3.1 Initial Charging

Before first use, fully charge the shaver. This typically takes several hours. The LCD screen will indicate the charging status.

1. Place the shaver securely onto the charging base.
2. Connect the charging base to a power outlet using the provided adapter.
3. The LCD screen will display the battery percentage increasing during charging.
4. Once fully charged, the screen will show 100%. Disconnect the charger.



Image: The shaver placed on its charging base, indicating proper charging setup.

3.2 Preparing for First Use

After charging, ensure the shaver heads are clean and free from any debris. A quick rinse under water is recommended if using wet.

4. OPERATING INSTRUCTIONS

4.1 Turning On/Off

- To turn on the shaver, press the power button once.
- To turn off the shaver, press the power button again.

4.2 Shaving Technique

For optimal results, follow these guidelines:

1. Ensure your skin is clean. For dry shaving, ensure skin is completely dry. For wet shaving, apply shaving foam or gel.
2. Hold the shaver at a right angle to your skin.
3. Move the shaver in small, circular motions over the skin.

4. Apply gentle pressure. Do not press too hard, as this can cause irritation.
5. Stretch your skin with your free hand to make hairs stand upright, especially in difficult areas like the neck.
6. Shave against the direction of hair growth for a closer shave.



Image: A user demonstrating the circular motion technique for shaving with the rotary shaver.

4.3 Wet and Dry Shaving

The PrecisionCare Aluminium Pro is IPX6 water-resistant, allowing for both dry and wet shaving. Wet shaving with foam or gel can provide a more comfortable experience and reduce skin irritation.

4.4 LCD Display

The integrated LCD screen provides important information:

- **Battery Percentage:** Shows the remaining charge.
- **Charging Indicator:** Illuminates when the shaver is charging.
- **Travel Lock Indicator:** May appear if the travel lock is activated (refer to specific model features for activation/deactivation).

5. MAINTENANCE

Regular cleaning and maintenance ensure optimal performance and extend the lifespan of your shaver.

5.1 Cleaning After Each Use

1. Turn off the shaver.
2. Open the shaver head unit (refer to diagrams in the full manual for specific release mechanism).
3. Rinse the shaver heads and the hair chamber thoroughly under warm running water. The IPX6 rating allows for this.
4. Use the provided cleaning brush to remove any stubborn hair particles.
5. Shake off excess water and allow the shaver head to air dry before closing or storing.



Image: The shaver being cleaned under running water, highlighting its water-resistant feature.

5.2 Blade Lubrication

Periodically lubricate the blades with the provided oil to maintain smooth operation and cutting efficiency. Apply a small drop of oil to each shaving head once a month or as needed.

5.3 Blade Replacement

The titanium blades are designed for long-lasting performance, but they will eventually wear down. Replace the shaving heads when you notice a decrease in shaving performance or increased irritation. Replacement parts can be purchased from authorized Cecotec retailers.

6. TROUBLESHOOTING

If you encounter any issues with your shaver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Low battery or travel lock activated.	Charge the shaver fully. Deactivate travel lock (usually by pressing and holding the power button for a few seconds).
Poor shaving performance / pulling hairs.	Blades are dull or dirty.	Clean the shaving heads thoroughly. Lubricate the blades. If performance does not improve, replace the shaving heads.
Skin irritation after shaving.	Incorrect shaving technique, dull blades, or sensitive skin.	Ensure gentle pressure and circular motions. Try wet shaving with foam. Replace blades if dull. Apply aftershave balm.
Shaver not charging.	Improper connection or faulty charger/base.	Ensure the shaver is correctly seated on the charging base. Check the power adapter and outlet. Contact customer support if issues persist.

7. SPECIFICATIONS

Feature	Detail
Model Name	PrecisionCare Aluminium Pro
Model Number	A01_EU01_116952
Blade Material	Titanium
Blade Type	Double Blade Technology
Motor Speed	8000 rpm
Battery Life	Up to 80 minutes
Power Source	Rechargeable Battery
Water Resistance	IPX6
Display	LCD Screen
Dimensions	15.4 x 6.6 x 6 cm
Weight	350 g
Color	Blue

8. WARRANTY AND SUPPORT

This product is covered by a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Cecotec website for detailed warranty terms and conditions.

For technical support, replacement parts, or any inquiries regarding your Cecotec PrecisionCare Aluminium Pro shaver, please contact Cecotec customer service through their official website or the contact

information provided in your warranty documentation.

Online Resources:

- Official Cecotec Website: www.cecotec.com
- Product Support Page: (Check Cecotec website for specific product support)