

VECELO KHD-CC-RF01-BLK-E1

VECELO Swivel Stool with Backrest and Casters

Model: KHD-CC-RF01-BLK-E1

Instruction Manual

1. SAFETY INFORMATION

Please read and understand all safety information before assembling and using this product. Keep this manual for future reference.

- This product is equipped with casters. Improper use may lead to tipping. Always use the stool on a flat, stable surface.
- The maximum load capacity for this stool is **100 kg (220 lbs)**. Do not exceed this weight limit to prevent damage or injury.
- Ensure all components are securely fastened before use. Regularly check for loose screws or damaged parts.
- Keep children and pets away from the assembly area. Small parts can be a choking hazard.
- Avoid standing on the stool or using it as a ladder.

2. PRODUCT OVERVIEW

The VECELO Swivel Stool is designed for versatility and comfort in various settings such as kitchens, counters, salons, and offices. It features a comfortable backrest, smooth-rolling casters, and an adjustable height mechanism.

Included Parts

- Chair Body x 1
- Casters x 5
- Assembly Tools (if applicable)

製品仕様



Figure 1: Product Dimensions and Weight Capacity. This image illustrates the key dimensions of the VECELO swivel stool, including seat height adjustment range (50-65cm), seat diameter (32cm), backrest height (14cm), and overall height (64-79.5cm). It also indicates a maximum load capacity of 102kg.

3. SETUP AND ASSEMBLY

Assembly is required for this product. Please follow these general steps. Refer to the included assembly instructions for detailed diagrams.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all included parts are present.
2. **Attach Casters:** Insert each of the five casters into the holes at the end of the chair base legs. You may need to apply firm pressure and gently wiggle the casters to fully seat them.
3. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled chair base.
4. **Attach Footrest (if applicable):** If your model includes a footrest ring, slide it over the gas lift cylinder and secure it according to the specific instructions.
5. **Attach Seat and Backrest:** Carefully place the seat assembly onto the top of the gas lift cylinder. The backrest is

typically pre-attached to the seat or attaches with screws. Ensure all connections are tight.

6. **Final Check:** Once assembled, gently sit on the stool to ensure all parts are properly engaged and stable.

4. OPERATING INSTRUCTIONS

Height Adjustment

- To raise the seat height: While standing, pull the height adjustment lever upwards. The seat will rise automatically. Release the lever at the desired height.
- To lower the seat height: While seated, pull the height adjustment lever upwards. The seat will lower under your weight. Release the lever at the desired height.



座面の高さはワンタッチで調整OK、最大調整範囲で自分にぴったりの高さに設定可能



音が気にならない静音設計で、静かな朝も快適に過ごせる



作業や休憩に合わせて簡単に高さ調整ができ、どんなシーンにもフィット

Figure 2: Height Adjustment Mechanism. This image demonstrates the one-touch height adjustment feature of the VECELO swivel stool and highlights its quiet design, suitable for various work or relaxation scenarios.

Caster Movement

- The stool is equipped with 360-degree swivel casters for easy mobility.
- To move the stool, simply push or pull it in the desired direction.
- Ensure the path is clear of obstacles to prevent tipping or damage to the casters.

昇降式&キャスター付きでスムーズに移動。調理中や接客中もストレスフリー。
「ちょっと座りたい」をしっかりサポートし、施術やカウンター作業も疲れにくく快適。
スリムなのに安定感があり、キッチンやサロンにぴったりのワークチェアです。



Figure 3: Caster Mobility. The image shows the VECELO swivel stool in a kitchen, emphasizing its smooth mobility with 360-degree rotating casters for stress-free movement during tasks.

5. MAINTENANCE

- **Cleaning:** For general cleaning, wipe the stool with a dry cloth. For more stubborn dirt, a damp cloth (wet wipe) can be used. Avoid harsh chemicals or abrasive cleaners.
- **Caster Maintenance:** Periodically check the casters for hair, dust, or debris that may hinder smooth movement. Clean them as needed.
- **Hardware Check:** Every few months, inspect all screws and bolts to ensure they are tight. Re-tighten any loose hardware to maintain stability and safety.

- **Storage:** Store the stool in a dry environment, away from direct sunlight or extreme temperatures.

6. TROUBLESHOOTING

- **Casters not inserting fully:** If casters are difficult to insert during assembly, apply firm, even pressure and gently wiggle them side-to-side until they click into place.
- **Stool feels unstable:** Ensure all assembly screws are tightened. Check that the gas lift is fully seated in both the base and seat mechanisms. Avoid exceeding the maximum weight capacity.
- **Height adjustment not working:** Check if the lever is fully engaged. Ensure there are no obstructions around the gas lift cylinder. If the issue persists, the gas lift may need replacement.
- **Casters not rolling smoothly:** Inspect casters for accumulated debris (hair, lint) and clean them thoroughly. Ensure the stool is on a suitable surface for casters (e.g., not thick carpet).

7. SPECIFICATIONS

Feature	Specification
Model Number	KHD-CC-RF01-BLK-E1
Product Dimensions (D x W x H)	38 x 32 x 64 cm (15 x 12.6 x 25.2 inches)
Adjustable Seat Height	50-65 cm (19.7-25.6 inches)
Seat Diameter	32 cm (12.6 inches)
Backrest Height	15.5 cm (6.1 inches)
Item Weight	4.15 kg (9.15 lbs)
Maximum Load Capacity	100 kg (220 lbs)
Materials	Seat: PVC; Frame: Alloy Steel; Casters: Polypropylene
Color	Black
Assembly Required	Yes
UPC	840510311797
Country of Origin	China

8. WARRANTY AND SUPPORT

VECELO is committed to providing quality products. For any questions, concerns, or issues regarding your swivel stool, please contact VECELO customer support.

- **Warranty Information:** Specific warranty details may vary by region and retailer. Please refer to your purchase documentation or contact VECELO customer service for warranty terms.
- **Customer Support:** For assistance, please visit the official VECELO website or contact the retailer from whom you purchased the product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FMCNN9FQ>

More documents and user manuals: <https://manuals.plus/>