



Manuals.plus /

› FOREVER /

› FOREVER IGO Watch 4 Smart Watch User Manual

FOREVER JW-602

FOREVER IGO Watch 4 Smart Watch User Manual

Model: JW-602

1. INTRODUCTION

The FOREVER IGO Watch 4 (Model JW-602) is a smart watch designed to integrate modern design with comprehensive functionality. It features a clear AMOLED display, a lightweight build, and a range of health and fitness tracking capabilities. This manual provides instructions for setting up, operating, and maintaining your device.

2. WHAT'S IN THE BOX

Please check the contents of your product packaging. The following items should be included:

- FOREVER IGO Watch 4 Smart Watch
- Magnetic Charger
- Two Interchangeable Straps
- User Manual

3. PRODUCT OVERVIEW

The IGO Watch 4 features a 1.28-inch AMOLED screen with a 416 x 416 pixel resolution, providing clear visuals. Its design is ultra-light, weighing approximately 31.5g, ensuring comfort during wear. The device is also IP67 waterproof, making it suitable for various conditions.



Figure 3.1: The FOREVER IGO Watch 4 displaying multiple customizable watch faces.

The watch is equipped with a 280mAh battery, offering up to 7 days of operation on a single charge. Charging is facilitated by a magnetic charger, achieving full capacity in approximately 2 hours.



1,28"



416 × 416 px



Figure 3.2: Visual representation of the 1.28-inch screen size and 416x416 pixel resolution of the IGO Watch 4.

 33,9 g

 10,6 mm



Figure 3.3: Side view of the IGO Watch 4, highlighting its slim profile (10.6 mm thickness) and lightweight design (33.9 g).

4. SETUP

4.1. Charging the Device

1. Connect the magnetic charger to a USB power source (e.g., computer USB port or a 5V/1A USB wall adapter).
2. Attach the magnetic end of the charger to the charging contacts on the back of the watch. Ensure a secure connection.
3. The watch display will indicate charging status. A full charge typically takes approximately 2 hours.

4.2. App Installation and Pairing

1. Download the "Fitcloud Pro" application from your smartphone's app store (available for Android and iOS).
2. Open the Fitcloud Pro app and follow the on-screen instructions to create an account or log in.
3. Enable Bluetooth on your smartphone.
4. Within the Fitcloud Pro app, navigate to the device pairing section and search for your IGO Watch 4.
5. Select your watch from the list of available devices to establish a Bluetooth connection. Confirm any pairing requests on both your watch and smartphone.

5. OPERATING INSTRUCTIONS

5.1. Basic Navigation

- **Touchscreen:** Swipe left, right, up, or down to navigate through menus and features. Tap to select an option.
- **Side Buttons:** Use the physical buttons on the side of the watch for specific functions, such as returning to the home screen or accessing the app list.

5.2. Notifications

Once paired with your smartphone, the IGO Watch 4 can display incoming calls, SMS messages, and notifications from various applications. Ensure notification permissions are enabled in the Fitcloud Pro app and your phone's settings.

5.3. Smart Features

The watch offers several practical smart features:

- **Music Control:** Control music playback on your smartphone directly from your watch.
- **Remote Photos:** Use your watch as a remote shutter for your smartphone camera.
- **Alarm Clock:** Set alarms directly on the watch.
- **Calculator:** Access a basic calculator function.
- **Weather Forecast:** View current weather conditions and forecasts.
- **Find Phone/Watch:** Locate your paired smartphone or watch if misplaced.



Figure 5.1: Icons illustrating smart features such as music control, weather, camera remote, and alarm on the IGO Watch 4.

6. HEALTH MONITORING FEATURES

The IGO Watch 4 includes a suite of health monitoring functions to help you track your well-being:

- **Heart Rate Monitor:** Continuously tracks your heart rate.
- **Sleep Monitor:** Analyzes sleep patterns, including duration and quality.

- **Blood Pressure & Saturation:** Provides estimates of blood pressure and oxygen saturation levels.
- **Breathing Exercises:** Guided breathing exercises for relaxation.
- **Liquid Reminders:** Prompts to ensure adequate hydration.
- **Women's Health Features:** Specific tracking and reminders related to women's health.



Figure 6.1: The IGO Watch 4 showing detailed sleep monitoring data, including sleep duration and historical trends.

Note: The health data provided by this device is for reference only and should not be used for medical diagnosis or treatment. Consult a healthcare professional for medical advice.

7. SPORTS MODES

The IGO Watch 4 supports over 100 sports modes to track your physical activity. It automatically counts steps, calories burned, and training time. Activity history is saved and accessible through the Fitcloud Pro app.



Figure 7.1: The IGO Watch 4 showing activity metrics such as calories burned, steps taken, and distance covered during a workout.

8. MAINTENANCE

8.1. Water Resistance (IP67)

The IGO Watch 4 is rated IP67 waterproof, meaning it is protected against dust ingress and can withstand immersion in water up to 1 meter for 30 minutes. It is suitable for daily use, such as washing hands or walking in the rain. Avoid prolonged immersion, hot water, or use during swimming or diving.



Figure 8.1: Graphic illustrating the IP67 water resistance rating of the IGO Watch 4.

8.2. Cleaning

To clean your watch, gently wipe the screen and body with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials. Ensure the charging contacts are clean and dry before charging.

9. TROUBLESHOOTING

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the magnetic charger and allow it to charge for at least 30 minutes before attempting to power it on.
- **Cannot pair with smartphone:**
 - Ensure Bluetooth is enabled on your smartphone.
 - Make sure the watch is within Bluetooth range of your phone.
 - Restart both your watch and smartphone.
 - Check if the Fitcloud Pro app has necessary permissions enabled.
- **Inaccurate health data:** Ensure the watch is worn snugly on your wrist, not too tight or too loose. Keep the sensor clean. Remember that data is for reference only.
- **Notifications not appearing:** Verify that notification permissions are granted to the Fitcloud Pro app in your phone's settings. Check app settings within Fitcloud Pro to ensure notifications are enabled for desired applications.

10. SPECIFICATIONS

Feature	Detail
Model Name	iGo Watch 4 JW-602
Screen Size	1.28 Inches AMOLED
Resolution	416 x 416 px
Battery Capacity	280 mAh
Battery Life	Up to 7 days (typical use)
Charging Time	Approx. 2 hours
Water Resistance	IP67
Connectivity	Bluetooth, USB (for charging)
Compatibility	Android, iOS
Operating System	Android Wear 2.11 <i>(Note: This may refer to compatibility rather than the watch's native OS.)</i>
Weight	Approx. 31.5g (watch only)
Dimensions	0.2 x 1.57 x 9.84 inches (product dimensions, may include strap length)
Case Material	Plastic
Band Material	Silicone

11. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the warranty card included with your product or visit the official FOREVER website. Contact details for customer service can typically be found on the manufacturer's website or in the product packaging.