

[Manuals.plus](#) /

› [MAMAPRO](#) /

› MAMAPRO PureMix Formula Maker (Model MFD02) - Instruction Manual

MAMAPRO MFD02

MAMAPRO PureMix Formula Maker (Model MFD02) - Instruction Manual

Your guide to precise and effortless formula preparation.

INTRODUCTION

The MAMAPRO PureMix Formula Maker is designed to simplify the process of preparing baby formula. This device ensures accurate water-to-formula ratios, precise temperature control, and thorough mixing to deliver nutritionally consistent and clump-free bottles. It is compatible with most formula brands and bottle sizes, offering convenience for caregivers.

SAFETY INFORMATION

- Always read and follow all instructions before use.
- Keep the appliance out of reach of children.
- Use only bottled or distilled water as recommended by your formula brand.
- Ensure the formula maker is placed on a stable, level surface.
- Always check the temperature of the prepared formula before feeding your baby.
- The product is made with BPA-free materials.
- Do not use for hypoallergenic formulas unless specifically advised by a medical professional.

WHAT'S IN THE BOX

Steps 1: Your Formula Ratio Setting

Tap  adjusting water and powder amounts with the + / - buttons

2. Press  to save



Image: The MAMAPRO PureMix Formula Maker and its accessories as packaged.

- Formula Dispenser Machine x1
- Tall Bottle Holder x1
- Short Bottle Holder x1
- Instruction Manual x1

SETUP

1. **Initial Cleaning:** Before first use, disassemble and wash all removable parts (water tank, formula container, funnel, bottle holders) with warm soapy water. Rinse thoroughly and allow to air dry.
2. **Assemble Water Tank:** Fill the large 67oz water tank with bottled or distilled water up to the MAX line. Place the water tank securely into the machine.
3. **Fill Formula Container:** Open the formula container lid at the top of the machine. Pour your chosen powdered formula into the container, ensuring it does not exceed the MAX line. Close the lid and lock it in place.
4. **Select Bottle Holder:** Choose the appropriate bottle holder (tall or short) based on your bottle's size. The holders fit most bottle brands (excluding silicone bottles). Place the bottle holder onto the machine's base.
5. **Place Bottle:** Position your clean baby bottle into the selected holder. Ensure the bottle neck is above the reference line indicated on the machine for proper dispensing.

Compatible with Most Formula and Bottle Brands

Excludes Silicone Bottles and Hypoallergenic Formula



Image: Components of the PureMix Formula Maker, including the powder container, water tank, and bottle holders.

OPERATING INSTRUCTIONS

1. **Power On:** Plug in the machine. The LCD touchscreen will illuminate.
2. **Set Formula Ratio:** Tap the 'Formula Prep' icon. Use the '+' and '-' buttons to adjust the water and powder amounts according to your formula's instructions. Press 'OK' to save. The machine features memory-saving, so your last settings will be retained.
3. **Customize Temperature and Volume:** Tap the temperature icon to select one of four precise temperature levels (95°F, 98°F, 104°F, 110°F). Tap the volume icon to choose your desired portion size (2-10oz).
4. **Start Dispensing:** Once settings are confirmed, press 'OK' to begin. The machine will heat the water to the set temperature, then dispense the water and formula into the bottle. The external spinning mixer will ensure a smooth, clump-free mix.

5. **Completion:** The machine will beep when the bottle is ready. Carefully remove the bottle, attach the nipple, and check the temperature before feeding.



Image: Setting the formula ratio on the touchscreen display.

Steps 3: Formula Dispensing



Image: Customizing water temperature and volume on the control panel.

Independent,More HygienicMore Healthy



Image: Formula dispensing in progress with the bottle on the mixing base.

Video: How to Use the Formula Maker

Your browser does not support the video tag.

Video Description: A step-by-step guide demonstrating the process of setting up and operating the MAMAPRO PureMix Formula Maker, including filling the water and formula, selecting bottle holders, and initiating formula preparation.

MAINTENANCE AND CLEANING

- **Daily Cleaning:** After each use, remove the funnel and mixing base. Wash them with warm soapy water, rinse thoroughly, and air dry.
- **Water Tank:** Clean the water tank regularly to prevent mineral buildup.
- **Descaling:** The machine has a 'Descaling' function. Follow the on-screen instructions for periodic descaling to maintain optimal performance and hygiene.

Video: Error E1 Troubleshooting Guide (Includes Cleaning)

Your browser does not support the video tag.

Video Description: This video demonstrates how to troubleshoot an E1 error on the formula maker, which often involves cleaning the funnel and ensuring proper assembly. It shows the disassembly and cleaning of the mixing components.

TROUBLESHOOTING

E1 Error

The E1 error typically indicates an issue with the water system or the mixing components. Common causes include:

- **Improper Funnel Installation:** Ensure the funnel is correctly inserted into the holder and clicks into place.
- **Clogged Funnel:** Formula residue can build up in the funnel, causing blockages. Regularly clean the funnel as part of daily maintenance.
- **Water Tank Issues:** Verify the water tank is properly seated and filled with water.
- **Bottle Placement:** Ensure the bottle and bottle holder are correctly aligned and the bottle opening is above the reference line.

If the E1 error persists after checking these points, refer to the 'Error E1 Troubleshooting Guide' video in the Maintenance section or contact customer support.

SPECIFICATIONS

Item Model Number	MFD02
Material Composition	ABS
Item Weight	13.47 pounds
Package Dimensions	19.3 x 15 x 9.7 inches
Additional Product Features	Accurate Temperature Control, Automatically Mix Smooth Formula, Customize 4 temperatures (±1°F) and 2–10oz powder (±0.1g), Precise Ratio

WARRANTY AND SUPPORT

For warranty information, technical support, or any questions regarding your MAMAPRO PureMix Formula Maker, please contact MAMAPRO customer service directly. Refer to the contact details provided in your product packaging or on the official MAMAPRO website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FQJMTRBG>

More documents and user manuals: <https://manuals.plus/>