

[Manuals.plus](#) /

› [DOOGEE](#) /

› DOOGEE Anywise W1 Smart Watch User Manual

DOOGEE Anywise W1

DOOGEE Anywise W1 Smart Watch User Manual

Model: Anywise W1

1. INTRODUCTION

This manual provides essential information for setting up, operating, and maintaining your DOOGEE Anywise W1 Smart Watch. Please read this manual thoroughly to ensure proper use and to fully utilize all features of your device.



Image: Overview of the DOOGEE Anywise W1 Smart Watch and its main features.

2. PACKAGE CONTENTS

Verify that all items are present in your product package:

- 1 X Anywise W1 Smartwatch
- 1 X Magnetic Charging Cable
- 2 X Watch Straps (1*Silicone Strap + 1*Braided Strap)
- 1 X User Guide
- 1 X Instruction Manual
- 1 X Service Card

Package Contents

- 1 X Anywise W1 Smartwatch
- 1 X Magnetic Charging Cable
- 2 X Freebies: 1*Silicone Strap+1*Braided Strap
- 1 X Color Box
- 1 X Film Screen Protector
- 1 X User Guide
- 1 X Instruction Manual
- 1 X Service Card



Image: The DOOGEE Anywise W1 Smart Watch and its accessories as found in the box.

3. SETUP

3.1 Initial Charging

Before first use, fully charge your DOOGEE Anywise W1 Smart Watch. Connect the magnetic charging cable to the charging pins on the back of the watch and plug the USB-A end into a compatible power source. The watch display will indicate charging status.

Video: Demonstrates connecting the magnetic charging cable to the watch and a USB power source.

3.2 App Installation and Pairing

1. Download the official DOOGEE Fit application from your smartphone's app store (compatible with Android and iPhone).
2. Open the app and create an account or sign in.
3. Follow the on-screen prompts to set up your personal profile (gender, height, weight, age, daily goals).
4. Enable Bluetooth on your smartphone and allow the DOOGEE Fit app to access Bluetooth.
5. In the app, select 'Add Device' and choose 'DOOGEE Anywise W1' from the list of available devices.

6. Confirm the pairing request on both your smartphone and the watch.

Video: Shows the process of setting up the DOOGEE Fit application on a smartphone and pairing it with the watch.

3.3 Language Selection

After initial charging and pairing, you may need to select your preferred language on the watch. Tap the screen to navigate through language options and select 'English'.

4. OPERATING INSTRUCTIONS

4.1 Display and Navigation

The DOOGEE Anywise W1 features a 1.43-inch AMOLED high-definition touch screen, providing clear visibility in various conditions. Navigate the watch interface by swiping left, right, up, or down, and tapping to select options.

1.43" Brilliant AMOLED Display

The screen is clearly visible even in outdoor sunlight.



Image: The watch display showing a notification, highlighting its clarity.

4.2 GPS Functionality

The watch includes built-in Dual-Band GPS (L1+L5) with six-satellite support (GPS, GLONASS, Beidou,

Galileo, QZSS, AGPS) for fast and accurate location tracking during outdoor activities.

Accurate GPS Navigation & Recording Tracking



L1 + L5
Dual-Band GPS



Six Global
Satellite Systems



Image: The watch displaying GPS navigation during a run.

4.3 Water Resistance

The DOOGEE Anywise W1 has a 5ATM waterproof rating, making it suitable for swimming, showering, and use in various harsh environments.

5ATM Water Resistance

Ready for Rainy Days and Pool Laps

With 50m deep water resistance, fit your urban rhythm without worry.



Image: The watch being used in water, showcasing its water resistance.

4.4 Battery Life

Equipped with a 550mAh high-capacity battery, the watch offers up to 12 days of daily use and 40 hours of continuous GPS positioning.

12-Day Battery Life

Charge Less, Do More



30 Days+
Standby



8-12 Days
Daily Use



3-5 Days
Heavy Use



30 Hours
GPS Navigation

12-Day



Note: Battery life may vary depending on settings, operating conditions, and other factors, so actual results may differ from lab data.

Image: Visual representation of the watch's extended battery life.

4.5 Sports Modes

The watch supports over 170 sports modes. Connect to the app to download more. It monitors critical data like workout heart rate, distance, speed, and calories in real-time.

170+ Sports Modes

Track Every Move, Indoors or Out



Cycling



Rowing Machine



Walking



Running



Elliptical Trainer



Still



Image: Examples of different sports modes available on the watch.

4.6 Health Monitoring

The watch provides comprehensive health monitoring, including real-time heart rate, sleep tracking, stress levels, and blood oxygen saturation. Access these metrics through the DOOGEE Fit app.

4.7 Communication & AI Features

- **Bluetooth Calling:** Make and answer calls directly from the watch. Up to 100 contacts can be imported via the app.
- **AI Voice Assistant:** Utilize AI functions for dialing, Q&A, and real-time translation (voice input to text display and voice announcements).
- **Notifications:** The watch alerts you to incoming messages and calls. Note: The watch cannot reply to messages.

4.8 Additional Features

- **LED Flashlight:** A 60 LM LED flashlight with 4 brightness levels.
- **Compass:** Integrated compass function for outdoor navigation.
- **Daily Tools:** Music control, weather updates, stopwatch, alarm, camera control, SOS mode, and voice recording.

4.9 Changing Watch Faces

Customize your watch's appearance by changing watch faces through the DOOGEE Fit app. Navigate to the watch face section in the app to browse and apply different styles.

4.10 Changing Watch Straps

The watch comes with two interchangeable straps (silicone and braided). To change a strap, locate the small pin on the underside of the strap connection point, slide it to release, and then attach the new strap by aligning the pins and releasing them into the watch lugs.

5. MAINTENANCE

To ensure the longevity and optimal performance of your DOOGEE Anywise W1 Smart Watch, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the watch and straps with a soft, damp cloth. Avoid harsh chemicals or abrasive materials.
- **Drying:** After exposure to water, ensure the watch is completely dry before charging or using buttons.
- **Storage:** Store the watch in a cool, dry place when not in use.
- **Avoid Extreme Conditions:** While rugged, prolonged exposure to extreme temperatures or direct sunlight can affect battery life and component integrity.

6. TROUBLESHOOTING

If you encounter issues with your DOOGEE Anywise W1 Smart Watch, refer to the following common solutions:

- **Watch not turning on:** Ensure the watch is fully charged. Connect it to the charger for at least 30 minutes.
- **Unable to pair with smartphone:** Check that Bluetooth is enabled on your phone and the watch. Ensure the watch is within range of your phone. Restart both devices and try pairing again.
- **Inaccurate health data:** Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensors on the back of the watch.
- **GPS not connecting:** Ensure you are in an open outdoor area with a clear view of the sky. Allow a few minutes for the watch to acquire a signal.
- **Notifications not appearing:** Check the notification settings in the DOOGEE Fit app and your smartphone's system settings to ensure permissions are granted.

For further assistance, consult the DOOGEE Fit app's help section or contact customer support.

7. SPECIFICATIONS

Feature	Specification
Memory Storage Capacity	35 GB

Feature	Specification
Wireless Communication Standard	Bluetooth
Screen Size	1.43 Inches
Brand	DOOGEE
Color	Black
Band Material Type	Silicone, Braided
Supported Application	Fitness Tracker, Sleep Monitor, Heart Rate Monitor, Pedometer, Blood Pressure Monitor, Multisport Tracker, Reminders, Calendar
Metrics Measured	Heart Rate Monitor, Sleep Duration, Stress Monitor, Blood Oxygen Monitor
Maximum Display Brightness	800 Nit
Communication Feature	Bluetooth

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the Service Card included in your package or visit the official DOOGEE website. You can also find additional resources and FAQs within the DOOGEE Fit application.