

[Manuals.plus](#) /

› [YINMIK](#) /

› YINMIK YK-F02 Food pH Probe Replacement Instruction Manual

YINMIK Probe-F02

YINMIK YK-F02 Food pH Probe Replacement Instruction Manual

Model: Probe-F02

1. PRODUCT OVERVIEW

This document provides instructions for the YINMIK Probe-F02, a replacement pH electrode designed for the YINMIK YK-F02 Food pH Meter. This probe is engineered for stable and accurate pH and temperature measurements in various food and liquid applications.

YINMIK New pH Probe for F02 pH Meter

No worries about the electrode
probe breaking



Image 1: YINMIK YK-F02 Food pH Probe Replacement. This image shows the replacement probe alongside the main YK-F02 pH meter unit, highlighting its compatibility and design.

Key Features:

- **High-Tech pH Electrode Design:** Features a threaded design combined with a metal blade to prevent probe damage and ensure stable data transmission.
- **Accurate Measurement:** Utilizes a high-tech green glass probe for precise pH and temperature level measurements.
- **Easy Replacement:** Designed for straightforward installation and removal from the YK-F02 meter.



High-Tech pH Electrode Design



Highly stable data transmission interface for more stable pH value display



Threaded design, combined with a metal blade, prevents probe damage



High-tech green glass probe for accurate pH and temperature level measurement

Image 2: High-Tech pH Electrode Design. This image illustrates the internal components and design features of the pH probe, emphasizing its durability and measurement stability.

2. SETUP AND PROBE REPLACEMENT

Follow these steps to replace the pH electrode on your YINMIK YK-F02 Food pH Meter.

1. **Screw off the Ring:** Gently twist and remove the retaining ring that secures the existing probe to the meter body.
2. **Unplug the Old Probe:** Carefully pull the old probe straight out from the meter.
3. **Align Grooves:** Take the new Probe-F02 replacement. Ensure the grooves on the probe align with the corresponding slots inside the meter's connection port.
4. **Install the New Probe:** Push the new probe firmly into the meter until it is fully seated.
5. **Screw on the Ring:** Reattach and tighten the retaining ring to secure the new probe in place. Do not overtighten.

Easy to Replace the Electrode




Image 3: Easy Electrode Replacement Steps. This diagram visually guides the user through the five-step process of replacing the pH probe, from unscrewing the ring to securing the new probe.

3. OPERATING INSTRUCTIONS

Once the new probe is installed, the YINMIK YK-F02 Food pH Meter is ready for use. Refer to your YK-F02 meter's main instruction manual for detailed operating procedures. General steps include calibration, sample measurement, and data recording.

Calibration:

Regular calibration ensures accurate readings. Use pH calibration powders (e.g., pH 4.00, pH 6.86, pH 9.18) to calibrate your meter with the new probe. Follow the calibration instructions provided with your YK-F02 meter.

More Precise pH Probe with pH Calibration Powder




Image 4: pH Probe Calibration. This image demonstrates the process of calibrating the pH meter using different pH calibration solutions, essential for maintaining accuracy.

Measurement Applications:

The YINMIK YK-F02 pH meter with this probe is suitable for a wide range of applications, including:

- Meat and Cheese
- Sourdough and Cosmetics
- Pools and Aquariums
- Brewing and Drinking Water

YINMIK pH Meter for **all Applications**




Image 5: YINMIK pH Meter for All Applications. This image showcases various uses for the pH meter, including measuring pH in meat, cheese, sourdough, cosmetics, pools, aquariums, brewing, and drinking water.

Instructional Videos:

Your browser does not support the video tag.

Video 1: Food pH Meter Using Video. This video demonstrates the practical application of a food pH meter, showing how to take measurements in various food items and liquids.

Your browser does not support the video tag.

Video 2: PH Monitor Video. This video provides a general overview of using a pH monitor, including basic operation and reading results.

Your browser does not support the video tag.

Video 3: OBEST Food Acidity Meter Temperature 2 in 1. This video showcases the use of a food acidity meter, demonstrating how to measure pH and temperature in food products.

4. MAINTENANCE

Proper maintenance extends the life and accuracy of your pH probe.

- **Cleaning:** After each use, rinse the probe thoroughly with distilled or deionized water to remove any sample residue. For stubborn residues, use a mild cleaning solution specifically designed for pH electrodes.
- **Storage:** Always store the pH probe in a storage solution (e.g., 3M KCl solution) or a dedicated pH electrode storage cap. Never store the probe dry, as this can damage the glass membrane.
- **Avoid Damage:** Handle the probe carefully. The glass bulb is fragile. The threaded design with a metal blade helps prevent damage, but care is still required.

5. TROUBLESHOOTING

If you encounter issues with your YINMIK YK-F02 Food pH Probe, consider the following:

- **Inaccurate Readings:**
 - Ensure the probe is properly calibrated. Recalibrate if necessary.
 - Check if the probe is clean. Residue can affect readings.
 - Verify the storage solution. A dry probe or incorrect storage solution can lead to drift.
 - The probe may be old or damaged. pH electrodes have a limited lifespan and may need replacement if consistently inaccurate after cleaning and calibration.
- **Slow Response Time:**
 - Clean the probe thoroughly.
 - Ensure the probe is adequately hydrated in storage solution.
- **No Reading/Error Message:**
 - Check if the probe is securely connected to the meter.
 - Inspect the probe for visible damage (e.g., cracked glass bulb). If damaged, replace the probe.

6. SPECIFICATIONS

Specification	Detail
Manufacturer	YINMIK
Part Number	Probe-F02
Item Model Number	Probe-F02
Item Weight	60 g
Parcel Dimensions	18.5 x 3.7 x 3.5 cm
Item Package Quantity	1
Measurement Accuracy	+/- 0.5%
Included Components	pH Probe for F02 Food pH Meter
Country of Origin	China

7. WARRANTY AND SUPPORT

For warranty information or technical support regarding your YINMIK Probe-F02 replacement pH electrode, please contact YINMIK customer service directly. Refer to the original packaging or the YINMIK website for contact details.

© 2026 YINMIK. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question