

## KALPADIVES PD-YS022

# KALPADIVES Pagani Design Men's Automatic Watch PD-YS022 Instruction Manual

Model: PD-YS022

## INTRODUCTION

---

This manual provides essential information for the proper use and care of your KALPADIVES Pagani Design Men's Automatic Watch, model PD-YS022. This timepiece features an SL1951 self-winding movement, a distinctive tourbillon-style open dial, and is crafted for durability and precision. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

## PRODUCT OVERVIEW

---

The PD-YS022 watch combines robust construction with intricate design. Key features include:

- **Movement:** SL1951 self-winding automatic movement with a tourbillon-style open dial.
- **Case Material:** Durable stainless steel.
- **Crystal:** Synthetic sapphire glass for superior scratch resistance.
- **Strap:** Comfortable fluorine rubber belt.
- **Water Resistance:** 100 meters (10 ATM), suitable for swimming and sports.
- **Luminous Features:** Luminous hands for visibility in low light conditions.
- **Design:** Bold 44mm dial with a transparent case back showcasing the automatic movement.



Image: Front view of the Pagani Design PD-YS022 watch, featuring a deep blue dial with visible automatic movement components and a matching blue fluorine rubber strap.



Image: The Pagani Design PD-YS022 watch worn on a wrist, showcasing its size and aesthetic appeal with the deep blue dial and strap.



Image: A detailed close-up of the watch dial, highlighting the intricate tourbillon-style mechanism, date sub-dial, and textured blue surface.

## SETUP AND INITIAL USE

### Winding the Watch

Your PD-YS022 is an automatic mechanical watch. It is powered by the motion of your wrist. If the watch has stopped or has not been worn for an extended period, it will need to be manually wound to initiate power reserve.

1. **Manual Winding:** To manually wind the watch, rotate the crown clockwise approximately 20-30 times while it is in its normal, pushed-in position. This will provide sufficient power to start the watch and build up a power reserve.
2. **Automatic Winding:** Once manually wound, wearing the watch for 8-10 hours a day will keep it sufficiently wound through the natural motion of your arm.

### Setting the Time and Date

To set the time and date on your watch:

1. **Pull the Crown:** Gently pull the crown out to the first click position to set the date, or to the second click position to set the time.
2. **Set the Date:** In the first click position, rotate the crown to adjust the date. Avoid setting the date between 9

PM and 3 AM, as this can damage the movement.

3. **Set the Time:** In the second click position, rotate the crown to move the hands clockwise until the correct time is displayed. Ensure you differentiate between AM and PM when setting the time to avoid the date changing at noon instead of midnight.
4. **Push the Crown Back:** Once the time and date are set, push the crown back into its normal position to secure it and ensure water resistance.

## OPERATING GUIDELINES

---

### Water Resistance

The PD-YS022 watch is rated for 100 meters (10 ATM) water resistance, making it suitable for swimming and showering. However, it is crucial to observe the following precautions:

- **Do Not Press Buttons Underwater:** Never press any buttons or pull the crown while the watch is submerged in water. This can compromise the water seals and lead to water ingress.
- **Avoid Extreme Temperatures:** Do not expose the watch to extremely hot water (e.g., hot tubs, saunas) or extremely cold temperatures, as this can affect the seals and movement.
- **Ensure Crown is Fully Pushed In:** Always ensure the crown is fully pushed in before exposing the watch to water.

### Luminous Display

The watch features luminous hands that absorb light and glow in the dark, providing readability in low-light conditions. Exposure to bright light will enhance the glow effect.

Your browser does not support the video tag.

Video: A demonstration of the Pagani Design PD-YS022 watch, showcasing its design, movement, and water resistance features. This video highlights the watch's aesthetic and functional aspects.

## MAINTENANCE AND CARE

---

To maintain the appearance and functionality of your watch:

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For the fluorine rubber strap, a damp cloth with mild soap can be used, followed by thorough drying.
- **Avoid Chemicals:** Do not expose the watch to harsh chemicals, solvents, or detergents, as these can damage the case, strap, or seals.
- **Storage:** When not wearing the watch, store it in a cool, dry place away from direct sunlight and strong magnetic fields.
- **Professional Servicing:** Mechanical watches benefit from periodic professional servicing (typically every 3-5 years) to ensure optimal performance and lubrication of the movement.

## TROUBLESHOOTING

---

If you encounter issues with your PD-YS022 watch, consider the following:

- **Watch Not Running:**
  - Ensure the watch is sufficiently wound. Manually wind it by rotating the crown clockwise 20-30 times.
  - Wear the watch for several hours to allow the automatic movement to build power reserve.
- **Time or Date Incorrect:**

- Refer to the "Setting the Time and Date" section to correctly adjust.
- Ensure the crown is fully pushed in after setting.

- **Condensation Under Crystal:**

- This may indicate a breach in water resistance. Avoid further water exposure and seek professional service immediately.

For any persistent issues or concerns, please contact customer support.

## SPECIFICATIONS

| Feature              | Detail                     |
|----------------------|----------------------------|
| Brand Name           | KALPADIVES (Pagani Design) |
| Model                | PD-YS022                   |
| Movement             | SL1951 Automatic           |
| Case Material        | Stainless Steel            |
| Case Diameter        | 44mm / 1.73 inches         |
| Case Thickness       | 14.7mm / 0.57 inches       |
| Strap Type           | Fluorine Rubber Belt       |
| Strap Width          | 24mm / 0.94 inches         |
| Max Perimeter        | 220mm / 8.66 inches        |
| Weight               | 121.3g / 0.26lb            |
| Dial Window Material | Synthetic Sapphire Glass   |
| Water Resistance     | 100M (10 ATM)              |
| Clasp Type           | Tang Buckle                |

*Note: Measurements are subject to minor deviation (dimensions  $\pm 1$  mm, weight  $\pm 2$  grams).*

MODEL:PD-YS022

-  Case Thickness:14.7MM/1.47CM/0.57IN
-  Dial diameter :44MM/4.4CM/1.73IN
-  Weight :121.3G/0.26IB/4.28OZ
-  Max Perimeter : 220MM/22CM/8.66IN
-  Movement : SL1951
-  Bracelet width : 24MM/2.4CM/0.94IN
-  Bracelet material : Fluorine rubber belt
-  Dial Window Material Type : Synthetic Sapphire Glass
-  Original gift box



Note:This data is only store measurement data  
There is an error(size  $\pm 1$ MM/0.04in,weight  $\pm 2$ G/0.004ib)

Image: A visual diagram detailing the dimensions (case diameter, thickness, strap width, max perimeter) and key material specifications of the PD-YS022 watch.

## WARRANTY AND SUPPORT

For warranty information or technical support regarding your KALPADIVES Pagani Design PD-YS022 watch, please refer to the warranty card included with your purchase or contact the retailer. Keep your proof of purchase for any warranty claims.

If you have any questions or require assistance, please contact customer service through the platform where the product was purchased.