

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PEJE](#) /

› [PEJE M01Pro AI Smart Glasses User Manual](#)

PEJE M01Pro

PEJE M01Pro AI Smart Glasses User Manual

Model: M01Pro

1. INTRODUCTION

The PEJE M01Pro AI Smart Glasses combine advanced audio, communication, and translation technologies into a stylish and comfortable eyewear design. Featuring real-time language translation, Bluetooth 5.4 connectivity, smart photochromic lenses, and intuitive touch controls, these glasses are designed to enhance your daily interactions and entertainment.



Image: Overview of PEJE M01Pro AI Smart Glasses highlighting key features such as music, waterproofing, long battery life, AI assistant, call function, voice recording, translation, and Bluetooth connectivity.

2. WHAT'S IN THE BOX

Please check the package contents upon unboxing:

- PEJE M01Pro AI Smart Glasses
- Charging Cable

- User Manual (this document)

3. SETUP

3.1 Charging the Glasses

Before first use, fully charge your PEJE M01Pro Smart Glasses. Use the provided magnetic charging cable. A full charge takes approximately 1.5 hours and provides up to 6 hours of continuous playback or talk time.



Image: The PEJE M01Pro Smart Glasses illustrating their durable battery and waterproof design, with icons showing 85x2mAh battery capacity, 200H standby, and 1.5H fast charging.

3.2 Power On/Off

- **To Power On:** Press and hold the power button (located on the temple) for approximately 3 seconds until you hear an audible prompt or see an indicator light.
- **To Power Off:** Press and hold the power button for approximately 3 seconds until you hear an audible prompt or see an indicator light.

3.3 Bluetooth Pairing

The glasses utilize Bluetooth 5.4 for efficient and stable connections.

1. Ensure the glasses are powered on and in pairing mode (indicated by a flashing LED light).
2. On your smartphone or device, navigate to Bluetooth settings.
3. Select "PEJE M01Pro" from the list of available devices.
4. Once connected, the LED indicator will stop flashing, and you will hear a confirmation sound.

3.4 App Installation

For full functionality, including volume adjustment and advanced translation features, download the dedicated PEJE Smart Glasses app from your device's app store. Follow the in-app instructions to connect your glasses.

4. OPERATING INSTRUCTIONS

4.1 Smart Touch Controls

The PEJE M01Pro Smart Glasses feature intuitive touch controls on the temples for easy operation.



Image: A woman wearing the PEJE M01Pro Smart Glasses, accompanied by a visual guide to the smart touch controls for various functions like power, calls, music, and voice assistant.

Action	Gesture
Power On/Off	Hold for 3 seconds
Answer/End Call	Double click
Reject Call	Hold for 2 seconds
Music Play/Pause	Single click
Music Switch (Next Track)	Double click
Activate Voice Assistant	Touch 3 times

4.2 Music Playback and Calls

The glasses feature two built-in speakers for a 360° enhanced stereo experience, delivering clear music and calls.



Image: A woman wearing the PEJE M01Pro Smart Glasses, demonstrating the Dolby Class 360° Surround Sound feature, with sound waves emanating from the temples.

- **Music:** Use the touch controls to play, pause, or switch tracks.
- **Calls:** Answer, end, or reject calls using the touch controls.
- **Volume:** Adjust volume levels conveniently via the connected smartphone app.

4.3 High-Accuracy Translation

Experience real-time, two-way translation across 45 languages, making communication seamless in various environments.



Image: A group of people in a meeting setting, illustrating the 45-language translation capabilities of the AI Smart Glasses, highlighting 99% accuracy and 0.3-second response time, with various country flags representing supported languages.

The translation function supports multiple modes:

- **Real-time Translation:** Hear two-way translations in real-time, similar to a native speaker.
- **Free Talk Mode:** Automatically captures conversations and synchronizes translations in 45 languages.
- **Voice Note Mode:** Records time, automatically recognizes language, and converts to text output for fast and accurate recording of meeting content.

The advertisement features three panels. The top-left panel shows a man in a grey blazer and glasses looking at his phone, with the text "video and audio call" above him. The top-right panel shows a man in a striped shirt and glasses smiling and talking to a woman, with the text "Voice Note Mode" and "Time recording, automatic language recognition and conversion to text output, fast and accurate recording of meeting content" below him. A blue banner across the middle reads "3 in 1 Real Time Translation". The bottom panel shows two men, one in a suit and glasses and the other in a light blue shirt, smiling and talking, with the text "Free talk mode" and "Automatically captures conversations and synchronizes translations in 45 languages in real time" below them.

Image: A collage demonstrating the 3-in-1 real-time translation features, including video and audio call translation, voice note mode for text conversion, and free talk mode for automatic conversation capture and translation.

4.4 Smart Photochromic Lenses

The lenses automatically adjust to complex lighting conditions, providing continuous protection. They effectively reduce glare from intense light while enhancing clarity and contrast, offering reliable eye protection during outdoor activities and travel.

5. MAINTENANCE

- **Cleaning:** Use a soft, clean microfiber cloth to wipe the lenses and frame. Avoid abrasive materials or harsh chemicals.
- **Water Resistance:** The glasses are IP67 waterproof, meaning they are protected against dust and can withstand immersion in water up to 1 meter for up to 30 minutes. Avoid prolonged submersion or exposure to high-pressure water jets.
- **Storage:** Store the glasses in their protective case when not in use to prevent scratches and damage.
- **Temperature:** Avoid exposing the glasses to extreme temperatures (hot or cold) for extended periods, as this can affect battery life and electronic components.

6. TROUBLESHOOTING

If you encounter issues with your PEJE M01Pro Smart Glasses, refer to the following common solutions:

Problem	Possible Solution
Glasses won't power on	Ensure the glasses are fully charged. Press and hold the power button for 3 seconds.
Cannot pair via Bluetooth	Ensure Bluetooth is enabled on your device and the glasses are in pairing mode. Try restarting both devices. Ensure no other devices are connected to the glasses.
No audio during music or calls	Check the volume level on your connected device and within the PEJE app. Ensure the glasses are properly connected via Bluetooth.
Translation not working	Ensure the glasses are connected to the app and have an active internet connection for translation services. Check app settings for language selection.
Touch controls unresponsive	Ensure the glasses are powered on. Try restarting the glasses. Clean the touch sensitive areas on the temples.

7. SPECIFICATIONS

Durable Battery & Waterproof Design



85x2MAH
Battery capacity

200H
Standby

1.5H
Fast charging

Image: Detailed product size diagram for the PEJE M01Pro AI Smart Glasses, showing lens width (50mm/1.97inch), glasses height (45mm/1.77inch), bridge width of nose (20mm/0.79inch), glasses width (147mm/5.78inch), and glasses length (139mm/5.47inch).

Feature	Detail
Model Number	M01Pro
Connectivity Technology	Bluetooth 5.4
Battery Capacity	85 mAh x 2 (Total 170 mAh)
Charging Time	Approx. 1.5 hours
Usage Time	Up to 6 hours (continuous playback/talk)
Standby Time	Up to 200 hours
Water Resistance	IP67
Item Weight	33 Grams (1.16 ounces)

Feature	Detail
Operating System Compatibility	Android, iOS
Special Features	Audio Recording, Music Player, Real-time Translation, Photochromic Lenses
Lens Width	50 mm / 1.97 inches
Glasses Height	45 mm / 1.77 inches
Bridge Width	20 mm / 0.79 inches
Glasses Width	147 mm / 5.78 inches
Glasses Length (Temple)	139 mm / 5.47 inches

8. WARRANTY AND SUPPORT

The PEJE M01Pro AI Smart Glasses come with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact PEJE customer service through the contact information provided on the official PEJE website or your purchase platform.