

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Garvee](#) /
- › [Garvee M9 Instant Voice Translator User Manual](#)

Garvee M9

Garvee M9 Instant Voice Translator User Manual

Model: M9

INTRODUCTION

Thank you for choosing the Garvee M9 Instant Voice Translator. This device is designed to facilitate seamless communication across language barriers, offering both voice and photo translation capabilities. This manual provides detailed instructions for setting up, operating, and maintaining your M9 translator to ensure optimal performance.

Package Contents

- 1 x Garvee M9 Voice Translator
- 1 x USB Cable
- 1 x User Manual (this document)
- 1 x Packaging Box

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Garvee M9 translator.



Figure 1: Garvee M9 Translator with labeled components. Key features include the On/Off button, Lock screen wake button, charging port, flash, HD speaker, HD microphone, volume buttons, return button, record button, and home button.

SETUP

1. Charging the Device

Before first use, fully charge your Garvee M9 translator. Connect the provided USB cable to the charging port on the device and plug the other end into a compatible USB power adapter (not included) or a computer's USB port.

- The charging port is located on the top edge of the device.
- A full charge typically takes approximately 2-3 hours.
- The battery indicator on the screen will show charging status.

2. Powering On/Off

- **To Power On:** Press and hold the On/Off button (located on the left side) until the screen lights up.
- **To Power Off:** Press and hold the On/Off button, then select "Power Off" on the screen.
- **To Wake/Sleep:** Briefly press the Lock screen wake button (also on the left side) to turn the screen on or off without powering down the device.

3. Initial Language Settings

Upon first startup, you will be prompted to select the system menu language. Follow the on-screen instructions.



Figure 2: System menu language selection on the Garvee M9. The device supports 17 system languages including English, Russian, Spanish, Japanese, Korean, Thai, Arabic, German, French, Italian, Portuguese, Vietnamese, Greek, Chinese, Malay, Myanmar, and Traditional Chinese.

4. Connecting to Wi-Fi

For online translation features, connect your device to a Wi-Fi network:

1. From the home screen, swipe down from the top to access the quick settings panel.
2. Tap the Wi-Fi icon to enable it.
3. Go to *Settings* > *Wi-Fi*, select your desired network, and enter the password if prompted.

OPERATING INSTRUCTIONS

1. Voice Translation (Online)

The Garvee M9 supports instant voice translation for 107 languages when connected to Wi-Fi.

1. From the home screen, tap the "Translation" icon (often represented by two speech bubbles).
2. Select the source language (your language) and the target language (the language you want to translate to) on the screen.
3. Press and hold the record button (the large circular button on the front) and speak clearly into the microphone. Release the button when you finish speaking.
4. The translated text will appear on the screen, and the device will speak the translation aloud.

2. Offline Voice Translation

The device supports offline translation for 12 major languages. Ensure the required offline language packs are downloaded in advance via Wi-Fi.

1. From the home screen, tap the "Offline Translation" icon.
2. Select your source and target languages from the available offline options.
3. Proceed with voice input as described for online translation.

3. Photo Translation

Translate text from images using the built-in camera.

1. From the home screen, tap the "Photo Translation" icon (often represented by a camera).
2. Point the camera at the text you wish to translate. Ensure the text is well-lit and clear within the frame.
3. Tap the capture button on the screen. The device will process the image and display the translated text.



Figure 3: The Garvee M9 translator displaying a photo translation. The device's camera captures text from a document, and the screen shows the original text alongside its translation into selected languages.

4. Language Learning and Practice

The Garvee M9 can assist with language learning through various modes.



Figure 4: The Garvee M9 translator displaying a language learning exercise. The screen shows a word or phrase in one language and prompts the user to speak or translate it, providing feedback on pronunciation or accuracy. Explore the "Learning" or "Practice" sections on the device to access features like vocabulary building, pronunciation practice, and interactive exercises. These features are designed to enhance your language skills.

MAINTENANCE

Cleaning the Device

To keep your Garvee M9 translator in optimal condition:

- Use a soft, dry, lint-free cloth to clean the screen and body.

- Avoid using abrasive cleaners, solvents, or aerosol sprays, as these can damage the device's finish.
- Do not expose the device to excessive moisture.

Software Updates

Garvee may release software updates to improve performance and add new features. It is recommended to keep your device's software up to date.

1. Connect your device to a stable Wi-Fi network.
2. Go to *Settings > About Device > System Update*.
3. Follow the on-screen instructions to check for and install any available updates.

TROUBLESHOOTING

Device Not Powering On

- Ensure the device is fully charged. Connect it to a power source and wait a few minutes before attempting to power on again.
- Try pressing and holding the On/Off button for at least 10-15 seconds to perform a forced restart.

Translation Inaccurate or Not Working

- **Online Translation:** Verify that the device is connected to a stable Wi-Fi network. Check your internet connection.
- **Offline Translation:** Ensure that the necessary offline language packs have been downloaded.
- Speak clearly and at a moderate pace, directly into the microphone.
- Confirm that the correct source and target languages are selected.

Photo Translation Issues

- Ensure the text is well-lit and in focus.
- Hold the device steady to avoid blurry images.
- The text should be clearly legible and not obscured.

Poor Audio Quality

- Ensure the speaker is not blocked.
- Adjust the volume using the volume buttons on the side.
- If using a Bluetooth headset, ensure it is properly paired and charged.

SPECIFICATIONS

Detailed technical specifications for the Garvee M9 Instant Voice Translator.

PRODUCT PARAMETERS

Motherboard Hardware	CPU Platform	MT6735
	Software system	Operating system Android .0
	RAM	RAM 1GB+ROM 8GB 8
	Audio	AW8736 , KA Class amplifier
	WIFI	2.4G/5G (802.11a/b/g/n)
	T	V2.1+EDR/V3.0+HS/V4.0 LE
	GPS	Not support
	USB	Tapy-c
	OTG	Not support
	Headphone holder	Bluetooth headset
Peripheral Hardware	LCD	3.0 "360* 640/IPS
	TP	G+F Single touch, 3D Shape
	Proactive	not support
	Back shot	500MAF Auto focus
	Flash	Stand by
	Horn	Diameter30BOX horn ,2.5W, Multimedia surround sound speakers
	Mike	Silicon wheat, double wheat noise reduction
	Battery	Polymer 15 00AMH
Structural Master	Main shell	Aluminum alloy CNC Processing
	Decorative shel	High strength PC Injection
	Side key	Power key aluminum alloy CNC
	Button	Aluminum alloyCNC

Figure 5: Garvee M9 Translator Product Parameters. This table provides a comprehensive overview of the device's hardware and software specifications.

Feature	Detail
CPU Platform	MT6735
Software System	Android
RAM	1GB
ROM	8GB
Audio Amplifier	AW8736, KA Class amplifier
Wi-Fi	2.4G/5G (802.11a/b/g/n)
Bluetooth	V2.1+EDR/V3.0+HS/V4.0 LE
GPS	Not supported
USB Port	Type-C

OTG	Not supported
Headphone Support	Bluetooth headset
LCD Screen	3.0" IPS Retina, 360*640 resolution
Touch Panel	G+F Single touch, 3D Shape
Front Camera	Not supported
Rear Camera	500MAF Auto focus
Flash	Supported
Speaker	Diameter 30BOX horn, 2.5W, Multimedia surround sound
Microphone	Silicon wheat, double wheat noise reduction
Battery	Polymer 1500mAh
Main Shell Material	Aluminum alloy CNC Processing
Decorative Shell Material	High strength PC Injection
Side Key Material	Aluminum alloy CNC
Button Material	Aluminum alloy CNC
Dimensions (L x W x H)	14 x 8 x 3 cm
Weight	217 grams
Color	Gold

For further assistance or support, please refer to the Garvee official website or contact customer service.

© 2026 Garvee. All rights reserved.