

[Manuals.plus](#) /

› [mcdodo](#) /

› mcdodo Speak A01 Series AI Translation Headset User Manual

mcdodo HP-8221

mcdodo Speak A01 Series AI Translation Headset User Manual

Model: HP-8221

INTRODUCTION

The mcdodo Speak A01 Series AI Translation Headset (Model HP-8221) is designed to facilitate multilingual communication through real-time AI translation and advanced noise cancellation. This headset is suitable for various applications, including business meetings, international travel, and daily use, providing clear audio and instant language translation.

This manual provides detailed instructions for setting up, operating, and maintaining your mcdodo Speak A01 headset. Please read it thoroughly before use to ensure optimal performance and longevity of your device.

Box CONTENTS

Verify that all items are present in the package:

- mcdodo Speak A01 Series AI Translation Headset (Earbuds and Charging Case)
- Eartips (various sizes)
- User Manual (this document)
- Charging Cable (USB-C)



Image: Contents of the mcdodo Speak A01 Series package, including the earbuds, charging case, and user manual.

SETUP

1. Charging the Headset

1. Place the earbuds into the charging case.
2. Connect the charging case to a power source using the provided USB-C cable.
3. The indicator light on the charging case will show charging status. A full charge typically takes approximately 1.5 hours.



Image: The mcdodo Speak A01 Series earbuds and their charging case.

2. Pairing with Your Device

1. Ensure the earbuds are charged and placed in the charging case.
2. Open the charging case lid. The earbuds will automatically enter pairing mode.
3. On your smartphone, tablet, or laptop, enable Bluetooth.
4. Search for available devices and select "mcdodo Speak A01" from the list.
5. Once connected, a confirmation sound will play, and the indicator light on the case may change.

3. Installing the Mobile Application

For full functionality, including AI translation and advanced settings, download the dedicated mcdodo Speak A01 mobile application from your device's app store (iOS App Store or Google Play Store). The app allows you to manage settings, update firmware, and utilize translation features.



Image: Screenshot of the mcdodo Speak A01 mobile application interface, displaying earbud connection status and available settings.

OPERATING INSTRUCTIONS

Wearing the Earbuds

Select the appropriate eartip size for a comfortable and secure fit. Insert the earbuds gently into your ears, ensuring a snug seal for optimal sound quality and noise cancellation.

Basic Controls (via Touch)

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Triple tap on either earbud.

- **Toggle Noise Cancellation/Transparency Mode:** Press and hold either earbud for 3 seconds.

AI Translation Function

The mcdodo Speak A01 supports real-time AI translation for up to 134 languages. This feature is primarily controlled through the dedicated mobile application.

1. **Open the App:** Launch the mcdodo Speak A01 application on your paired device.
2. **Select Translation Mode:** Navigate to the 'Translate' section within the app.
3. **Choose Languages:** Select the source and target languages for translation.
4. **Dual Ear Translation Mode:** For face-to-face conversations, one person wears one earbud, and the other person wears the second earbud. The app will facilitate real-time translation between the two languages spoken.
5. **Single User Translation:** For translating spoken language around you, wear both earbuds and use the app to capture and translate audio.



Image: Two individuals using the mcdodo Speak A01 Series earbuds, illustrating the dual ear translation mode for direct communication.

Hybrid ANC + ENC Noise Cancellation

The headset features Hybrid Active Noise Cancellation (ANC) and Environmental Noise Cancellation (ENC) to provide clear audio in noisy environments.

- **ANC:** Reduces ambient noise for an immersive listening experience.

- **ENC:** Enhances voice clarity during calls by filtering out background noise.
- **Toggle Mode:** Use the touch controls (press and hold for 3 seconds) or the mobile app to switch between ANC, Transparency Mode (to hear your surroundings), and normal mode.



Image: An mcdodo Speak A01 earbud depicted with sound wave patterns, symbolizing its noise cancellation capabilities.

MAINTENANCE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive materials or harsh chemicals.
- **Eartips:** Remove and clean the eartips periodically with water and mild soap. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Avoid Water:** The earbuds are not waterproof. Avoid exposure to excessive moisture or submersion in water.

TROUBLESHOOTING

Problem	Solution
Earbuds not pairing	• Ensure earbuds are charged. • Place earbuds in case, close lid, then open to re-enter pairing mode. • Turn Bluetooth off and on again on your device. • Forget/remove "mcdodo Speak A01" from your device's Bluetooth list and try pairing again.
No sound or low volume	• Check volume levels on both your device and the earbuds. • Ensure earbuds are properly seated in your ears. • Reconnect the earbuds to your device.
Translation not working	• Ensure the mobile app is open and connected to the earbuds. • Verify correct source and target languages are selected in the app. • Check your internet connection (required for AI translation). • Ensure microphone access is granted to the app.
Noise cancellation ineffective	• Ensure earbuds have a snug fit in your ears. • Toggle ANC mode using touch controls or the app. • Clean any debris from the earbud microphones.

SPECIFICATIONS

Feature	Detail
Brand	mcdodo
Model Number	HP-8221
Series	Speak A01
Product Type	AI Translator TWS Headset
Color	Black (Metallic Gray variant also available)
Ear Placement	In Ear
Noise Control	Hybrid Noise Cancellation (ANC + ENC)
AI Translation	Supports 134 languages (via mobile app)
Control Method	Touch controls, Mobile App
Connectivity	Wireless (Bluetooth)
Compatible Devices	Smartphone, Tablet, Laptop
Weight	80 Grams

Feature	Detail
Country of Origin	China

WARRANTY INFORMATION

The mcdodo Speak A01 Series AI Translation Headset comes with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

SUPPORT

For technical support, warranty claims, or further assistance, please contact mcdodo customer service or the authorized distributor.

Importer Contact Information:

Anmol Marketing, G-4 Ganesh Plaza near Sardar Park Chokadi, GIDC., Ankleshwar 393002, Gujarat

Email: anmolmarketing127@gmail.com

For the latest information and updates, visit the official mcdodo website or the product page on Amazon.

© 2026 mcdodo. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0GQ4XK2DD>

More documents and user manuals: <https://manuals.plus/>