





Chug PCEM001 Wireless Ergonomic Mouse User Manual

Home » Chug » Chug PCEM001 Wireless Ergonomic Mouse User Manual 🖫



Contents

- 1 Chug PCEM001 Wireless Ergonomic Mouse
- 2 Wireless Ergonomic Mouse
- **3 Product Requirements**
- 4 Charging the Mouse
- **5 Connecting via the Receiver**
- 6 Safety
- 7 Specification
- **8 FCC Statement**
- 9 FAQ
- 10 Documents / Resources
 - 10.1 References
- 11 Related Posts



Chug PCEM001 Wireless Ergonomic Mouse



Wireless Ergonomic Mouse

6 Button Rechargeable Mouse

- 1 x 6 Button Mouse
- 1 x USB-A 2. 4Ghz Receiver
- 1 x USB-A to USB-C Charging Cable
- 1 x Instruction Manual



*product design may vary

Product Requirements

PC with a USB-A port

Charging the Mouse

• A full charge requires approximately 3 hours.

Plug the USB-C end of the charging cable into the mouse and plug the opposite end into your computer.

• The LED indicator will turn solid red while the mouse is charging, when charging is complete the LED indicator

will turn off.

Note: You can use the mouse while it is charging.

Connecting via the Receiver

• Take the receiver out from the back of the mouse and plug it into your computer.

• Switch the power button up to 2. 4Ghz; the indicator light will flash red.

• The mouse and receiver will automatically pair. The indicator light will turn solid red when the pairing is

successful.

Connecting via Wireless Pairing:

Switch the power button down to wireless pairing, the indicator light will flash blue.

• Use your device to pair with "PCEM-002". The indicator will turn solid blue then fade when pairing was

successful.

Adjusting DPI:

• Press the DPI button to adjust the mouse sensitivity. DPI 800 > 1200 > 1600 Troubleshooting:

• If the mouse is not connecting, make sure the receiver is properly plugged into the computer or make sure

wireless pairing is enabled on your device and pairing it has successfully paired.

• If the mouse is not responding, check if your battery is low. If it is recharge the mouse.

• If the connection keeps dropping ,move closer to the device or reduce interference from other wireless devices.

• Having trouble with your device? Be sure you're running the latest software on your devices. You can do this by

doing a 'software update' in the settings of your device.

Safety

Do not use near any water source

· Do not modify or repair this device

• Do not use chemical detergents to clean your device, use a soft dry cloth

Specification

• Mouse Model: PCEM002

FCC ID: 2AO23-PCEM001

Mouse Input: 5V =300mA

Receiver Model:YTW1

• FCC ID: 2AO23-YTW1

• Working distance: B-10m

Made in China

FCC Statement

This device compiles with part 15 of the FCC Rules. Operation Is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may Colusa harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user Is encouraged to try to correct the Interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

gemsfindyours.com 7157 Shady Oak RD, Eden Prairie, MN 55344 Distributed by Chug, Inc.

For qualified repair specialists requesting repair information and parts please contact the original manufacturer at customersupport@gemsfindyours.com

FAQ

How do I charge the mouse?

Plug the USB-C end of the charging cable into the mouse and the other end into your computer. The LED indicator will show red while charging.

What should I do if the mouse is not connecting?

Ensure the receiver is properly plugged into the computer or check if wireless pairing is enabled on your device.

· Can I use the mouse while it's charging?

Yes, the mouse can be used while it is charging.

Documents / Resources



Chug PCEM001 Wireless Ergonomic Mouse [pdf] User Manual

2AO23-PCEM001, 2AO23PCEM001, PCEM001 Wireless Ergonomic Mouse, PCEM001, Wireless Ergonomic Mouse, Ergonomic Mouse, Mouse

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.