

## **GOOSENECK 8091350 Tech Holder Instruction Manual**

Home » GOOSENECK » GOOSENECK 8091350 Tech Holder Instruction Manual

#### Contents

- 1 GOOSENECK 8091350 Tech Holder
- 2 INSTRUCTIONS
- 3 Documents / Resources
- **4 Related Posts**

# **GOOSENECK**

### **GOOSENECK 8091350 Tech Holder**



1. Unscrew the plastic screw from the holder and put the neck through it. Fits devices 4.7in. to 9.7in.



2. Use the screw to attach the holder to the neck. Tighten to secure.



- 3. Unscrew the plastic base (A).
- 4. Adjust the clamp size (B) to suit the thickness of your desk or shelf. Place the clamp over the desk and rotate the clamp again in the reverse direction to secure on the desk. (max. 70mm)
- 5. Adjust the mount (C) to securely hold your device and adjust the neck to the desired position.



**NOTE:** Mount is suitable for viewing or reading only. Tapping and touching your device frequently will make the holder shake.

**TIP:** When holding a heavy tablet, loop the gooseneck into a "S" shape or circle shape to provide more stability. Bend using two hands and bend just the gooseneck when adjusting the position because it is stiff. Pulling the device too quickly when adjusting may break the nut. DO NOT overtighten the base clamp to avoid breaking.

### THE SOURCE - WARRANTY

The Source warrants that this product will be free from defects in materials and workmanship for a period of six (6) months from the date of purchase. Within this period, simply take the product and your proof of purchase to any The Source store or participating dealer and the product will be replaced (where available) without charge. Any product which has been subject to misuse or accidental damage is excluded from this warranty. This warranty is only applicable to a product purchased through The Source company-owned stores or participating dealers in Canada where the warranty is included with the product. While this warranty does not confer any legal rights other than those set out above, you may have additional statutory rights which will vary under the laws of the various countries, states, provinces and other governmental entities in which The Source operates. This warranty is subject to all statutory rights you may have in Canada.

**Imported by:** The Source, Barrie, Ontario, Canada, L4M 4W5 Manufactured in China www.thesource.ca

**Documents / Resources** 



Manuals+,