

# JBM 53724 Endoscope With Wifi Connection Instruction Manual

Home » JBM » JBM 53724 Endoscope With Wifi Connection Instruction Manual ™

JBM 53724 Endoscope With Wifi Connection
Instruction Manual





#### **Contents**

- 1 PRODUCT PRESENTATION
- **2 SAFETY INSTRUCTIONS**
- **3 TECHNICAL SPECIFICATIONS**
- **4 INSTALLATION AND USE ON**

#### **SMARTPHONE**

- **5 LIST OF PARTS**
- 6 Documents / Resources
  - **6.1 References**

# **PRODUCT PRESENTATION**

Endoscope with wifi connection compatible with all smartphones on the market. Suitable for connection to tablets and PCs.

# **SAFETY INSTRUCTIONS**

Please read these instructions carefully before using the product. instructions carefully before using the product. Failure to follow these instructions correctly instructions may result in personal injury personal injury and/or damage to the product. Keep these instructions for future reference.

#### **TECHNICAL SPECIFICATIONS**

- Resolution: HD640\*480, 1280\*720

Viewing angle: 70Diameter: 8mm2 mega pixel

Focal length: 4-6cm6 adjustable white LEDs

- IP67 waterproof

- 800mAh lithium battery

- 1m cable

# **INSTALLATION AND USE ON SMARTPHONE**

- 1. Check the WiFi network that the endoscope broadcasts. It can be "TC WiFi" or "WiFi Look".
- 2. In case the WiFi network that emits is TC WiFi. Download and install the Wifi Check application or the TC Wifi application, through the App Store on IOS devices or from Google Play on Android devices.
- 3. In the case that the WiFi network that emits is WiFi Look. Download and install the Wifi Look application through the App Store on IOS devices or from Google Play on Android devices.
- 4. Turn on the Wifi connection port and connect the camera to the corresponding input.
- 5. Search for and connect the wifi signal emitted by your endoscope to your device (no password required).
- 6. Start the app with the camera connected and make sure that camera access for this device is enabled.
- \* The endoscope is not compatible with the JBM app.

### **LIST OF PARTS**

The equipment includes:

- Wifi connection port
- Charger



Endoscope



· Hook tip



Magnetic tip



· Mirror tip for side view

- 1. WIFI NETWORK: TC WIFI
- · APP WIFI CHECK





https://manuals.plus/wpcontent/uploads/2024/09/JBM-53724-Endoscope-With-Wifi-Connection-Instruction-Manual-App-Store-Logo.jpg





https://manuals.plus/wpcontent/uploads/2024/09/JBM53724-EndoscopeWith-WifiConnectionInstruction-ManualApp-Store-Logo.jpg



https://play.google.com/store/apps/details? id=com.joyhonest.wifi\_check&hl=es&gl=US

# · APP TC WIFI





https://apps.apple.com/us/app/tcwifi/id1473358442



https://play.google.com/store/apps/details? id=com.joyhonest.wifi\_check\_tc&hl=es\_419&gl=US



https://apps.apple.com/us/app/tcwifi/id1473358442



https://play.google.com/store/apps/details? id=com.joyhonest.wifi\_check\_tc&hl=es\_419&gl=US

2. WIFI NETWORK: WIFI LOOK

· APP WIFI LOOK





https://apps.apple.com/us/app/wifilook/id1275018170



https://play.google.com/store/apps/details? id=com.molink.john.wifiviewer&hl=es&gl=US



https://apps.apple.com/us/app/wifilook/id1275018170



https://play.google.com/store/apps/details? id=com.molink.john.wifiviewer&hl=es&gl=US

54724



#### www.jbmcamp.com

JBM CAMPLLONG, S.L.U. CIM La Selva – Ctra. Aeropuerto km. 1,6 Nave 2.2 – CP 17185 Vilobí d'Onyar – GIRONA

jbm@jbmcamp.com

Tel. +34 972 405 721 Fax. +34 972 245 437

# **Documents / Resources**

	JBM 53724 Endoscope With Wifi Connection [pdf] Instruction Manual 53724 Endoscope With Wifi Connection, 53724, Endoscope With Wifi Connection, Wifi Connection, Connection
--	--

#### References

- Welcome to nginx!
- User Manual

# Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.