



Home » Jura » JURA MDB Connect Interface System Instruction Manual 📆

#### Contents [ hide ]

- 1 JURA MDB Connect Interface System
- **2 PRODUCT INFORMATION**
- 3 Overview of MDB Connect
- 4 Installation
- 5 LED indicators
- **6 WARRANTY**
- 7 FCC
- **8 CONTACT INFORMATION**
- 9 FAQs
- 10 Documents / Resources
  - 10.1 References



**JURA MDB Connect Interface System** 



#### PRODUCT INFORMATION

## Proper use

MDB Connect may only be used with the specified JURA interfaces. It provides wireless communication between the coffee machine and various accessories (for compatible machines, see <a href="jura.com">jura.com</a>). Use for any other purpose will be deemed improper. JURA cannot accept any responsibility for the consequences of improper use.

**Wireless connection (Bluetooth LE / Wi-Fi)**: Frequency band 2.4 GHz | Max. transmission power < 100 mW

## **Overview of MDB Connect**



1. **LED**: Indicates the status of MDB Connect

2. **Connector**: For inserting into the service socket of the coffee machine / MDB interface / Cool Control

## Installation

MDB Connect must be inserted in the service socket of the automatic coffee machine (which is switched off). This is usually on the top or at the rear of the machine, beneath a removable cover. If you don't know where the service socket of your coffee machine is, ask your dealer or go to jura.com.

- Plug MDB Connect into the coffee machine's service socket.
- The "Collection" programme item appears in the coffee machine's settings.

Find out more at <u>jura.com/payment</u>.

## **Connecting to JURA Cool Control**

MDB Connect can be used to connect the coffee machine to Cool Control. This requires Cool Control to also be equipped with MDB Connect. If a machine is switched off and then on again, the connection is re-established automatically.

### Resetting MDB Connect to factory settings in Cool Control

MDB Connect can be reset to factory settings should any general problems occur (such as connection problems): To do this, press and hold the Cool Control On/Off button  $\circ$ .

## **LED** indicators

LED action	Coffee machine	Cool Control	MDB interface syste m 2.0
LED does not light up	Coffee machine is sw itched off; no power supply	Cool Control is switch ed off; no power supp ly	MDB interface syste m is switched off; no power supply

LED lights up	_	Connection established with the coffee machi ne
LED flashes (once per sec ond)	Connection establish ed with the accessory	The coffee machine is switched off, connection to coffee machine not possible
LED flashes (twice per se cond)	Attempting to establi sh a connection	Cool Control/MDB interface system is not con figured with the coffee machine.

#### WARRANTY

#### **JURA Products Ltd warranty conditions**

For this machine, JURA Products Ltd, Vivary Way, Colne, Lancashire, offers to the end customer, in addition to the rights of guarantee from the retailer, an optional manufacturer's warranty with the following terms and conditions for

## 12 months from the date of purchase

- During the warranty period, defects will be remedied by JURA. JURA shall decide
  whether to remedy the defect by repairing the machine, replacing defective parts or
  replacing the machine. The performance of warranty services shall not cause the
  warranty period to be extended or restarted. Replaced parts become the property of
  JURA.
- 2. A warranty service is not applicable for damage or defects caused by incorrect connection, incorrect handling or transport, repair attempts or modifications by unauthorised persons or non-compliance with the instructions for use. In particular, the warranty shall be void if JURA's operating or maintenance instructions are not followed or if maintenance products other than JURA water filters, JURA cleaning tablets or JURA descaling tablets are used that do not correspond to the original specifications. Wearing parts (e.g. seals, grinding discs, valves) are excluded from the

warranty, as is damage caused by foreign bodies entering the grinder (e.g. stones, wood, paper clips).

- 3. The sales receipt, specifying the purchase date and machine type, must be provided as evidence for warranty claims. In order to simplify the process, the sales receipt should also include the following information where possible: name and address of the customer and serial number of the machine.
- 4. Warranty services are performed in the United Kingdom. For machines purchased in one EU country and taken to another EU country, services will be performed in accordance with the JURA warranty conditions applicable in this country. An obligation to provide warranty services only exists if the machine satisfies the technical specifications applicable in the country in which the warranty claim is made.
- 5. In the United Kingdom, warranty services are performed by authorised JURA service centres for commercial models.

#### **FCC**

This device complies with Industry Canada licence-exempt RSS standard(s) and part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- 2. This device must accept any interference,

including interference that may cause undesired operation of the device. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### **CONTACT INFORMATION**

JURA Products Ltd.

• Service hotline: 0844 257 92 29 (charged at local rates)

• E-Mail: service@uk.jura.com

• Availability: Monday to Friday 8.30 a.m. – 5.00 p.m.

• Service centre address: JURA Products Ltd.

Vivary Mill

- Vivary Way
- Colne, Lancashire BB8 9NW
- Distributor address: JURA Products Ltd.
  - Vivary Mill
  - Vivary Way
  - Colne, Lancashire BB8 9NW

#### **Contact**

- JURA Elektroapparate AG Kaffeeweltstrasse 10
- 4626 Niederbuchsiten, Switzerland
- Tel. +41 (0)62 389 82 33
- You can find additional contact details for your country at jura.com.
- Declaration of conformity: <u>jura.com/conformity</u>

#### **FAQs**

- Q: What is the warranty period for the MDB Connect?
  - A: The warranty period for the MDB Connect is typically 12 months from the date of purchase.
- Q: How do I know if my MDB Connect is properly connected?
  - A: The LED indicator on the MDB Connect will blink at different rates to indicate its connection status. Refer to the user manual for specific LED indications.
- Q: Can I transfer the warranty if I move to a different country within the EU?
  - A: Warranty conditions may vary based on the country you move to within the EU.
     Contact JURA customer service for detailed information on transferring
     warranties between EU countries.

## **Documents / Resources**



JURA MDB Connect Interface System [pdf] Instruction Manual

MDB Connect Interface System, MDB Connect, Interface System, Syste

m

#### References

## • User Manual

- Interface System, Jura, MDB Connect, MDB Connect Interface System,
- Jura System

# Leave a comment

Your email address will not be published. Required fields are marked\*

Comment *		
Name		
Email		
Website		
☐ Save my name, email, and website in this browser for the next time I com	nment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of

these marks on this website does not imply any affiliation with or endorsement.						