

# LogTag® VFC400-WI

## Quickstart Guide

Version A

[www.vfcdataloggers.com](http://www.vfcdataloggers.com)

# Quickstart Guide Contents

---

What's Included	3
Downloading the Connection Wizard	4
Running the Connection Wizard	5
Connecting to your WiFi Network	6
LogTag Online	9
Registering a new device	10
Creating a Location	11
Physical Installation	12
Uploading Results to LogTag Online	13
Viewing Results	14

# What's Included

---

Please check you have each of the items shown below before continuing with setting up your VFC400-WI.



VFC400-WI



USB Cable



x1 Adhesive strip



AC Adaptor

**Note:** The VFC400-WI is only compatible with some loggers. Please refer to the VFC website for the latest compatibility models.

# Downloading the Connection Wizard

---

Connect your VFC400-WI to your computer via the USB cable provided. The USB socket on the device is located at the bottom of the interface cradle.



---

Your VFC400-WI requires you to connect it to your WiFi Network. To do that, we have an easy tool for you to use called the LogTag Online Connection Wizard.

To download the LogTag Online Connection Wizard, please open your browser and type the link below to begin the download:

 <https://www.vfcdataloggers.com/content/Software/connectionwizard.exe>

**Warning:** Please ensure no other LogTag software is currently running on your computer before running the Wizard software.

# Running the Connection Wizard

---

Please ensure there is internet connection on your computer prior to starting this process.

This software doesn't require any setup or installation. Simply double-click the connectionwizard.exe file that you downloaded. The first page of the Wizard will be displayed.

When you're ready to begin, click **"Start"**.



**Easy Setup** will be selected by default. Keep this option checked and click **"Next"**.

You will be asked to sign in to your LogTag Online account. If you do not have an account, click the link below or alternatively, open your browser, type the following link into the address bar and follow the on-screen instructions.

**<https://logtagonline.com/signup>**

or click **Create a LogTag Online Account** link.

You have now created your account and is now ready to set up connection of your VFC400-WI to the WiFi network.

# Connecting to your WiFi Network

---

Type your LogTag Online account details and click “**Sign In**”, followed by “**Next**”.




The Wizard will now scan for any connected LogTag devices.

If the scan doesn't find any devices, double-check the device is plugged in to your computer with the USB cable provided and click “Scan Again”.



As soon as a device has been identified, it will appear in the table (left) and automatically register that device to your LogTag Online account.



The Status will turn green with the text “Registered” once complete.

Click the “**Next**” button once you are ready.



1. Click the Network Name arrow to see nearby Wireless Networks options.

**Note:** This process can take up to 2 minutes, please wait whilst the network scan is in progress.


2. Once you have selected your WiFi Network from the list, type the password for the network. **Remember that passwords are case-sensitive.**
3. (Optional) Once you have typed your password, you can click the eye icon to reveal the password. Incorrectly typed passwords is one of the most frequent reasons why device setup fails.
4. Once you have selected your WiFi Network and typed the password, click **"Next"**.

**Note:** Some WiFi Networks won't appear in this list for security purposes. If you are aware that your network is one of these, you can manually type the name of your network (SSID) in the Network Name field instead of clicking the menu arrow.



The device is now being configured with the WiFi details you provided in the previous screen, which typically takes 10 seconds.

The Connection Wizard is now checking that the VFC400-WI can connect to your WiFi network and to LogTag Online.



1. Once the Wizard displays “Connection Succeeded”, click **Next** to complete the Wizard.
2. Click **Close** to close the Wizard or click the ‘LogTag Online Sign In page’ link to take you to LogTag Online website.

**Note:** The blue network LED flashes on VFC400-WI once connection is successful. If the red network LED is flashing, please refer to the product user guide for troubleshooting.



# LogTag Online

---


LogTag Online is a secure online service that stores the data recorded from your logger against your account.

## Signed in to your LogTag Online Account

Open your browser and navigate to: <https://logtagonline.com>

The screenshot shows the LogTag Online login interface. At the top, there's a navigation bar with links for 'Home', 'About Us', 'Products', 'Support', 'Contact Us', and 'Log In'. Below this, the 'Log In' section is highlighted. It contains two input fields: 'EMAIL' and 'PASSWORD'. Below these fields is a green 'Log In' button. There are also links for 'Forgot Password' and 'Create an Account'. The footer of the page includes the text 'LogTag Online' and '© 2018 LogTag Online'.

1. Type your Email and Password
2. Then click "Sign In".
3. Upon signing in, you will see the Dashboard.

The screenshot shows the LogTag Online Dashboard. The top navigation bar includes links for 'Home', 'About Us', 'Products', 'Support', 'Contact Us', and 'Log In'. The main content area is divided into two sections. The left section, titled 'My Recent Log', contains a table with columns for 'Log ID', 'Log Name', 'Log Date', and 'Log Status'. The right section, titled 'My Recent Log', contains a table with columns for 'Log ID', 'Log Name', 'Log Date', and 'Log Status'. The bottom section, titled 'My Recent Log', contains a table with columns for 'Log ID', 'Log Name', 'Log Date', and 'Log Status'.

# Registering a new device

After you have docked a logger into your VFC400-WI it will automatically register the logger with LogTag Online and show it in the [Recently Registered Devices](#) section on the dashboard.

Recently Registered Devices <a href="#">(View all)</a>				<a href="#">Register Device</a>
Model	Device Name	Serial Number	Last Connection	
TRK200-NA		201606002968	2017-06-26 20:19	

---

END OF PAGE



# Physical Installation

---

Setup of your VFC400-WI is complete, to install the VFC400-WI:

1. Un-clip the interface from the mount base.
2. Mount base with adhesive strip or screws on a flat surface at your preferred site.
3. Clip back the interface onto the mount base
4. Plug in USB power cable



**Note:** Ensure the mounting surface is clean and dry before installing.



Make sure the USB cable from the VFC400-WI can reach the USB wall charger comfortably without obstruction.

# Uploading Results to LogTag Online

Please ensure your logger has started prior to docking it into the interface.



The Green 'Ready' LED is permanently on to indicate it is ready to accept a logger.

To upload your logger's data to LogTag Online, simply dock it into the VFC400-WI.

The red 'Busy/Error' LED is permanently on while the data is being downloaded from the logger.



The blue 'Network' LED rapidly flashes to indicate it is in the process of uploading data to LogTag Online cloud.



When the upload of data from the logger is complete, Amber and blue lights flash at the same time to indicate real-time temperature upload is active.




# Viewing Results

To view your data, sign in to your LogTag Online account.

For any pinned location you can see a snapshot of the data collected. To view the data in more detail, click on the miniature chart or click “Inspect”.

For any locations that are not pinned to the dashboard, click “Locations” and select the location you wish to see in more detail.



If the logger is not attached to a location, browse to LogTag Drive at the bottom of the dashboard to view data online along with options to share, edit and delete the data on your account.

