

Smart Handles

Product Manual

Safety Precautions

- It is recommended to use an adapter with an output of 5V/2A when charging the handles.
- Before charging, be sure to check if there are lint, water, or other foreign objects near the socket. Clean the area thoroughly before inserting, as failure to do so may lead to fire, electric shock or a short circuit.
- During charging, please avoid placing the device in high-temperature or direct sunlight areas. After charging is complete, promptly remove the charger to prevent overcharging and potential accidents.
- 4. Do not charge the product for an extended period without supervision. The maximum charging time should not exceed 12 hours. If left unused for a long time, please charge it to full capacity at least once every six months.
- 5. Please charge the product under the environment between 5°C and 35°C. Store this product within the range of -20°C to +45°C.
- 6. If any abnormal things occurred during charging or usage (such as unusual odors or sounds), immediately cut off the power and stop usage.
- Please do not rub the button violently, if there is any malfunctions of the smart handles
 or the adjustment system, please stop using it and contact Speediance Aftersales
 immediately
- 8. Any attrimpt to dissemble or modify the product or damage the electronic components, such as the circuit boards, is strictly prohibited. All repairing & maintenance operations must be conducted by experts. If the power cord is damaged, it must be replaced through official channels to prevent any potential hazards.












Away from No Rinsing with Water Away from Open Flame

No Faulty Powe





Basic

Product Name	Smart Handles
Product Dimensions	14.5*3.2*5cm
Bluetooth Parameter	Bluetooth 5.0
Battery Parameter	3.7V 480mAh



Condition of Device	Indicator's Light	
Normal Battery	White Light	
Low Battery	Red Light	
Disconnected	Flashing Light	
Charging	Orange Light when not being fully charged, White Light when being fully charged	





Awake Your Handles

Single click on the side button to awake the handles





Bluetooth Connection/ Disconnection

When the indicator flashes, you can search it on a Speediance machine or via the companion App.

The indicator flashes when the Bluetooth is disconnected.



How to Use

Single-click or double-click (modifiable via software) to control the weight switch

(Z




Sleeping Mode

Automatically disconnect Bluetooth after 120 seconds of null response.

How to Charge

Red flashing light indicates immediate charging! Charge it with the Type-C cable which is included in the package.



Warranty card

Name				
Address			One-year	
Tel				Warranty
Purchase Date				
When you purchase the product, please fill in the warranty card immediately, stick the invoice on the back of the warranty card and keep them properly. Please show the warranty card and keep them properly. Please show the maintenance card and the purchase provice for maintenance. 1. Under the condition that user operates the product normally in strict accordance with the instructions berin, Speediace provides free maintenance service within one-year warranty period, which starts from the date that the 2. If the products out of warranty berind as described above, and needs a				
replacement of the ac 3. The warranty does a. product with no p b. product out of wa c. product disassem d. d.damage caused e. e.product damage (such as prolonged us f. products that natu	cessories, a rational maintenance fee will be charged. Inoft ower urchase or warranty certificate (warranty card) available rating period rating rati	Signature of Distributor		
For details on the war on the Speediance of	ranty policy, please refer to the after-sales warranty policy ficial website.			