

INSTALLATION INSTRUCTIONS

1. If this is the first time using the RadioPRO PC Application, download the Radio PRO PC Application. This can be found at the "Download" tab at the very bottom of the firmware list on this page.
2. Download the firmware file.
3. Install the Radio PRO PC Application using the .exe file you downloaded in step one.
4. Open the RadioPRO PC Application using the new shortcut created on your desktop.
5. Set all four DIP Switches to ON (DOWN) position.
6. Connect the interface to the computer using a standard to micro USB cable.
7. Click the "Firmware" icon.
8. Click "Select File" and browse to the new firmware file. The new firmware can be found where you saved it before beginning.
9. Once the file is chosen the update will begin. When successful it will show the text "Update Completed".