

FILTERPLUS**

Codes:

FH0618-K

Kit Includes:

1x 6x18 Manual Softner Kit



English

INSTR-FH0618-K



Thank you for purchasing a STREAMLINE® Water Filtration System

The **STREAMLINE*** FH0618K water softening filter is a simple way to soften water prior to small and medium sized reverse osmosis water filtration systems and other applications. The resin medium can be easily and quickly regenerated, many times over, using softening salt.

Your system has been assembled and tested to ensure there are no leaks by our team at **STREAMLINE***. Your system is ready to go!

Please ensure that you connect your mains water hose to the inlet connection and have connected a hose from the outlet connection to the filter as explained in the Instructions for Use.

When cleaning windows, remember to pay special attention to the frames, especially if it is the first time this method of window cleaning is being used. The most important part of the cleaning process is the rinsing, after the window has been cleaned. To do this, lift the brush away from the glass and move the head from side to side working from top to bottom, allowing the water to create a sheet, therefore rinsing the glass. Extra care must be taken if the water refuses to 'sheet', as this makes rinsing successfully more difficult. If you are cleaning windows on a warm day, the rinsing procedure must be done meticulously, as warm, direct sunlight can cause spotting, due to insufficient rinsing.

Instructions for use

Set Up

- Connect a hose from the water supply to the inlet connection of the FH0618K water softening filter.
- Connect a hose from the outlet of the filter to the inlet connection of the RO filtration system.
- The FH0618K water softening filter will treat approximately 2200 litres of water at a hardness of 100ppm. (1100l at 200ppm etc.)

•••••

Servicing

- When the resin becomes spent, turn off the water supply and remove both hoses from the FH0618K water softening filter.
- Connect the short hose from the attached 10" cartridge housing to the inlet connection of the water softening filter.
- Connect a hose from the mains water supply to the inlet connection of the 10" cartridge housing.
- Connect a hose from the water softening filter and direct it to the nearest drain.
- Unscrew the 10" cartridge housing and fill the empty cartridge with course softening salt.
- Insert the salt cartridge into the 10" housing and secure the housing filter bowl.
- Turn the water supply on slightly and allow the water to slowly flush the salt through the softening filter and down the drain.

- Once the salt has dissolved, turn the water supply off, refill the salt cartridge, and flush the softening filter a second time
- After a few minutes test the waste water with a TDS meter to check for the presence of salt.
- If the salt concentration is still high, the TDS meter will display ERR for error, or it may display a ppm figure (x10).
- Continue to flush the softening filter with water until an approximate tap water TDS ppm is achieved. The so ftening filer resin has now completed regeneration.
- Remove the hoses and connect them as explained in 'set up' .

3



STREAMLINE® Warranty

The warranty on all Machines and Equipment is for 1 year (12-months) from RECORDED DATE OF PURCHASE.

THIS WARRANTY EXCLUDES NORMAL MAINTENANCE ITEMS, including but not limited to HOSES, FILTERS, O-RINGS, DIAPHRAGMS, VALVES, GASKETS. CARBON BRUSHES and damage to motors and other components as a result of failure to replace normal maintenance items. THIS LIST IS NOT EXHAUSTIVE.

If **STREAMLINE**® receives notice of such defects during the warranty period, STREAMLINE® will either, at its opinion, repair or replace components which prove to be defective.

Replacement parts will only be supplied under warranty, upon the inspection and approval of the defective parts by **STREAMLINE***.

Should it be necessary to supply replacement parts before the opportunity to inspect, these will be charged at current prices and credit will only be issued upon subsequent inspection and warranty approval by STREAMLINE®.

The customer is responsible for the cost of return of the defective part. If warranty is approved, **STREAMLINE*** will pay for the cost of the repaired or replacement part.

This warranty excludes the following conditions and circumstances which are at the discretion of STREAMLINE®:

Wear and tear, misuse, abuse improper maintenance, frost damage, the use of chemicals other than those supplied or approved by **STREAMLINE***, improper installation or repair, unauthorised modification, incidental or consequential costs, loss or damage, service. labour or third party charges, the cost of returning defective parts to STREAMLINE®.

This warranty constitutes the exclusive remedy of any purchaser of a **STREAMLINE**® unit and is in lieu of all other warranties, express or implied, including without limitation any implied warranty of merchantability or fitness for use, to the fullest extent permitted by law. In no event shall any implied warranty of merchantability or fitness for use exceed the term of the applicable warranty stated above and **STREAMLINE**® shall have no other obligation or liability.

Important

Unfortunately these rights cannot be transferred to a third party.









Why STREAMLINE®?

Flexibility

- STREAMLINE® systems can be built according to customers' exact requirements
- For non-standard systems, the user's needs or specifications are listened to and turned into reality.

Quality

- Whilst price is important, quality is remembered long after price is forgotten
- We insist on sourcing brand name products from around the world, only of a reputable quality, and bring them together under the **STREAMLINE®** name
- All STREAMLINE® products carry a full one year's warranty, according to the manufacturers' standard terms and conditions of sale.

Service

- We have an in-house technical helpline able to answer most of your guestions relating to the capabilities and functionalities of all **STREAMLINE®** products
- · If we get it wrong, we will put it right. If you are sent a wrong item, we will immediately attend to sending you the correct item and arrange a collection of the wrong item without any quibbles
- STREAMLINE* is backed by a comprehensive range with massive stocks providing you with a 'one stop shop' for all your requirements.





CHECKED AND **TESTED BY QUALITY CONTROL**

5

INSTR-FH0618-K



Hamilton House, 8 Fairfax Road, Heathfield Industrial Estate, Newton Abbot Devon, TQ12 6UD United Kingdom

Telephone: +44 (0) 1626 830 830 Email: sales@streamline.systems Visit: www.streamline.systems

INSTR-FH0618-K