155.00 mm



K01 Open-Frame Directional Audio Smart Glasses


Statement

- First of all, thank you for using our products! Please read this manual before
 use and use this product correctly.
 For better service, the content of this user manual may change. Changes due
 to product performance and functions will not be notified separately.

Product Model

K01 Open Directional Audio Smart Glasses, this product is a Bluetooth glasses with stereo function, simple to operate and easy to carry


Product button instructions



Operation Instructions

Charging

The power cord is magnetically charged, and the glasses are turned off during charging




A Do not make contact in the reverse direction it may cause a short circuit

Low battery voice prompt

Power on/off

The right temple is powered on separately, press and hold for 2 seconds to power on: Press and hold for 2 seconds to power off.



Connect/pair

The left and right earphones will pair automatically after powering on Open the Bluetooth list in the phone settings and search for the KOI Bluetooth name to pair



Restore factory settings/ clear pairing records

Press and hold for 8 seconds in the off state to clear the pairing record with the mobile phone




Play music

Single click to start playing
 Double-click to enter low latency mode
(There is no volume adjustment button on the glasses, so you need to adjust the volume on the phone)


Make a call

Turn on Bluetooth

• Single click to hang up the call




Voice Assistant



Touch button

- Turn on the single color cycle of the marquee Short touch: switch light bar color (RGB color; green, red, blue, yellow, cyan, purple)





Product parameters

roduct parameters					
Frame color	Matte black	Bluetooth protocol	BLE 5.4	Frame material	PC
Battery capacity	110mAh	Lens material	TAC	Charging voltage	5V
Product weight	44.8g	Charging time	90min	Charging current	80mA
Waterproof	IPX4	Operating	0-45°C	Playtime	About

St.E. 5.0 competible with mainstream brand ameriphones and other Bluetooth devices. Product unfailured physical bottons. Dual left and right speakers for directional playback. Continuous physicas for 5 hours at 100% volume, and 8 hours at 60% volume. The product does not support washing.

■ Packing List

- Please read the instructions carefully before using this product and keep them
 Please fully charge this product before using it for the first time
 If the product is not charged for a long time (more than 2 weeks), please charge it
- before use 4. Do not wipe the dirty lenses directly, wet the lenses first, and then wipe them dry with
- a glasses cloth

 5. Try to use a velvety and highly absorbent glasses cloth to gently wipe them clean, and
 be careful not to use too much force

 6. Wipe the feeses in one direction, do not wipe back and forth, and do not wipe them in
 circles on the lenses

 7. When the battery temperature exceeds "10"C-50"C, the product will stop working

Do not dismantle or repair this product for any reason, otherwise it may cause fire, electronic breakdown or even complete damage to the product

- 2. Do not place the device in an environment with too low or too high temperature libelow

- 6°C or above 45°C)

 3. Do not wet the product with liquid or soak it in liquid

 4. Do not expose the glasses to the sun for a long time, otherwise they are prone to determine, aging and breaking

 5. Do not place the magnetic end of the charging cable close to metal objects to prevent the risk of short circuit caused by magnetic attraction of metal objects

 6. Do not use any solvents, chemicals or detergents containing alcohol, ammonia or otherwise.

Important safety information

1. Before using this product, please read all safety information to ensure correct and safe

use

2. Using power supplies, chargers or batteries not approved by this manufacturer may
cause fire, explosion and other hazards

5. Please use accessories approved by this manufacturer and compatible with this model of

- equipment
 4. Please use this device within the temperature range of 0°C-35°C, and store the device
 and its accessories within the temperature range of -20°C-45°C. When the ambient
 temperature is too high or too low, it may cause equipment feiture
 5. If charging is completed, please disconnect the charger from the device and unplug the
 charger from the power socket. The continuous charging time should not exceed 12 hours
 6. The bettery is prohibited from being disassembled, impacted, squeezed or thrown into
 fire. If it is swerrely expended, do not continue to use if
 I. Do not place it in a high temperature senfronment. Overheating of the battery may cause
 an exclusion.
- Posses keep the device dry
 If the device or any other part does not work properly, do not repair any product by
- yourself

 10. When connecting other devices, please refer to the connection method in the user manual and do not connect incompatible devices at well

 11. To avoid hearing damage, do not use high volume for a long time.

Warning

Please follow relevant laws and regulations and do not use in the following environments.

It is structly forbiddem to use the device in environments where flammable and explosive oil, gas or chemicals are stored, such as gas stations, oil depots, and chemical warehouses.

2. Do not use this device in hospital operating rooms, emergency rooms, intensive care units, etc. If a avoid interfaining with the operation of medical equipment, please stay away from pacemakers, hearing aids, cochiaar implants and other medical devices when using this device. Please keep a distance of more than 15 cm between this device and the pacemaker.

- pacemaker!

 You want to use this device near personal medical devices, please consult a physician and the device manufacturer

 4. Please follow all safety warnings and regulations regarding the use of this device while

- 4. Predate control is aftery membrane as outdoors to avoid lightning strikes

 5. In thunderstorms, do not use it outdoors to avoid lightning strikes

 6. Do not use the charger in high-temperature places such as bathrooms, otherwise it may
 cause electric shock, personal injury, fire and danage to the charger

 Please comply with relevant legal regulations that explicitly prohibit use in any environment

FCC Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party

responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class
B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to
provide reasonable protection against harmful interference in a residential installation. This
equipment generates, uses and can radiate radio frequency energy and, if not
installed and used in accordance with the instructions, may cause harmful interference
to radio communications. However, there is no guarantee that interference will not
occur in a particular installation. If this equipment does cause harmful interference to radio or
television reception, which can be determined by turning the equipment off and on, the user is
encouraged

encouraged to try to correct the interference by one or more of the following measures: — Reorient or

relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which

eceiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device

can be used in portable exposure condition without restriction

