

Google Home Voice Module User Manual


I. Sinric.com Operation (by Computer)	Page 1
II. Node MCB config setting (by computer)	Page 2
III. Google Actions Operation Setting (by computer)	Page 3
IV. Google Home APP operation setting (by Mobile Phone)	Page 8

I. Sinric.com operation

- 1. Go to sinric.com (www.sinric.com)
- 2. Create an account and log in
- 3. Click on Add button to create a smart home device
- 4. Input Name, Description and Type
- 5. Repeat step 3 and step 4
- 6. To create more smart home devices.
- 7. The information of 【Google Home】 will be used











II. Node MCB config setting


- 1. Get the module out of the MCB, connecting the module to the computer via USB wire.
- 2. Open the program of "Voice-Module-Config"
- 3. Input your router's name and password for the "Wifi Router"
- 4. Copy the "KPI Key" from the "sinric.com" into the "Sinric Skill"
- 5. Click 【Set Port】, to choose the 【Com Port】 of the USB driver
- 6. Choose the device KC868-H8 or KC868-H32, which you will use
- 7. Copy the Device IDs from the "sinric.com" into the "Relay Device ID" one by one accordingly.
- 8. Click [1:Open Port]
- 9. Click 【2:Create String】, and then Click 【3: Send】
- 10. Config setting OK, put the module back into the MCB
- 11. Connect the MCB to the device
- 12. Get both of them power on




III. Google Actions Operation Setting


- 1. Visit https://console.actions.google.com/
- 2. Click 【Add/ import project】
- 3. Name new project, click 【Create Project】
- 4. Wait few seconds to get it created








After creating successfully, Click 【Home Control】



6. Click 【Smart Home】




7. Click

[Name your Smart Home Action]


8. Input one name for 【Display name】 Click 【Save】


9. Click 【Overview】
Choose 【Setup Account Linking】

10. Select 【OAuth】 and 【Authorization Code】 Click 【NEXT】




Actions on Google







- 11. Login your Sinric account
- 12. Generate Keys
- 13. Copy Client ID and Client Secret




- 14. Paste for 【Client information】
- 15. Copy below address:
 Authorization URL:
 https://google.sinric.com/oauth
 Token URL:
 https://google.sinric.com/token
- 16. Paste them for 【Authorization URL】 and 【Token URL】
- 17. Enter a name for Configure your client






18. Input "Test" for 【Testing instructions】


19. Click [Save]




20. Select No , Click 【TEST】




21. Select 【Actions】 under 【Build】 of the left Menu.
Click 【Add your first action】



22. Copy the link of https://sinric.com/api/v1/googlehome/event, Paste it in, click 【Done】



23. Click 【TEST】 to finish the operation setting



IV. Google Home APP operation setting

- 1. Open your 【Google Home】app.
- 2. Click 【Add】
- 3. Click [Set up device]

- 4.click [Works with Google]
- 5.Click on 【Dr. Kincony】
- 6. Login your Sinric account
- 7. Link successfully
- 8. Back to homepage
- 9. Control by google home

