

Q U I C K S T A R T G U I D E



Wey-TEK HD Wireless™

Refrigerant Charging Scale

English · Español · Deutsch · Français · Italiano · 中文 · 日本語





Español

1. Emparejamiento Bluetooth
2. Botón de encendido
3. Cero
4. Unidades
5. Encendido/apagado

Deutsch

1. Bluetooth-Kopplung
2. Ein-/Aus-Schalter
3. Nullabgleich
4. Einheiten
5. Ein/Aus

Français

1. Liaison Bluetooth
2. Bouton d'alimentation
3. Zéro
4. Unités
5. Marche/Arrêt

Italiano

1. Associazione Bluetooth
2. Pulsante di accensione/spengimento
3. Zero
4. Unità
5. Acceso/Spento

中文

1. 蓝牙配对
2. 电源按钮
3. 清零
4. 单位
5. 开启 / 关闭

日本語

1. Bluetooth ペ어링ボタン
2. 電源ボタン
3. ゼロ点調整ボタン
4. 単位切り替えボタン
5. オン / オフボタン

1. Wey-TEK HD Wireless Base (Weighing Platform) Setup

- Insert four AA alkaline batteries into the back of the wireless base.
- To turn the weighing platform on or off, long press the On/Off button.

2. Pairing an Android™ Device with the Wireless Base

Requirement: Android 2.2 and above with Wey-TEK HD app installed (available on Google Play™) and Bluetooth-enabled.

- Turn the weighing platform On.
- Press **Bluetooth Pair**. The yellow indicator will change from flashing to solid.
- Open the Wey-TEK HD Android app.
- Tap **Connect To Scale**. A list of devices will display.
- Tap **Scale**. The yellow indicator will extinguish when pairing is complete.

3. Pairing an Apple iPhone® with the Wireless Base

Requirement: Apple iPhone 4s and above with the Wey-TEK HD app installed (available on the App Store) and Bluetooth-enabled.

- Turn the weighing platform On.
- Open the Wey-TEK HD app.
- Tap **Connect To Scale**. A list of devices will display.
- Tap **Scale**. The yellow indicator will extinguish when pairing is complete.

4. Wey-TEK HD Handpiece Setup

If purchased together, Wey-TEK HD Wireless and the optional handpiece are paired at the factory.

- Insert four AA alkaline batteries into the back of the handpiece.
- To turn the handpiece On or Off, long press the **On/Off** button.

5. Pairing a Handpiece with the Wireless Base

A new or replacement Wey-TEK HD handpiece must be paired with the wireless base.

- a. Turn the handpiece On.
- b. Turn the weighing platform On.
- c. Press **Bluetooth Pair** on the weighing platform. The yellow indicator will change from flashing to solid.
- d. On the handpiece, press **Menu**, scroll down, and select **Pair With Base**.
- e. Press **Start**. The flashing yellow indicator will extinguish when pairing is complete.

6. How to Use Wey-TEK HD Wireless (after pairing)

- a. Turn the weighing platform On.
- b. Open the Wey-TEK HD app or turn the handpiece on. The weighing platform will connect automatically and weight will be displayed.
- c. Press **Zero** at any time to zero the reading.

Additional information, including setting up the alarm, is located in the operating manual available from www.inficonservicetools.com.

**EU DECLARATION OF CONFORMITY**

This is to certify that this equipment, designed and manufactured by INFICON, meets the essential safety requirements of the European Union and is placed on the market accordingly. It has been constructed in accordance with good engineering practice in safety matters in force in the Community and does not endanger the safety of persons, domestic animals or property when properly installed and maintained and used in applications for which it was made.

Equipment Description: Wey-TEK HD Wireless Refrigerant Scale

Model Number:	719-202-G1	Wey-TEK HD Wireless
	719-203-G1	Wey-TEK HD Wireless w/Handpiece
	719-715-G1	Handpiece Kit, Wey-TEK HD Wireless

Applicable Directives:	1999/5/EC	RTTE
	2011/65/EU	RoHS

Applicable Standards:

Safety:	EN 61010-1:2010
	EN 62311:2008
	EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013
	EN 62479:2010

EMC:	EN 61326-1:2013 Class A
	CISPR 11/EN 55011:2009 (+A1:2010)
	EN 301 489-17 V2.2.1:2012-09
	EN 300 328 V1.9.1:2015-02

RoHS:	EN 50581:2013
--------------	---------------

CE Implementation Date: January 26, 2015



Manufacturer Representative
Brian King
General Manager - Service Tools
Two Technology Place
East Syracuse, NY USA 13057
INFICON

EU Authorized Representative
INFICON GmbH
50968 Köln, Bonner Str. 498

ANY QUESTIONS RELATIVE TO THIS DECLARATION OR TO THE SAFETY OF INFICON'S PRODUCTS SHOULD BE DIRECTED, IN WRITING, TO THE AUTHORIZED REPRESENTATIVE AT THE ABOVE ADDRESS.