



MEAN WELL MSP-450 series Single Output Medical Type Installation Guide

[Home](#) » [MEAN WELL](#) » MEAN WELL MSP-450 series Single Output Medical Type Installation Guide 



MSP-450 series
450W Single Output Medical Type



Contents

- 1 MSP-450 series Single Output Medical Type
- 2 Features:
- 3 SPECIFICATION
- 4 Mechanical Specification
- 5 Block Diagram
- 6 Function Description of CN100
- 7 Function Manual
- 8 Documents / Resources
 - 8.1 References

MSP-450 series Single Output Medical Type



https://www.meanwell.com/Upload/PDF/Enclosed_Type_EN.pdf

GTIN CODE

<https://www.meanwell.com/serviceGTIN.aspx>

Features:

- Universal AC input / Full range
- Built-in active PFC function, PF>0.95
- High efficiency up to 89.5%
- Withstand 300VAC surge input for 5 seconds
- Protections: Short circuit / Overload / Over voltage / Over temperature
- Built-in constant current limiting circuit
- Medical safety approved (MOOP level)
- Built-in cooling Fan ON-OFF control
- Built-in DC OK signal
- Built-in remote ON-OFF control
- Stand by 5V@0.3A
- Built-in remote sense function
- No load power consumption<0.6W (Note.6)
- 5 years warranty

SPECIFICATION

MODEL		MSP-45 0-3.3	MSP-45 0-5	MSP-45 0-7.5	MSP-45 0-12	MSP-45 0-15	MSP-45 0-24	MSP-45 0-36	MSP-45 0-48
	DC VOLTAGE	3.3V	5V	7.5V	12V	15V	24V	36V	48V

FUNCTION	5V STANDBY	5VSB : 5V@0.3A ; tolerance \pm 5%, ripple : 50mVp-p(max.)
	DC OK SIGNAL	PSU turn on : 3.3 ~ 5.6V ; PSU turn off : 0 ~ 1V
	REMOTE CONTROL	RC+ / RC-: 4 ~ 10V or open = power on ; 0 ~ 0.8V or short = power off
	FAN CONTROL (Typ.)	Load 20 \pm 10% or RTH2 \geq 50°C Fan on
ENVIRONMENT	WORKING TEMP.	-40 ~ +70°C (Refer to "Derating Curve")
	WORKING HUMIDITY	20 ~ 90% RH non-condensing
	STORAGE TEMP., HUMIDITY	-40 ~ +85°C, 10 ~ 95% RH non-condensing
	TEMP. COEFFICIENT	\pm 0.03%/°C (0 ~ 50°C)
	VIBRATION	10 ~ 500Hz, 5G 10min./1cycle, 60min. each along X, Y, Z axes
SAFETY & EMC (Note 8)	SAFETY STANDARDS	ANSI/AAMI ES60601-1, IEC60601-1, EAC TP TC 004 approved; Design refer to BS EN/EN60601-1, BS EN/EN62368-1
	ISOLATION LEVEL	Primary-Secondary: 2 \times MOOP, Primary-Earth: 1 \times MOOP, Secondary-Earth: 1 \times MOOP
	WITHSTAND VOLTAGE	I/P-O/P:4KVAC I/P-FG:2KVAC O/P-FG:0.5KVAC
	ISOLATION RESISTANCE	I/P-O/P, I/P-FG, O/P-FG:100M Ohms / 500VDC / 25°C/ 70% RH
	EMC EMISSION	Compliance to BS EN/EN55011 (CISPR11) Class B, BS EN/EN61000-3-2,-3, EAC TP TC 020
	EMC IMMUNITY	Compliance to BS EN/EN61000-4-2,3,4,5,6,8,11, BS EN/EN60601-1-2, BS EN/EN55035, EAC TP TC 020
OTHERS	MTBF	1171.9K hrs min. Telcordia SR-332 (Bellcore) ; 159.4K hrs min. MIL-HDBK-217F (25°C)
	DIMENSION	218*105*41mm (L*W*H)
	PACKING	1.19Kg; 12pcs/15.3Kg/0.82CUFT

NOTE


1. All parameters NOT specially mentioned are measured at 230VAC input, rated load and 25°C of ambient temperature.
2. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated with a 0.1 μ F & 47 μ F parallel capacitor.
3. Tolerance : includes set up tolerance, line regulation and load regulation
4. Derating may be needed under low input voltages. Please check the derating curve for more details.
5. Length of set up time is measured at first cold start. Turning ON/OFF the power supply may lead to increase of the set up time.

6. No load power consumption < 0.5W when RC- & RG+ (CN100 pin1,2) 0 ~ 0.8V or short
7. When the input voltage is less than 40VAC, the SPS may exhibit degradation of performance. The final product manufacturers must re-confirm this deviation that does not affect basic safety or essential performance.
8. The power supply is considered a component which will be installed into a final equipment. All the EMC tests are been executed by mounting the unit on 2 360mm*360mm metal plate with 1mm of thickness. The final equipment must be re-confirmed that still meets EMC directives. For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on https://www.meanwell.com/Upload/PDF/EMI_statement_en.pdf)
9. The ambient temperature derating of 3.5°C/1000m with fanless models and of 5°C/1000m with fan models for operating altitude higher than 2000m(5000ft)


Product Liability Disclaimer : For detailed information, please refer to

<https://www.meanwell.com/service/Disclaimer.aspx>


Mechanical Specification




Block Diagram



Derating Curve



Output Derating VS Input Voltage




Function Description of CN100

Pin No.	Function	Description
1	RC+	Turns the output on and off by electrical or dry contact between pin 2 (RC-), Short: Power OFF, Open: Power ON.
2	RC-	Remote control ground.
3	AUX	Auxiliary voltage output, 4.75~5.25V, referenced to pin 4(AUXG). The maximum load current is 0.3A. This output is not controlled by the "remote ON/OFF control".
4	AUXG	Auxiliary voltage output ground. The signal return is isolated from the output terminals (+V & -V).
5	DC-OK	DC-OK Signal is a TTL level signal, referenced to pin6(DC-OK GND). High when PSU turns on.
6	GND	This pin connects to the negative terminal(-V). Return for DC-OK signal output.
7	+S	Positive sensing. The +S signal should be connected to the positive terminal of the load. The +S and -S leads should be twisted in pair to minimize noise pick-up effect. The maximum line drop compensation is 0.5V.
8	-S	Negative sensing. The -S signal should be connected to the negative terminal of the load. The -S and +S leads should be twisted in pair to minimize noise pick-up effect. The maximum line drop compensation is 0.5V.

Function Manual

1.Remote Sense

The remote sensing compensates voltage drop on the load wiring up to 0.5V.



2.DC-OK Signal

DC-OK signal is a TTL level signal. High when PSU turns on.

Between DC-OK(pin5) and GND(pin6)	Output Status
3.3 ~ 5.6V	ON
0 ~ 1V	OFF




Fig 2.1

3.Remote Control

The PSU can be turned ON/OFF by using the "Remote Control" function.

Between RC+(pin1) and RC-(pin2)	Output Status
SW ON (Short)	OFF
SW OFF (Open)	ON




Fig 3.1



Downloaded from [ARROW.COM](https://www.arrow.com)

Documents / Resources

	<p>MEAN WELL MSP-450 series Single Output Medical Type [pdf] Installation Guide</p> <p>MSP-450 series Single Output Medical Type, MSP-450 series, Single Output Medical Type, Output Medical Type, Medical Type, Type</p>
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.