

MEASUREMENT COMPUTING USB-2020 Ultra High-Speed Simultaneous USB Device User Guide

Home » MEASUREMENT COMPUTING USB-2020 Ultra High-Speed Simultaneous USB Device User Guide [™]

MEASUREMENT COMPUTING USB-2020 Ultra High-Speed Simultaneous USB Device User Guide



Contents

- 1 What you will learn from this user's quide
- 2 Conventions in this user's guide
- 3 Where to find more information
- 4 Introducing the USB-2020
- 5 Functional block diagram
- 6 Installing the USB-2020
 - 6.1 Unpacking
 - 6.2 Installing the software
 - 6.3 Installing the hardware
- 7 Calibrating the hardware
- 8 Board connections
- 9 Functional Details
 - 9.1 Analog input acquisition modes
- 10 Board components
- 11 Signal connections
 - 11.1 Trigger input
- 12 Mechanical drawing
- 13 Specifications
 - 13.1 Analog input
 - 13.2 Analog input calibration
 - 13.3 Digital input/output
- 14 External trigger
 - 14.1 External clock input/output
 - 14.2 Memory
 - 14.3 Power
 - 14.4 Environmental
 - 14.5 Mechanical
 - 14.6 USB
 - 14.7 Signal I/O connectors
- 15 Trademark and Copyright Information
- 16 Documents / Resources
 - 16.1 References
- 17 Related Posts

What you will learn from this user's guide

This user's guide describes the Measurement Computing USB-2020 data acquisition device and lists device specifications.

Conventions in this user's guide

For more information

Text presented in a box signifies additional information and helpful hints related to the subject matter you are reading.

Caution! Shaded caution statements present information to help you avoid injuring yourself and others, damaging your hardware, or losing your data.

bold text Bold text is used for the names of objects on a screen, such as buttons, text boxes, and check boxes. **italic text** Italic text is used for the names of manuals and help topic titles, and to emphasize a word or phrase.

Where to find more information

Additional information about USB-2020 hardware is available on our website at www.mccdaq.com. You can also contact Measurement Computing Corporation with specific questions.

- Knowledgebase: kb.mccdaq.com
- Tech support form: www.mccdaq.com/support/support form.aspx
- Email: techsupport@mccdaq.com
- Phone: 508-946-5100 and follow the instructions for reaching Tech Support

For international customers, contact your local distributor. Refer to the International Distributors section on our web site at www.mccdaq.com/International.

Introducing the USB-2020

The USB-2020 is a high-speed data acquisition USB board supported under the Windows® operating system.


The USB-2020 is compatible with both USB 1.1 and USB 2.0 ports. The speed of the device may be limited when using a USB 1.1 port due to the difference in transfer rates on the USB 1.1 versions of the protocol (lowspeed and full-speed).

The USB-2020 device provides the following features:

- two 20 MS/s analog inputs
 - simultaneous sampling
 - 1 A/D per channel
 - 12-bit resolution
 - ±10 V, ±5 V, ±2 V, ±1 V voltage ranges (software-selectable)
 - 17 MHz input bandwidth
- 64 megasample onboard memory
 - 40 MS/s overall rate to onboard memory when acquiring from both channels (20 MS/s per channel)
 - 8 MS/s throughput to host computer
- Analog and digital triggering (level and edge)
- · Analog and digital gating
- Eight digital I/O lines
- · Internal or external pacing of analog scans
- Eight digital I/O lines
- BNC connectors and 40-pin auxiliary connector for signal connections

Functional block diagram

USB-2020 functions are illustrated in the block diagram shown here.



Installing the USB-2020

Unpacking

As with any electronic device, you should take care while handling to avoid damage from static electricity. Before removing the device from its packaging, ground yourself using a wrist strap or by simply touching the computer chassis or other grounded object to eliminate any stored static charge.

Contact us immediately if any components are missing or damaged.

Installing the software

Refer to the MCC DAQ Quick Start and the USB-2020 product page on our website for information about the software that supports the device.

Install the software before you install your device

The driver needed to run the USB-2020 is installed with the software. Therefore, you need to install the software package you plan to use before you install the hardware.

Installing the hardware

Before you connect the USB-2020 to your computer, connect the external power supply that was shipped with the device.

Disconnect USB, then power supply

When disconnecting the USB-2020, disconnect the USB cable first, and then disconnect the power supply.

Connecting the external power supply

Refer to Figure 4 on page 12 for the location of the connectors and LEDs mentioned in the following procedure.

Power to the USB-2020 is provided with the 9 VDC external power supply (CB-PWR-9).

Connect the external power supply before connecting the USB cable to the USB-2020 and your computer.

Complete the following steps to connect the power supply to the USB-2020:

- 1. Connect the external power cord to the USB-2020-power connector.
- 2. Plug the power supply into a power outlet.

The top (Device Ready) LED is on (blue) when 9 VDC power is supplied the USB-2020 and a USB connection is established. If the voltage supply is less than 7.3 V and/or a USB connection is not established, the Device Ready LED is off.

Connecting the USB-2020

Complete the following steps to connect the USB-2020 to your system:

- Connect the USB cable that was shipped with the device to the USB connector on the USB-2020.
 The USB cable supplied with the USB-2020 has a higher gauge wire (24 AWG minimum VBUS/GND, 28 AWG minimum D+/D-) than generic USB cables, and is required for proper enumeration of the USB-2020.
- Connect the other end of the USB cable to a USB port on your computer or to an external USB hub that is connected to your computer. The bottom (USB Activity) LED turns on. The USB cable only provides communication to the USB-2020.

If you are running Windows XP and connect the device to a USB 1.1 port, a message displays Your USB device can perform faster if you connect to a USB 2.0 port. You can ignore this message.

The USB-2020 functions properly when connected to a USB 1.1 port, although USB bandwidth is limited.

If the Device Ready LED turns off

If communication is lost between the device and the computer, the Device Ready LED turns off. Disconnect the USB cable from the computer and then reconnect it. This should restore communication, and the Device Ready LED should turn on.

If your system does not detect the USB-2020

If a USB device not recognized message appears when you connect the USB-2020, complete the following steps:

- 1. Unplug the USB cable from the USB-2020.
- 2. Unplug the external power cord from the power connector.
- 3. Plug the external power cord back into the power connector.
- 4. Plug the USB cable back into the USB-2020.

Your system should now properly detect the USB-2020 hardware. Contact technical support if your system still does not detect the USB-2020.

Removing USB-2020 boards from Windows XP systems

Device Manager may require up to 30 seconds to detect the removal of a USB-2020 board from a Windows XP system with Service Pack 2 installed. This time increases with each additional connected device. If you remove four devices from your system, the time required for Device Manager to update may be almost two minutes.

If you re-attach the USB-2020 to your system before Device Manager updates, the bottom LED does not turn on. Your system does not detect new hardware until Device Manager first detects that hardware has been removed. InstaCal software is unresponsive during this re-detection time. Wait until Device Manager updates with the new hardware before running InstaCal. The USB-2020 is detected by the system when the top (Device Ready) LED is on.

Calibrating the hardware

The Measurement Computing Manufacturing Test department performs the initial factory calibration. The calibration coefficients are stored in non-volatile RAM.

You can use InstaCal to recalibrate the USB-2020. No external equipment or user adjustments are required. At run time, the calibration factors are loaded into system memory and are automatically retrieved each time a different ADC range is specified. A full calibration typically takes less than two minutes.

Before you calibrate the device, turn your computer on and allow at least 30 minutes for the surrounding temperature to stabilize. For best results, calibrate the device immediately before making critical measurements.

The high-resolution analog components on the board are sensitive to temperature. Pre-measurement calibration insures that your device is operating with optimum calibration values.

Board connections

The table below lists the board connector types, applicable cables, and compatible products for the USB-2020.

Board connectors, cables, accessory equipment

Parameter	Specification
Connector types	 Four standard BNC female connectors for analog input, clock I/O, and digital trigger input 40-pin IDC connector
Compatible cable for the BN C connectors	Standard BNC cable
Compatible cables for the 40	C40FF-x: 40-conductor ribbon cable, female both ends, x = length in feet.
-pin IDC connector	C40-37F-x: 40-pin IDC to 37-pin female D connector, x = length in feet.
Compatible accessory products using the C40FF-x cable	CIO-MINI40
Compatible accessory products using the C40-37F-x cable	CIO-MINI37 SCB-37

Cabling

You can use the CIO-MINI40 screw terminal board and C40FF-x cable for signal connections and termination.




Figure 2. C40FF-x cable

You can use the C40-37F-x or C40F-37M-x cable for connections to 37-pin connectors or boards.




Figure 3. C40-37F-x cable

Field wiring, signal termination and conditioning

You can use the 40-pin CIO-MINI40 universal screw terminal board to terminate field signals and route them into the USB-2020 using the C40FF-x cable:

You can use the following MCC screw terminal boards to terminate field signals and route them into the USB-2020 using the C40-37F-x cable directly:

- CIO-MINI37 37-pin universal screw terminal board.
- SCB-37 37-conductor, shielded signal connection/screw terminal box

Functional Details

Analog input acquisition modes

The USB-2020 can acquire analog input data in three different modes – software paced, continuous scan (hardware paced), and BURSTIO.

Software paced

In software paced mode, you can acquire one analog sample at a time. You initiate the A/D conversion by calling a software command. The analog value is converted to digital and returned to the computer. You repeat this procedure until you have the total number of samples that you want from one channel.

The typical throughput sample rate in software paced mode is 4 kS/s (system-dependent).

Continuous scan (hardware paced)

Continuous scan mode enables data to be directly transferred to the host computer during acquisition. The maximum rate in continuous scan mode is 8 MS/s for all acquired data (one channel or two channels). The maximum rate achieved depends on the host computer.


BURSTIO

When using BURSTIO, the USB-2020 can acquire data at the maximum rate of 20 MS/s per channel to the internal memory buffer (up to 64 megasamples)

The acquired data is read from the FIFO and transferred to a user buffer in the computer. You can initiate a single acquisition sequence of one to two channels with either a software command or an external hardware trigger event.

When BURSTIO is enabled, scans are limited to the depth of the onboard memory, as the data is acquired at a rate faster than it can be transferred to the computer. Time must be allowed between scans for the acquisition and the transfer of the data.

Board components



- 1. USB connector
- 2. Clock I/O BNC connector (CLK IO)
- 3. Analog input channel 0 BNC connector (CH0)
- 4. External power connector
- 5. External digital trigger input BNC connector (TRIG IN)
- 6. USB Activity LED
- 7. 40-pin IDC auxiliary connector
- 8. Analog input channel 1 BNC connector (CH1)
- 9. Device Ready LED

BNC connectors

The USB-2020 has four BNC connectors that provide connections for the following signals:

- Two single-ended analog inputs
- · One external digital trigger input
- One clock input/output

The external digital trigger input signal is also available on the 40-pin IDC connector.

Status LEDs

The Device Ready LED turns on after the device is enumerated by the system and is associated with a hardware

driver.

The USB Activity LED turns on when the USB-2020 is transmitting or receiving data.

USB connector

The USB connector provides power to the USB-2020 and communication with the host computer.

External power connector

The USB-2020 requires external power. Connect the CB-PWR-9 power supply to the external power connector. This power supply provides 9 VDC, 15 A power, and plugs into a standard 120 VAC outlet.

40-pin IDC auxiliary connector (J9)

The 40-pin auxiliary connector provides the following connections for all I/O signals except for analog input and clock I/O:

- Eight digital I/O (DIO0 to DIO7)
- Digital trigger input (TRIG IN)
- 12 ground connections (GND)
- Two +5V power outputs (+VO)

The signals that are available on the 40-pin IDC connector are listed below. Connect signals on the 40-pin IDC connector using a C40FF-x cable or C40-37F-x cable.

40-pin IDC connector pinout

Pin Description	Signal Name	Pin			Pin	Signal Name	Pin Description
Ground	GND	1	•	•	2	+VO	Power output
Ground	GND	3	•	•	4	N/C	Do not connect
Digital I/O bit 7	DIO7	5	•	•	6	N/C	Do not connect
Digital I/O bit 6	DIO6	7	•	•	8	N/C	Do not connect
Digital I/O bit 5	DIO5	9	•	•	10	TRIG IN	External digital trigger input

Digital I/O bit 4	DIO4	11	•	•	12	GND	Ground
Digital I/O bit 3	DIO3	13	•	•	14	GND	Ground
Digital I/O bit 2	DIO2	15	•	•	16	GND	Ground
Digital I/O bit 1	DIO1	17	•	•	18	GND	Ground
Digital I/O bit 0	DIO0	19	•	•	20	GND	Ground
Ground	GND	21	•	•	22	N/C	Do not connect
Do not connect	N/C	23	•	•	24	N/C	Do not connect
Ground	GND	25	•	•	26	N/C	Do not connect
Do not connect	N/C	27	•	•	28	N/C	Do not connect
Ground	GND	29	•	•	30	N/C	Do not connect
Do not connect	N/C	31	•	•	32	N/C	Do not connect
Ground	GND	33	•	•	34	N/C	Do not connect
Power output	+VO	35	•	•	36	N/C	Do not connect
Ground	GND	37	•	•	38	N/C	Do not connect
Do not connect	N/C	39	•	•	40	N/C	Do not connect

40-pin to 37-pin signal mapping

Signal mapping on the C40-37F-x cable is not a one-to-one ratio. The table below lists the signals on the 40-pin end and the associated signals on the 37-pin end.

Signal mapping on the C40-37F-x cable

40-pin cable	40-pin cable end		37-pin cable end	
Pin	Signal Name	Pin	Signal Name	
1	GND	1	GND	
2	+VO	20	+VO	
3	GND	2	GND	
4	N/C	21	N/C	
5	DIO7	3	DIO7	
6	N/C	22	N/C	
7	DIO6	4	DIO6	
8	N/C	23	N/C	
9	DIO5	5	DIO5	
10	TRIG IN	24	TRIG IN	
11	DIO4	6	DIO4	
12	GND	25	GND	

13	DIO3	7	DIO3
14	GND	26	GND
15	DIO2	8	DIO2
16	GND	27	GND
17	DIO1	9	DIO1
18	GND	28	GND
19	DIO0	10	DIO0
20	GND	29	GND
21	GND	11	GND
22	N/C	30	N/C
23	N/C	12	N/C
24	N/C	31	N/C
25	GND	13	GND
26	N/C	32	N/C
27	N/C	14	N/C
28	N/C	33	N/C

29	GND	15	GND
30	N/C	34	N/C
31	N/C	16	N/C
32	N/C	35	N/C
33	GND	17	GND
34	N/C	36	N/C
35	+VO	18	+VO
36	N/C	37	N/C
37	GND	19	GND
38	N/C		
39	N/C		
40	N/C		

Signal connections

Analog input

The USB-2020 has two single-ended simultaneous sampling analog inputs that provide sampling at rates of up to 20 MS/s to internal memory when using BURSTIO and at rates of up to 8 MS/s (system-dependent) to the host computer in continuous scan mode. The input ranges are software-selectable for $\pm 10 \text{ V}$, $\pm 5 \text{ V}$, $\pm 2 \text{ V}$, $\pm 1 \text{ V}$.

When using BURSTIO, the internal memory can store up to 64 mega samples at the maximum rate for transfer to the computer after the acquisition is complete. Data is transferred to the host computer at a maximum rate of 8 MS/s (system-dependent).

Buffer size limitations on Windows systems

When creating very large buffers in Windows, you may receive the message "The requested amount of Windows page-locked memory is not available" when you try to start a scan. This error occurs when there is enough memory to create the buffer, but the memory cannot be locked down. For example, the driver can only lock a maximum buffer size of 67,107,800 bytes (33,553,900 samples) on Windows XP systems. A workaround for this is available when BURSTIO is enabled, allowing you to transfer the entire 64 MS of data from the onboard memory to the Windows buffer. Refer to the USB-2020 topic in the UL Help for more information.

You can pace analog input operations with the internal A/D clock or with an external clock source. When using an external input scan clock, connect the clock source to the CLK IO BNC connector.

For more information about signal connections

For more information about signal connections, refer to the Guide to DAQ Signal Connections (available for download from www.mccdaq.com/support/DAQ-Signal-Connections.aspx.)

External clock I/O

USB-2020 analog input scanning operations can be paced with the internal A/D clock or with an external clock source. The CLK IO connector can be configured through software for input (default) for external pacing, or for output to pace a connected device.

Digital I/O

You can connect eight digital I/O lines to DIO0 through DIO7 on the 40-pin IDC connector. When a bit is configured for input, it can detect the state of any TTL-level input.

Digital input voltage ranges of up to 0 to 15 V are permitted, with thresholds of 0.8 V (low) and 2.0 V (high).

Each DIO channel is an open-drain, which can sink up to 150 mA for direct drive applications when used as an output.

Figure 5 shows an example of a typical digital output connection.

Typical DIO channel





Figure 5. Digital output connection

External pull-up capability


Inputs are pulled high by default to 5 V through 47 k Ω resistors on the circuit board. The pull-up voltage is common to all 47 k Ω resistors.

You can configure the pull-up/pull-down state by changing the placement of the shorting block located at the three-pin header J10. Pull-up is the default factory configuration Figure 6. Pull-up and pull-down jumper configurations (J10)

Pull-up default configuration (factory default)



Pull-down configuration



An external pull-up resistor can be used to pull the DIO bit up to a voltage that exceeds the internal 5 V pull-up voltage (15 V maximum). Be aware that this would place the 47 k internal pull-up resistor in a parallel resistance configuration that could offset the logic high voltage level.




Figure 7. Digital I/O external resistor configuration

Trigger input

Both the TRIG IN BNC connector and the TRIG IN IDC pin are external digital trigger/gate inputs that you can configure through software.

An analog scan can have a trigger or a gate, but not both. For example, you cannot use an analog trigger and use the TRIG IN BNC connector to gate at the same time.

A trigger or gate can be digital or analog.

Digital triggers can be configured for rising or falling edge, or for high or low level.

USB-2020 User's Guide Functional Details

- Analog triggers can be configured for software-selectable high or low level, or for rising or falling edge with software-selectable hysteresis.
- Digital gates can be configured for high or low level.
- Analog gates can be configured for software-selectable high or low level, or for in or out of software selectable window.

Each configuration is explained below:

- High or low level
- Trigger or gate an acquisition when an input signal is higher or lower than the specified voltage.
- Rising or falling edge
- Trigger an acquisition when input signals cross a specified voltage (rising or falling)
- Window
- Gate an acquisition when the input signal is within or outside two specified voltages (in/out of window)
- Hysteresis
- After the input signal has passed through one specified voltage, trigger an acquisition when the input signal

passes through a second voltage (positive or negative). For example, once the signal goes below 5 V, a rising edge that crosses 4 V must occur to trigger an acquisition.

Mechanical drawing




Figure 8. USB-2020 circuit board dimensions

Specifications

All specifications are subject to change without notice.

Typical at 25 °C unless otherwise specified Specifications in italic text are guaranteed by design.

Analog input

Table 1. Analog input specifications

Parameter	Condition	Specification
A/D converter type		AD9225
Number of channels		2
Resolution		12-bits

Input configuration		Single-ended, individual A/D per channel
Sampling method		Simultaneous
Input ranges		±10 V, ±5 V, ±2 V, ±1 V, software-selectable
Connection type		BNC
Input coupling		DC
Absolute maximum input volta ge		±15 V max (power on)
Input impedance		1.5 MΩ typ
Input leakage current		2 uA typ, 10 uA max
Input bandwidth (3 dB)	All input ranges	17 MHz typ
Crosstalk	DC to 10 kHz	-90 dB
Trigger source	Digital	TRIG IN (BNC connector and 40-pin connector) See External trigger for more information
	Analog	CH0 or CH1
	Internal	1 kHz to 20 MHz max

Sample clock source	External	CLK IO (BNC connector) See External clock input/output for more information
	Software paced	33 S/s to 4 kS/s typ; system-dependent
Throughput	Continuous scan	1 kS/s to 8 MS/s, system-dependent
	BURSTIO	1 kS/s to 20 MS/s to 64 MS onboard memory
Data transfer rate	From onboard memory	10 MS/s typ
Signal-to-noise ratio (SNR)		66.6 dB
Signal-to-noise and distortion ratio (SINAD)		66.5 dB
Spurious free dynamic range (SFDR)		80 dB
Total harmonic distortion (THD)		80 dB

Accuracy

Table 2. DC Accuracy components and specifications. All values are (\pm)

Range	Gain error (% of reading)	Offset error (mV)	INL error (% of range)	Absolute accu racy at Full Sc ale (mV)	Gain temperat ure coefficient (% reading/°C)	Offset tempe rature coeffi cient (µV/°C)
±10 V	0.11	5.2	0.0976	35.72	0.0035	30
±5 V	0.11	5.2	0.0488	20.46	0.0035	110
±2 V	0.11	1.1	0.0244	8.18	0.0035	10
±1 V	0.11	1.1	0.0122	4.64	0.0035	25

Noise performance

For the peak-to-peak noise distribution test, a single-ended input channel is connected to AGND at the input BNC connector and 20,000 data samples are acquired at the maximum rate.

Table 3. Noise performance specifications

Range	Counts	LSBrms
±10 V	5	0.76
±5 V	5	0.76
±2 V	7	1.06
±1 V	7	1.06

Analog input calibration

Table 4. Analog input calibration specifications

Parameter	Specification
Recommended warm-up ti me	15 minutes min
Calibration method	Self calibration, with calibration factors for each range stored onboard in non-volat ile memory
Calibration interval	1 year (factory calibration)

Digital input/output

Table 5. Digital I/O specifications

Parameter	Specification
Digital type	CMOS
Number of I/O	8
Configuration	Each bit can be independently configured as input (power on default) or output Input bits can be read at any time whether the digital output is active or tri-stated.
Input voltage range	0 V to 15 V
Input characteristics	47 k Ω pull-up/pull-down resistor, 28 k Ω series resistor
Abs. Maximum input volt age	+20 V max
Pull-up/pull-down config uration	The port has 47 k Ω resistors that can be configured as pull-up or pull-down with an internal jumper. The factory configuration is pull-up (J10 shorting block default position is pins 1 and 2). Pull down capability is available by placing the J10 shorting block across pins 2 and 3.
Digital I/O transfer rate (software paced)	33 S/s to 4,000 S/s typ; system-dependent
Input high voltage	2.0 V min
Input low voltage	0.8 V max

Output characteristics	47 kΩ pull-up, open drain (DMOS transistor, source connected to ground)
Output voltage range	0 V to 5 V (using 47 kΩ internal pull up resistors) 0 V to 15 V max through optional, user-supplied external pull-up resistors (Note 1)
Drain to source breakdo wn voltage	42.5 V min (Note 2)
Off state leakage current	1.0 μΑ
Sink current capability	 150 mA max (continuous) per output pin 150 mA max (continuous), total for all eight channels
DMOS transistor on- resi stance (drain to source)	4 Ω

- Note 1: Adding external pull-up resistors connects the output bit in parallel with the internal 47 k Ω pull-up resistor. The resulting load voltage depends on the value of the external resistor value and the pull-up voltage used. In general, external 10 K Ω pull-up resistors are sufficient for most applications.
- **Note 2:** Does not include the additional leakage current contribution that can occur when using an external pull-up resistor.

External trigger

Table 6. External trigger specifications

Parameter	Condition	Specification
Trigger source	Digital	TRIG IN (BNC connector and 40-pin connector)
	Analog	CH0 or CH1
	Digital	Rising or falling edge, high or low level
Trigger mode	Analog	Trigger above or below software-selectable level, rising or falling e dge with software-selectable hysteresis
A/D gate source	Digital	TRIG IN (BNC connector and 40-pin connector)
W D gate source	Analog	CH0 or CH1
	Digital	High or low level
A/D gate modes	Analog	Software-selectable high or low level, in or out of software-selecta ble window
Trigger latency		50 ns max
Trigger pulse width		25 ns min
Input type	Digital	49.9 $Ω$ series resistor
Input high voltage threshol d	Digital	2.0 V min
Input low voltage threshold	Digital	0.8 V max
Input voltage range	Digital	-0.5 V to 6.5 V

External clock input/output

Parameter	Specification
Terminal name	CLK IO (BNC connector)
Terminal type	ADC clock input/output, software-selectable for input or output (default is input)
Terminal description	n When configured for input, receives sampling clock from external source n When configured for output, outputs the internal sampling clock
Clock rate	1 kHz to 20 MHz max
Stability	±50 ppm
Input impedance	1 ΜΩ
Maximum rate	20 MHz
Input range	-0.5 V to 5.5 V
Clock pulse width	25 ns min
Input type	49.9 $Ω$ series resistor
Input high voltage threshol d	2.0 V min
Input low voltage threshold	0.8 V max
Output high voltage	3.8 V min
Output low voltage	0.6 V max

Dutput current ±8 mA max	Output current
--------------------------	----------------

Memory

Table 8. Memory specifications

Parameter	Specification
Data FIFO	64 MS using BURSTIO, 4 kS not using BURSTIO
Non-volatile memory	32 KB (30 KB firmware storage, 2 KB calibration/user data)

Power

Table 9. Power specifications

Parameter	Specification
Supply voltage	9 VDC to 18 VDC; MCC plug-in power supply CB-PWR-9 recommended
Supply current	0.75 A max (Note 3)
Power jack configuration	Two conductor, barrel
Power jack barrel diameter	6.3 mm
Power jack pin diameter	2.0 mm
Power jack polarity	Center positive
+VO voltage range	4.50 V to 5.25 V
+VO current sourcing	10 mA max

Note 3: This is the total quiescent current requirement for the device that includes up to 10 mA for the Status LED.

This value does not include potential loading of the DIO bits or the +VO pin.

Environmental

Table 10. Environmental specifications

Parameter	Specification
Operating temperature ran ge	0 °C to 50 °C max
Storage temperature range	−40 °C to 85 °C max
Humidity	0% to 90% non-condensing max

Mechanical

Table 11. Mechanical specifications

Parameter	Specification
Dimensions (L × W × H)	142.24 × 180.34× 38.09 mm (5.6 × 7.1 × 1.5 in.)
Weight	1.5 lb

USB

Table 12. USB specifications

Parameter	Specification
USB device type	USB 2.0 (high-speed)
Device compatibility	USB 2.0
USB cable type	A-B cable, UL type AWM 2527 or equivalent. (min 24 AWG VBUS/GND, min 28 AWG D+/D-)
USB cable length	3 m (9.84 ft) max

Signal I/O connectors

Table 13. Connector specifications

Connector	Specification
USB	B type
Auxiliary connector (J9)	40-pin header connector
Compatible cables for the 40 -pin auxiliary connector	• C40FF-x • C40-37F-x
Compatible accessory products with the C40FF-x cable	CIO-MINI40
Compatible accessory products with the C40-37F-x cable	• CIO-MINI37 • SCB-37

BNC connectors

Table 14. BNC connector pinout

BNC signal name	Signal description
CH0	Analog input channel 0
CH1	Analog input channel 1
TRIG IN	BNC connection for external digital trigger (Note 4)
CLK IO	BNC connection for the ADC clock input/output, software-selectable for input or output (default is input)

Note 4: Also available on auxiliary connector J9.

Auxiliary connector J9

Table 15. 40-pin connector J9 pinout

Pin	Signal name	Pin description	Pin	Signal name	Pin description
1	GND	Ground	2	+VO	Power output
3	GND	Ground	4	N/C	Do not connect

5	DIO7	Digital I/O bit 7	6	N/C	Do not connect
7	DIO6	Digital I/O bit 6	8	N/C	Do not connect
9	DIO5	Digital I/O bit 5	10	TRIG IN	External digital trigger input
11	DIO4	Digital I/O bit 4	12	GND	Ground
13	DIO3	Digital I/O bit 3	14	GND	Ground
15	DIO2	Digital I/O bit 2	16	GND	Ground
17	DIO1	Digital I/O bit 1	18	GND	Ground
19	DIO0	Digital I/O bit 0	20	GND	Ground
21	GND	Ground	22	N/C	Do not connect
23	N/C	Do not connect	24	N/C	Do not connect
25	GND	Ground	26	N/C	Do not connect
27	N/C	Do not connect	28	N/C	Do not connect
29	GND	Ground	30	N/C	Do not connect
31	N/C	Do not connect	32	N/C	Do not connect
33	GND	Ground	34	N/C	Do not connect

35	+VO	Power output	36	N/C	Do not connect
37	GND	Ground	38	N/C	Do not connect
39	N/C	Do not connect	40	N/C	Do not connect

Note 5: N/C = no connection, not used

Trademark and Copyright Information

Measurement Computing Corporation, InstaCal, Universal Library, and the Measurement Computing logo are either trademarks or registered trademarks of Measurement Computing Corporation. Refer to the Copyrights & Trademarks section on mccdaq.com/legal for more information about Measurement Computing trademarks. Other product and company names mentioned herein are trademarks or trade names of their respective companies.

© 2021 Measurement Computing Corporation. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form by any means, electronic, mechanical, by photocopying, recording, or otherwise without the prior written permission of Measurement Computing Corporation.

Notice

Measurement Computing Corporation does not authorize any Measurement Computing Corporation product for use in life support systems and/or devices without prior written consent from Measurement Computing Corporation. Life support devices/systems are devices or systems that, a) are intended for surgical implantation into the body, or b) support or sustain life and whose failure to perform can be reasonably expected to result in injury. Measurement Computing Corporation products are not designed with the components required, and are not subject to the testing required to ensure a level of reliability suitable for the treatment and diagnosis of people.

Measurement Computing Corporation 10 Commerce Way Norton, Massachusetts 02766

(508) 946-5100 Fax: (508) 946-9500

E-mail: info@mccdaq.com

www.mccdag.com

NI Hungary Kft H-4031 Debrecen, Hátar út 1/A, Hungary

Phone: +36 (52) 515400 **Fax:** +36 (52) 515414

http://hungary.ni.com/debrecen



User's Guide

MEASUREMENT COMPUTING USB-2020 Ultra High-Speed Simultaneous USB Device [pdf

] User Guide

USB-2020 Ultra High-Speed Simultaneous USB Device, USB-2020, Ultra High-Speed Simultaneous USB Device

References

- <u>Sengineer Ambitiously NI</u>
- Measurement Computing Data Acquisition Knowledgebase
- Q Legal
- MC Data Acquisition (DAQ) Measurement Computing
- ME International Distributors
- MC Guide to DAQ Signal Connections
- ME Tech Support Form

Manuals+,