



MIDOCEAN MO9921 LED Alarm Clock User Manual

[Home](#) » [midocean](#) » MIDOCEAN MO9921 LED Alarm Clock User Manual 

MIDOCEAN MO9921 LED Alarm Clock



Contents

1 Instructions

1.1 Features

1.2 Display and keys

1.3 Precautions

2 Documents / Resources

2.1 References

3 Related Posts

Instructions

Features

1. Display mode: Time, date, temperature
2. Calendar: 2000-2099 years
3. Temperature(C/F)
4. 12/24H format selectable: (initial mode:24-hour)
5. Three groups of alarm, each alarm 1 minute
6. 18:00-07:00 half luminance; and four luminance to set (L0 – L1- L2 – L3)
7. 4xAAA batteries (not included) or DC(5V/500mA) power

Display and keys

1. Display mode select DP-1/DP-2
Initial mode DP1; Press “SET” to transform DP1 \longleftrightarrow DP2
2. Sound control mode select (Power-saving mode on AAA batteries):
Press “DOWN”, “on: Sd” \longleftrightarrow “–:Sd”; “on: Sd” means sound control works; “–:SD” means sound control closed
3. Press “UP” to change temperature display format $^{\circ}\text{C} \longleftrightarrow ^{\circ}\text{F}$.
4. Press “SET” for 3 seconds to enter the setting mode, set:
YEAR \rightarrow MONTH \rightarrow DATE \rightarrow 12H/24H \rightarrow HOUR \rightarrow MINUTE \rightarrow AL(ALARM) \rightarrow ALA1 \rightarrow ALA2 \rightarrow ALA3 \rightarrow WORKDAR
ALARM ON/OFF YEAR symbol flashing, press “UP” or “DOWN” key; MONTH symbol flashing, press “UP” or “DOWN” key; 12 hour format display; a red dot will display next to time figure at the afternoon.
5. Display luminance adjustment
Press and hold “UP” key for 3 seconds, “L3” will show on the display. Press “DOWN” key to decrease luminance level to “L2”. Press “UP” key for luminance enhancement. 4 different levels: L3-0.
6. RESET
Press the button “RESET” to reset the setting



Precautions

1. Use the clock in dry area only do not wet or keep in extreme heat location.
2. Take out the AAA battery from battery compartment if power is depleted.
3. Only 5V/500mA AC adapter is applicable for power supply.

Hereby, MOB, declares that item MO9921 is in Compliance with the essential requirements and other relevant conditions of Directive 2014/30/EU. The full text of the EU declaration of conformity is available at the following internet address: www.momanual.com.
MOB, PO BOX 644, 6710 BP (NL).



Documents / Resources

<div><p>USER MANUAL</p><p><small>The user manual contains information about the product and its use. It is important to read the manual carefully before using the product. The manual is available in Dutch and English. The manual is available in PDF format. The manual is available in PDF format. The manual is available in PDF format.</small></p></div>	<p>MIDOCEAN MO9921 LED Alarm Clock [pdf] User Manual</p> <p>MO9921 LED Alarm Clock, LED Alarm Clock, MO9921 Alarm Clock, Alarm Clock, Clock, MO9921</p>
--	---

References

-  [Export](#)
-  [Error during processing.](#)