



Home » Palintest » Palintest Lumiso Expert Pool Water Testing Instruction Manual

Contents [hide]

- 1 Palintest Lumiso Expert Pool Water Testing
- 2 Specifications
- 3 Blank the Instrument
- 4 Prepare Sample
- 5 Measure Total Hardness
- 6 Hardness Total
- 7 HOW TO USE
- 8 FAQS
- 9 Documents / Resources
 - 9.1 References



Palintest Lumiso Expert Pool Water Testing



Specifications

- Color Change Range: Not specified
- Technical Resource: Available at www.palintest.com

Blank the Instrument

- 1. Fill the sample to the 10 mL line.
- 2. Place the sample in the cell holder.
- 3. Press the Blank button to calibrate the instrument.

Prepare Sample

- 1. Add 12 drops of Hardicol liquid buffer to the sample.
- 2. Stir the sample to mix the buffer thoroughly.
- 3. Add a Hardicol No. 2 tablet to the sample.
- 4. Crush and stir the tablet until fully dissolved.

Measure Total Hardness

- 1. Place the prepared sample in the cell holder.
- 2. Press the Measure button on the instrument.
- 3. Allow the timer to count down for 2 minutes.
- 4. The result for Total Hardness will be displayed on the instrument

For more technical information and resources, visit <u>www.palintest.com</u>.

Hardness - Total



HOW TO USE



FAQS

Q: How often should I calibrate the instrument?

A: It is recommended to calibrate the instrument before each use for accurate results.

Q: Can I reuse the sample for multiple tests?

A: It is recommended to use a fresh sample for each test to ensure accurate measurements.

Documents / Resources



<u>Palintest Lumiso Expert Pool Water Testing</u> [pdf] Instruction Manual Lumiso Expert Pool Water Testing, Lumiso Expert, Pool Water Testing, W ater Testing

References

- User Manual
 - Lumiso Expert, Lumiso Expert Pool Water Testing, Palintest, Pool Water Testing, Water
- Palintest Testing

Leave a comment

Your email address will not be published. Required fields are marked *

Comment * Name Email Website Save my name, email, and website in this browser for the next time I comment. **Post Comment** Search: e.g. whirlpool wrf535swhz Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.