



PHANTOM RECOVERY Effects and Devices Owner's Manual

[Home](#) » [Phantom](#) » PHANTOM RECOVERY Effects and Devices Owner's Manual 

Contents

- [1 PHANTOM RECOVERY Effects and Devices](#)
- [2 Controls](#)
- [3 FAQ](#)
- [4 Questions?](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Phantom

PHANTOM RECOVERY Effects and Devices



The Phantom Operator is a supernatural filter with a mind of its own. It's rhythmic paranormal activity, you may think there's a ghost at the helm. The haunted randomization makes you feel like you've entered Twilight Zone. Plug into this pedal for endless inspiration that challenges you to compete against otherworldly spirits!

Achieve rhythmic patterns, complex tremolo, cadenced filters, and hard, glitched-out sounds with Sample and hold mode. The Voltage Controlled Filter mode is an incredibly smooth, classic low-pass, conducted by the dynamics of the input. Controls allow manipulation of filter frequency, as well as resolution, attack, and decay.

The Phantom Operator includes mode-changing via foot switch, with status and speed indicators. It's 100 percent analog, true bypass, and hand-wired with quality, through-hole components. Powered by a standard 9vdc negative-tip power supply.

Controls

SPEED

- Controls Sample/Hold speed. It only functions in Sample/Hold mode.

RES

- Controls the amount of filter resonance.

ATTACK

- Controls the attack of the filter. Turning clockwise produces a higher filter frequency.

DECAY

- Controls the speed of the filter decay. Turning clockwise will increase the decay time.

MODE

- Toggles between VCF and sample/Hold modes.

BYPASS

- Turns the effect on and off.

FAQ

Q: Is there a way to add a tap tempo overclocking option to the PhantomOperator?

A: Even though there's a steady pace on the speed indicator, the sample and hold is responsive to the dynamics of the instrument, making syncing pretty difficult. It's one of the reasons it's billed as a "random filter". There isn't a clocking option that we suggest or offer support for.




Made in Seattle, Washington

- **Enclosure size:** 4.67" x 3.654" x 1.547"
- **Available colors:** Cream & red

Questions?

- Send us an email: recoveryeffects@gmail.com

Documents / Resources

	<p>PHANTOM RECOVERY Effects and Devices [pdf] Owner's Manual</p> <p>RECOVERY Effects and Devices, Effects and Devices, RECOVERY Effects, RECOVERY Devices</p>
--	---

References

- (R) [Recovery Effects And Devices – Recovery Effects and Devices](#)

Manuals+.