



RemotePro Duplicate Coding Instructions

[Home](#) » [RemotePro](#) » RemotePro Duplicate Coding Instructions

RemotePro Duplicate Coding Instructions



Contents [[hide](#)]

- [1 Step 1: Erasing Factory Code](#)
- [2 Step 2: Copying the Code from an Existing Operational Remote](#)
- [3 WARNING](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

Step 1: Erasing Factory Code

1. Press and hold the top two buttons at the same time and do not let go (these will either be an unlock/lock symbol, numbers 1&2 or an up and down arrow). After a few seconds the LED will flash and then go out.
2. While still holding the first button (lock, UP or button 1) release the second button (unlock, down or number 2) and then press it 3 times. The LED light will flash again to indicate that the factory code has successfully been deleted.
3. Release all buttons.
4. Test: press a button on the remote. If the deletion of the factory code has been successful, the LED should not work when you press any button.

Step 2: Copying the Code from an Existing Operational Remote

1. Place both your new remote and original remote together. You may need to try different positions, head to head, back to back ect.
2. Press and hold one button on your new remote you wish to operate your door. The LED will flash quickly and then go out to indicate that your duplicator remote is in the "learn-code" mode. Do not release this button.
3. Press and hold the button that operates your door on your original remote this will send out the signal for your new remote to learn. When you see the LED light on your new remote start flashing constantly then coding has been successful.
4. Release all the buttons, and then test your new remote to make sure that it is working.

How to Restore an Accidentally Erased Remote Control

Press and hold the bottom two buttons on your new remote for 5 seconds.

www.remotepro.com.au

WARNING

To prevent possible SERIOUS INJURY or DEATH:

- Battery is hazardous: NEVER allow children near batteries.



- If battery is swallowed, immediately notify a doctor.

To reduce risk of fire, explosion or chemical burn:

- Replace ONLY with the same size and type battery
- DO NOT recharge, disassemble, heat above 100° C or incinerate Battery will cause SEVERE or FATAL injuries in 2 hours or less if swallowed or placed inside any part of the body.

Documents / Resources

[illegible]