




SMARTPEAK P1000 Android POS Terminal User Guide

[Home](#) » [SMARTPEAK](#) » SMARTPEAK P1000 Android POS Terminal User Guide 

SMARTPEAK P1000 Android POS Terminal User Guide



Contents

- [1 Packing list](#)
- [2 Installation instructions](#)
- [3 Product operation](#)
- [4 Matters needing attention](#)
- [5 List of hazardous substances](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Packing list

No.	Name	Quantity
1	P1000 POS terminal	1
2	P1000 quick start guide	1
3	DC Charging line	1
4	Power adapter	1
5	Battery	1
6	Printing paper	1
7	Cable	1

Installation instructions

SIM/UIM card Turn off the machine, tap the battery cover, take out the battery, and insert the SIM/UIM card chip face down into the slot of the corresponding card.

Battery Insert the upper end of the battery into the battery compartment, and then press the lower end of the battery.

Battery cover Insert the upper end of the battery cover into the machine, and then slide the switch downward to fasten the battery cover according to the silk screen indication beside the switch.

Note Before installing the battery, please check the battery appearance without any damage.

Product operation

Open Long press the power button on the side of the machine for 3 seconds.

Close Press the power button on the side of the machine, the screen will display “shutdown”, “restart”, select shutdown and press the “confirm” button to complete the operation.

Charging After installing the battery and battery cover, connect the power cord to the P1000 DC interface and the other end to the adapter, and start charging after connecting the power supply.

Please scan the QR code below for detailed instructions and analysis of common faults.

Scan the QR code by mobile phone to read the detailed operating instructions and common fault analysis of the terminal.



Matters needing attention

1. Can only use 5V/2A charger.
2. Before connecting the power supply to the ac socket during charging, check whether the power cord and the power adapter are damaged. If so, they cannot be used any more.
3. The equipment should be placed on a stable platform indoors.
Do not place it in direct sunlight, high temperature, humidity or dusty place. Please keep away from liquid.
4. Do not insert any foreign object into any interface of the device, which may seriously damage the device.
5. If equipment failure, please contact specialized POS maintenance personnel. Users shall not repair the equipment without authorization.
6. The software of different distributors has the different operation.
The above operation is for reference only.

List of hazardous substances

Part name	Harmful substances									
	Pb	Hg	Cd	Cr(VI)	PBBs	PBDEs	DIBP	DEHP	DBP	BBP
Shell	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Circuit board	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Power	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Cable	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Packaging	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
Battery	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

This form is prepared in accordance with SJ/T 11364



Indicates that the content of harmful substances in all uniform materials of the component is below the limit specified in GB/T 26572.




Indicates that the content of the hazardous substance in at least one uniform material of the component

exceeds the limit specified in GB/T 26572.
/ Indicates that all uniform materials of the component do not contain this harmful substance.

PS

- 1. **.Most** parts of the product are made of harmless and environment-friendly materials, the parts containing harmful substances cannot be replaced due to the limitation of global technology development level.
- 2. Environmental data for reference are obtained by testing in the normal use and storage environment required by the product, such as humidity and temperature.

Documents / Resources

	SMARTPEAK P1000 Android POS Terminal [pdf] User Guide P1000, 2AJMS-P1000, 2AJMSP1000, Android POS Terminal, P1000 Android POS Terminal, P OS Terminal
---	---