



UNI-T UT-P30 Differential Probe Active Probe Instruction Manual

[Home](#) » [UNI-T](#) » **UNI-T UT-P30 Differential Probe Active Probe Instruction Manual** 

Contents

- [1 UNI-T UT-P30 Differential Probe Active Probe](#)
- [2 Features](#)
- [3 Specifications](#)
- [4 Operating environmental conditions](#)
- [5 Operating procedure](#)
- [6 Maintenance](#)
- [7 Cleaning](#)
- [8 Warranty](#)
- [9 Repair](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)



UNI-T UT-P30 Differential Probe Active Probe



Features

The UT-P30 differential probe provides a safety means for measuring differential voltage to all models of oscilloscopes. It can convert the high differential voltage ($\leq 800\text{Vp-p}$) into a low voltage ($\leq 7\text{V}$) and display on the oscilloscope. Its bandwidth is up to 100MHz, which is ideal for big power testing, development and maintenance. The UT-P30 is designed to operate with the 1M Ω impedance oscilloscopes. When combined with the 50 Ω load, the attenuation will be 2 times. UT-P30 is recommended to use with our own manufactured PL-10 to expand the measuring with the electricity meter to observe more accurate measurement. The accuracy of oscilloscope is 1% and the DMM is less than 1%.

Specifications

1. Bandwidth: DC-100MHz
2. Attenuation: X100, X10
3. Accuracy: $\pm 1\%$
4. Input voltage range (DC+AC PEAK TO PEAK)
 - $\leq 80\text{V}$ for x10, (about 29V RMS)
 - $\leq 800\text{V}$ for x100, (about 290V RMS)
5. (5) Permitted max input voltage:
 - Max differential voltage: 800V (DC+AC PEAK TO PEAK)
 - Max voltage between each input terminal and ground: 5KV RMS
6. Input Impedance:
 - Differential: 4M Ω / 1.3pF
 - Between terminal and ground: 2M Ω / 2.6pF
7. Output voltage: $\leq 7\text{V}$
8. Output impedance: 50 Ω
9. Rise time:
 - 3.5ns for x100
 - 3.5ns for x10
10. Rejection rate on common mode:
 - 60Hz: 80dB; 100Hz: 60dB; 1MHz: 50dB

11. Power Supply: Only External 6V DC power supply.
12. Consumption: 150mA max (0.9 Watt)

Operating environmental conditions

	Reference	Use	Storage
Temperature	+20°C...+30°C	0°C....+50°C	-30°C....+70°C
Relative Humidity	≤70%RH	10%...85%RH	10%...90%RH

1. Dimensions and weight 69x26x165mm; 500g
2. Electrical safety to IEC 1010-1
 - Dual insulation
 - Installation category III
 - Degree of Pollution 2
 - Related voltage or max line-earth 5KV RMS
 - CE EN50081-1 and 50082-1

Operating procedure

- Connect the probe to the oscilloscope with the insulated BNC/BNC lead.
- Adjust the vertical zero adjustments of the oscilloscope if necessary.
- Select the attenuation ratio* and the vertical deviation of the oscilloscope in accordance with the conversion table below.
- NB: The POWER light must come on.

Attenuation ratio	X100	X10
Voltage Input Range (DC+AC Peak to PEAK)	800V	80V

[N.B]

The real vertical deviation in V/div is equal to the attenuation factor multiplied by the range of vertical deviation selected on the oscilloscope. It will be doubled in the case of use of a 50 Ω load.

Maintenance

For maintenance, only use specified spare parts. The manufacturer can not be held responsible for any accident arising following a repair made other than its after-sales service or approved repairs.

Cleaning

This probe does not require any particular cleaning. If necessary, clean the case with a cloth slightly moistened with soapy water.


Warranty

Unless notified to the country, our instruments are guaranteed against any manufacturing defect or material defect. They do not bear the specification known as the safety specification. Our guarantee, which may not under any circumstances exceed the amount of the invoiced price, goes on further than the repair of our faulty equipment, carriage paid to our workshops.

Repair

Maintenance, repairs under or out of guarantee. Please return the product to the manufacturer.

Documents / Resources

	<p>UNI-T UT-P30 Differential Probe Active Probe [pdf] Instruction Manual</p> <p>UT-P30, Differential Probe Active Probe, UT-P30 Differential Probe Active Probe</p>
---	---