



ACB E S8194B Lindana LED Table Lamp Instructions

[Home](#) » [ACB](#) » ACB E S8194B Lindana LED Table Lamp Instructions 

Contents


- [1 ACB E S8194B Lindana LED Table Lamp](#)
- [2 LINDANA](#)
- [3 CONNECTION TO THE NETWORK](#)
- [4 HOW TO USE](#)
- [5 SAFETY INSTRUCTIONS](#)
- [6 EXPLANATION OF PROTECTION CLASSES](#)
- [7 STAMP OF THE COMPANY](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)




ACB E S8194B Lindana LED Table Lamp




LINDANA



A cracked safety glass lampshade must be replaced.




CONNECTION TO THE NETWORK



CONNECTING WIRES TYPE“Y”:

If the flexible wire or cord of the luminaire is damaged should be replaced only by the manufacturer, its service or a similarly qualified person in order to avoid any risk.

HOW TO USE



SAFETY INSTRUCTIONS

1. Electrical appliances must only be connected by qualified persons.
2. Important! Before starting installation work disconnect the main cable from the power supply – remove fuse or turn switch to «OFF». The power supply connection must be done with the suitable connecting box, as seen on illustrations.
3. The lamps with index of protection 20 (IP20) cannot be used outdoor.
4. Lamps marked with the symbol may not be installed on easily flammable surfaces such as: wood, carpet.
5. Do not attach lamp on surfaces which are damp, freshly painted, or otherwise electrically conductive.
6. Connect the wires of the lamp with the same colour like the wires of the wall or the cell. PE or = green/yellow = ground wire. N =blue=neutral wire. L=brown (black) = phase.
7. Use the fixation system according to the weight of the lamp.
8. Keep away the wires and connections from heat sources.
9. Make sure that the wiring is not damaged during de drilling/fixing procedure.
10. Be sure to always use the correct type of bulb (see information on the label!).
11. Keep these instructions in a safe place.
12. Use the sleeves to cover the mains supply wiring to the fitting.
13. Cleaning is limited to the outer surfaces, shades or protective glass, reflectors and covers. It is important to ensure that no moisture enters the terminal compartment or reaches any live parts!. Gold and brass finishing lamps can be cleaned only with a soft cloth (do not use cleaning agents of any kind).
14. Use low pressure halogen lamps with low ultraviolet radiation (UV-STOP).
15. Suitable only for indoor use, at 25°C.


EXPLANATION OF PROTECTION CLASSES

- **Protection class I:** This lamp has an earth terminal. The earth wire (yellow and green) must be connected to the terminal indicated by the symbol.
- **Protection class II:** This lamp is double insulated and must not be connected to earth wire.
- All the technologic LED lamps are constructed with Led systems cannot be replaced.

STAMP OF THE COMPANY

The manufacturer guarantees the proper functioning of this equipment, repairs or spare parts of the model owing to faulty manufacture during 3 years after the surrender date. Responsibility will not be accepted, however, for damages or injury caused though misuse, For any claims the sale ticket must be presented. The company agrees to repair any defect or malfunction found in the item and any damages said defect or malfunction might directly provoke. If the repair should fail to satisfy the customer and/or the object fail to present the optimum condition for the use to which it is destined the guarantee holder will have the right to the substitution of the acquired item for another of identical characteristics or a complete refund of purchase price.

Documents / Resources



[ACB E S8194B Lindana LED Table Lamp](#) [pdf] Instructions
E S8194B, Lindana LED Table Lamp, E S8194B Lindana LED Table Lamp

