




amazon Capsule Sensor Lamp Instruction Manual

[Home](#) » [Amazon](#) » amazon Capsule Sensor Lamp Instruction Manual 



CAPSULE SENSOR LAMP INSTRUCTION MANUAL



Please read this manual carefully before using it.

Thank you for purchasing our products.

Please read the instruction manual and safety precautions carefully so that you can use them better.
For your future inspection and use, please keep this instruction manual and warranty card in good use.


Contents

- [1 Product features](#)
- [2 Meet your capsule sensor lamp](#)
- [3 Instructions for use](#)
- [4 Install the light](#)
- [5 Sensing range](#)
- [6 Product features](#)
- [7 Product parameters](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

Product features

1. Do not try to disassemble, repair or modify the appliance on your own.
2. Leave the appliance from wet or do not use it when your hands are wet.
3. Avoid installing the product near a heat source, at a direct light point, or at a too wet place where will affect the sensitivity of the sensor.
4. During product use, if an abnormal situation occurs, please discontinue use.
5. The light source of this lamp is irreplaceable;
6. Products do not include power adapters, be sure to buy safety-certified adapters for charging.

Meet your capsule sensor lamp



Package: USB charging cable: X1, Fixing plate X1


Instructions for use

Rotate the lamp cover to turn the switch indicator to the corresponding mode

OFF: Power off

AUTO: Induction mode, turning the switch to AUTO on, and when the body is sensed in dark light, the light automatically lights up for 20 seconds and then goes off

ON: Always-on mode, turn the switch until the ON light is always on. (Brightest)



Charging tip

The indicator will turn on when shows the light is charging properly, It will go out automatically when fully charged.


Charging time

2.5 hours for a full charge,

The "On" mode can be used continuously for 4 hours,

Under "Auto" mode it can be used for a: tam. a:z the built-in light sensor.


Install the light



It can be placed horizontally on the desktop or fixed to the wall or any metal surface.

1. Tear off the 3M cover of the plate and paste to the appropriate position. (Before pasting, please, make sure the surfaces are clean and dry)
2. Attach the magnetic base to the fixing plate.

Sensing range



Sensing range

5-7m in front of the front, Level 120 degree, side 2 -3m (Note: Sensitivity will be affected by environmental temperature, body shape, movement speed)

Product features

- LED light source, with low power consumption and long using life.
- Can be used as sensing light, small night lights, atmosphere lights.
- Built-in sensors can turn on the light automatically when detecting body motion.

2 Available working modes:

“On” mode when the light is brightest on.


“AUTO” mode refers to the light that will automatically turn on and keep for 20 seconds and then go off when detecting any body motion in the dark night.

- Magnetic Base design, convenient to hold or place on the desktop, wall, or any metal surfaces.
- Built-in 500mAh polymer lithium battery that can be charged via a USB charging cable.
- When indicator will keep on when is charging and turn off when fully charged.

Product parameters

Model	H-L-13
Design Patent	ZI2018307151105
Materials	ABS, PC, POM
Size	62x61x94.5mm
Weight	105g
Battery capacity	500mAh
Input	5V— 1A
Power	0.3W
Light color	4000k
Product Color	Light Gray/Dark Green/Dark Orange

Documents / Resources

	<p>amazon Capsule Sensor Lamp [pdf] Instruction Manual amazon, H-L-13, Capsule, Sensor, Lamp</p>
--	--