

[Manuals.plus](#) /

› [Pyle](#) /

› Pyle Adjustable Microphone Stand (Model PMKS5) Instruction Manual

Pyle PMKS5

Pyle Adjustable Microphone Stand (Model PMKS5) Instruction Manual

INTRODUCTION

Thank you for choosing the Pyle Adjustable Microphone Stand, Model PMKS5. This universal microphone stand is designed for stability and versatility, making it ideal for studio recording, live performances, and home use. It features a compact heavy base, adjustable height, and a pivot angle clip to accommodate various microphone types and user preferences.

Key features include:

- **Height Adjustable:** Smoothly adjust the height from 33.5 inches to 60.24 inches.
- **Reliable Sturdy Base:** A solid die-cast base with a 9.8-inch diameter and 9.92 lbs counterweight ensures stability.
- **Convenient Design:** Ultra-lightweight with a sleek black finish for easy transport and durable for long-term use.
- **Universal Mic Clip:** Features a USA standard 5/8 x 27 external thread size and a pivot angle clip for optimal microphone positioning.

WHAT'S IN THE BOX

Please ensure all components are present before assembly:

- Microphone Holder
- Adjustable Mount Arm
- Stand Base
- Rubber Base (anti-slip pads)

What's in the Box



Stand Base



Adjustable Mount Arm



Rubber Base



Microphone Clip

Figure 1: Included Components of the Pyle PMKS5 Microphone Stand

SETUP INSTRUCTIONS

Follow these steps to assemble your Pyle PMKS5 Microphone Stand:

1. **Attach the Stand Base:** Carefully screw the adjustable mount arm into the heavy stand base. Ensure it is tightened securely to prevent wobbling.
2. **Install Anti-slip Rubber Base:** If not pre-installed, attach the anti-slip rubber pads to the bottom of the stand base for enhanced stability and floor protection.
3. **Attach the Microphone Clip:** Screw the microphone holder onto the top of the adjustable mount arm. The stand uses a standard 5/8 x 27 external thread size, compatible with most universal microphone clips.
4. **Mount Your Microphone:** Secure your microphone into the attached microphone clip.




Figure 2: Fully Assembled Microphone Stand with Labeled Features


Your browser does not support the video tag.

Video 1: A seller-provided video demonstrating the easy setup of the Pyle microphone stand.

OPERATING INSTRUCTIONS

The Pyle PMKS5 Microphone Stand offers flexible adjustments for optimal microphone placement:

- **Height Adjustment:** To adjust the height of the stand, locate the height adjustment clutch on the main pole. Loosen the clutch by turning it counter-clockwise, slide the pole to your desired height (between 33.5 and 60.24 inches), and then tighten the clutch by turning it clockwise to secure the position.
- **Pivot Angle Adjustment:** The microphone clip features a pivot angle mechanism. Loosen the knob on the side of the microphone clip, adjust the microphone to your preferred angle, and then tighten the knob to lock it in place. This allows for precise microphone positioning for various vocal or instrument applications.



Easy Setup and Intuitive Operation

- Microphone Clip U.S. Standard: M-6
- Construction Materials: Steel Alloy Base + Mounting Pole
- Base Diameter: 9.8”

Figure 3: Adjusting the Microphone Clip Pivot Angle

MAINTENANCE

To ensure the longevity and optimal performance of your microphone stand, follow these maintenance guidelines:

- **Cleaning:** Wipe down the stand regularly with a soft, dry cloth to remove dust and debris. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Avoid abrasive cleaners or solvents.
- **Lubrication:** Periodically check the moving parts, such as the height adjustment clutch and pivot mechanism. If they become stiff, apply a small amount of silicone-based lubricant to ensure smooth operation.
- **Storage:** When not in use, store the microphone stand in a dry, cool place. If disassembling for storage, ensure all parts are clean and dry.
- **Inspection:** Regularly inspect all screws, knobs, and connections to ensure they are tight and secure. Tighten any loose parts to maintain stability.

TROUBLESHOOTING

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Base not fully tightened; uneven surface; damaged base.	Ensure the mount arm is securely screwed into the base. Place the stand on a flat, even surface. Inspect the base for damage.
Height adjustment is difficult or slips.	Clutch is too tight/loose; internal mechanism dirty or dry.	Loosen or tighten the clutch as needed. Clean and lubricate the internal sliding mechanism.
Microphone clip does not hold position.	Pivot knob is loose; clip is worn or incompatible.	Tighten the pivot knob. Ensure your microphone is compatible with the clip. Replace the clip if worn.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	PMKS5
Brand	Pyle
Color	Black
Material	Alloy Steel
Height Adjustment	33.5" - 60.24" (2.8' - 5' ft.)
Base Diameter	9.8" (235mm)
Base Type	Flat, Heavy Die-Cast
Base Weight	9.92 lbs
Microphone Thread Size	USA Standard 5/8" x 27
Included Components	Microphone Holder

WARRANTY INFORMATION

The Pyle PMKS5 Adjustable Microphone Stand comes with a **1-year limited warranty**. For specific details regarding warranty coverage and claims, please refer to the official Pyle website or contact customer support.

SUPPORT

For further assistance, product registration, or to explore other Pyle products, please visit the official Pyle store:

Visit the Pyle Store

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B002PAW6AU>

More documents and user manuals: <https://manuals.plus/>