

ToiLight TLDTORIGINAL1

ToiLight Toilet Bowl Night Light User Manual

MODEL: TLDTORIGINAL1

Brand: ToiLight

INTRODUCTION

Welcome to the user manual for your ToiLight Toilet Bowl Night Light. This innovative device is designed to enhance your bathroom experience by providing soft, motion-activated illumination, preventing the need for harsh overhead lights during nighttime visits. Enjoy a more comfortable and convenient way to navigate your bathroom in the dark.

PRODUCT OVERVIEW

Key Features:

- **Durable:** Adjustable arm and LED diode are waterproof for long-lasting use.
- **Motion & Light Sensor:** Lights up when you approach at night to prevent waking from bright lights.
- **Battery Powered:** Uses 3 AAA batteries (not included). Energy efficient, batteries last at least 6 months with active use.
- **Universal Fit:** Installs in 5 seconds. Stays in place and doesn't interfere with toilet use. Discrete and works whether the seat is raised or not. Does not interfere with closing of the toilet lid.
- **Multiple Color Modes:** Choose from color rotation or 8 single color modes: Blue, Red, Pink, Green, Baby Blue, Purple, Yellow, White.
- **Hygienic Design:** Crafted to stay clean and sanitary.
- **Wide Sensor Angle:** Wide sensor angle for optimal setup. Ensures proper lighting every time.



IMPROVES YOUR SLEEP

No more blinding lights
in your bathroom




The ToiLight provides soft illumination to improve sleep by avoiding harsh bathroom lights.




SMART SENSOR

Activates automatically when you approach in the dark



Equipped with a smart sensor, the ToiLight activates automatically when motion is detected in the dark.



The ToiLight features a durable build, offers 8 distinct colors plus rotation, is designed to stay clean, and operates on 3 AAA batteries (not included) for at least 6 months.



UNIVERSAL FIT

Fits any toilet securely
in just 5 seconds

Slim design
does not
interfere with
toilet use

Durable
waterproof
arm & LED
diode



Its universal fit and slim design ensure secure installation on any toilet in seconds without interfering with toilet use.



Experience a variety of vibrant colors with the ToiLight's multiple color modes.

SETUP GUIDE

Step 1: Insert Batteries

Open the battery compartment on the back of the ToiLight unit. Insert 3 AAA batteries, ensuring correct polarity. Close the compartment securely. (Batteries are not included).

Step 2: Install ToiLight on Your Toilet

Adjust the flexible arm of the ToiLight unit to fit the rim of your toilet bowl. Position the unit so the motion sensor faces the direction from which you typically approach the toilet. Ensure the LED light is inside the bowl. The slim design allows the toilet lid to close without interference.

Instructions

1. Insert Batteries

Insert 3 AAA Batteries.
(Not included in the package)




2. Install ToiLight on Your Bowl

Adjust ToiLight's arm gently so it fits the shape of your bowl perfectly.



3. Turn Off the Lights



ToiLight only works in the dark and when it detects movement. When it activates it stays on for 2 minutes after the last detected movement.

4. Set a Color or Let it Rotate



Select a color by pressing the button while the desired color is active. Press again to select color rotation.

Visual guide for battery insertion and proper installation of the ToiLight on the toilet rim.

OPERATING INSTRUCTIONS

Automatic Activation:

The ToiLight is equipped with both motion and light sensors. It will only activate in dark conditions when motion is detected. Once activated, the light will remain on for approximately 2 minutes after the last detected movement.

Setting Color Modes:

The ToiLight offers 8 single color modes and a color rotation mode. To select a specific color, press the button located on the side of the unit. Each press will cycle through the available colors (Blue, Red, Pink, Green, Baby Blue, Purple, Yellow, White). To activate the color rotation mode, continue pressing the button until it cycles through all colors automatically. To set a desired color, press the button again when that color is active.

MAINTENANCE

Cleaning:

The ToiLight is designed for hygienic use. To clean, simply wipe the unit with a damp cloth and mild cleaner. Avoid submerging the main unit in water. The adjustable arm and LED diode are waterproof.

Battery Replacement:

When the light begins to dim or fails to activate, it's time to replace the batteries. Follow the steps in the "Setup Guide" to replace the 3 AAA batteries.

TROUBLESHOOTING

Light Not Activating:

- Ensure the room is sufficiently dark. The light sensor prevents activation in well-lit environments.
- Check battery levels and replace if necessary.
- Verify the motion sensor is not obstructed and is facing the area of approach.

Light Not Changing Colors:

- Press the button firmly to cycle through the colors. If stuck on one color, try pressing the button multiple times to reset the mode.

PRODUCT SPECIFICATIONS

Feature	Detail
Finish Type	Modern
Base Material	Plastic
Product Dimensions	1"D x 2.6"W x 2.6"H
Item Weight	1.6 Ounces
Lamp Type	Toilet Night Light

Feature	Detail
Shade Color	Yellow, Blue, Purple, Pink, Green, Baby Blue, Red (9 Color modes)
Shade Material	Plastic
Switch Type	Motion & Light Sensor
Power Source	3 AAA Batteries (Not included)
Material	ABS Plastic
Is Waterproof	Waterproof LED Diode
Voltage	4.5 Volts
Brightness	5 Lumen
Model Number	TLDTORIGINAL1
UPC	760537040572

PRODUCT DEMONSTRATION

Your browser does not support the video tag.

This video provides an official demonstration of the ToiLight's features and functionality, including color changes and motion activation.

WARRANTY & SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official ToiLight website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details.](#)

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question