



[Manuals.plus](#) /

> [Allied Brass](#) /

> Allied Brass P-700-36-GB Pipeline Collection 36 Inch Grab Bar User Manual

Allied Brass P-700-36-GB

Allied Brass Pipeline Collection 36 Inch Grab Bar User Manual

Model: P-700-36-GB | Brand: Allied Brass

1. INTRODUCTION

This manual provides essential instructions for the safe installation, proper use, and maintenance of your Allied Brass P-700-36-GB Pipeline Collection 36 Inch Grab Bar. Please read all instructions carefully before installation and retain this manual for future reference. This grab bar is designed to provide support and enhance safety in bathroom environments.

2. SAFETY INFORMATION

- **Proper Installation is Crucial:** Ensure the grab bar is securely mounted to structural blocking or studs. Improper installation can lead to failure and serious injury. If you are unsure about installation, consult a qualified professional.
- **Weight Limit:** This grab bar is designed to support human weight for balance and assistance. Do not use it for climbing, as a swing, or to support excessive weight beyond its intended purpose.
- **Regular Inspection:** Periodically check the grab bar and its mounting hardware for any signs of looseness, damage, or corrosion. Tighten fasteners as needed.
- **Cleaning:** Use only mild, non-abrasive cleaners. Harsh chemicals can damage the finish and compromise the material integrity.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Allied Brass P-700-36-GB Pipeline Collection 36 Inch Grab Bar
- Color-coordinated mounting hardware (screws, anchors if applicable)
- Installation instructions (this manual)

4. INSTALLATION INSTRUCTIONS

7. INSTALLATION INSTRUCTIONS

Tools Required: Pencil, measuring tape, level, drill, drill bits appropriate for mounting surface and hardware, screwdriver (Phillips or flathead depending on hardware), stud finder (recommended).

1. **Determine Mounting Location:** Choose a location that provides optimal support and accessibility. Ensure the mounting surface is structurally sound. For walls, locate wall studs using a stud finder. The grab bar must be mounted into solid wood blocking or studs for maximum safety and stability.
2. **Mark Drill Holes:** Hold the grab bar in the desired position. Use a level to ensure it is perfectly horizontal. Mark the locations for the mounting screws through the pre-drilled holes on the grab bar flanges.
3. **Drill Pilot Holes:** Using an appropriate drill bit for your mounting surface and hardware, drill pilot holes at the marked locations. Ensure holes are deep enough to accommodate the screws.
4. **Secure Grab Bar:** Align the grab bar with the drilled holes. Insert the provided color-coordinated mounting screws and tighten them securely. Do not overtighten, as this can strip the screws or damage the wall surface.
5. **Test Stability:** After installation, firmly pull on the grab bar to ensure it is securely mounted and does not wobble or move. It should feel completely rigid.



Image 1: Allied Brass P-700-36-GB Pipeline Collection 36 Inch Grab Bar in Matte Black. This image shows

the grab bar's design and finish, illustrating how it appears when installed.

5. OPERATING (USAGE) INSTRUCTIONS

The Allied Brass grab bar is designed for providing stability and support. Grasp the bar firmly with one or both hands when entering or exiting a shower, tub, or when needing assistance with balance. Ensure your grip is secure before applying weight. Do not use the grab bar for any purpose other than providing support and balance.

6. CARE AND MAINTENANCE

To maintain the finish and integrity of your grab bar:

- **Cleaning:** Clean regularly with a soft, damp cloth. For stubborn spots, use a mild soap solution and immediately dry with a clean, soft cloth.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, ammonia-based products, bleach, or scouring pads, as these can damage the matte black finish and brass material.
- **Inspect Mountings:** Periodically check the mounting screws for tightness. If any screws feel loose, gently tighten them.

7. TROUBLESHOOTING

- **Grab Bar Feels Loose:** If the grab bar feels loose after installation or during use, immediately cease using it for support. Check all mounting screws and tighten them. If the screws do not tighten securely, the mounting surface may be compromised, and professional assistance should be sought to re-secure the bar in a new, structurally sound location.
- **Finish Damage:** If the finish appears dull or scratched, ensure you are using only recommended cleaning methods. Minor scratches may be less noticeable on a matte finish, but deep scratches cannot be repaired.

8. SPECIFICATIONS

Brand	Allied Brass
Model Number	P-700-36-GB
Material	Brass
Color	Matte Black
Finish Type	Matt
Product Dimensions	36 x 3.6 x 3 inches
Item Weight	4.6 Pounds
Included Components	Grab Bar and mounting hardware

9. WARRANTY INFORMATION

This Allied Brass grab bar is provided with a **Lifetime Warranty Against Manufacturer's Defects**. This

warranty covers defects in materials and workmanship under normal use and service. It does not cover damage resulting from improper installation, misuse, abuse, accident, or normal wear and tear. For warranty claims, please retain your proof of purchase and contact customer support.

10. CUSTOMER SUPPORT

For assistance with installation, troubleshooting, or warranty inquiries, please contact Allied Brass customer support. Visit the official Allied Brass website for contact information or refer to your purchase documentation.

Allied Brass Official Website: www.alliedbrass.com