



Manuals.plus /

› Artraise /

› Artraise Filter Replacement Manual for Shark Navigator and Rotator Vacuums (Models NV60, NV70, NV80, NV130, NV141, UV420, NV90, NV95)

Artraise XFF80, XHF80 (compatible with NV60, NV70, NV71, NV80, NVC80C, NV130, NV141, UV420, NV90, NV95)

Artraise Filter Replacement Manual

For Shark Navigator and Rotator Vacuums (Models NV60, NV70, NV80, NV130, NV141, UV420, NV90, NV95)

1. INTRODUCTION

This manual provides instructions for the installation, maintenance, and care of your Artraise replacement filters. These filters are designed to maintain the performance and air quality of your compatible Shark vacuum cleaner.

2. COMPATIBILITY

The Artraise replacement filters (Part # XFF80 and XHF80) are compatible with the following Shark vacuum cleaner models:

- **Shark Navigator DXL Vacuums:** NV60, NV70, NV71, NV80, NVC80C, NV130, NV141, UV420
- **Shark Rotator Professional XL Capacity Vacuums:** NV90, NV95



COMPATIBLE WITH



✓ For Shark Navigator Professional Upright Vacuum NV70, NV80, NVC80C, UV420

✓ For Shark Navigator DLX Upright Vacuum NV71

✓ For Shark Rotator Professional XL Upright Vacuum NV90, NV95

Compare to Part # XFF80 and XHF80

This image illustrates the compatibility of Artraise filters with various Shark vacuum models, including Navigator and Rotator series.

3. PACKAGE CONTENTS

Your Artraise filter replacement package includes the following components:

- 1 HEPA Filter
- 3 Foam Filters
- 3 Felt Filters



This image displays the complete set of Artraise replacement filters: one HEPA filter, three felt filters, and three foam filters.

4. SETUP AND INSTALLATION


To replace the filters in your Shark vacuum, follow these general steps. Refer to your specific Shark vacuum's user manual for exact filter locations and removal procedures.

1. **Power Off:** Ensure your vacuum cleaner is unplugged from the power outlet before beginning any maintenance.
2. **Locate Filters:** Identify the locations of the HEPA, foam, and felt filters in your vacuum. These are typically found in the dust cup assembly or motor housing.
3. **Remove Old Filters:** Carefully remove the used filters. Dispose of them according to local regulations.
4. **Insert New Filters:** Place the new Artraise HEPA, foam, and felt filters into their respective compartments. Ensure they are seated correctly and securely.
5. **Reassemble:** Reassemble any parts of the vacuum that were removed to access the filters.

5. OPERATING PRINCIPLES OF FILTERS

The Artraise filter system employs a multi-stage filtration process to capture dust and allergens, improving indoor air quality.

- **HEPA Filter:** This premium filter is designed with a 60 PPI density and H12 efficiency, capable of capturing 99.97% of particles as small as 0.3 microns. This includes dust, mites, dirt, hair, pet dander, and pollen.
- **Felt Filter:** An ultra-thick filter with a textured surface, it works to capture larger particles and protect the HEPA filter.
- **Foam Filter:** Utilizes advanced technology to absorb small particles such as food debris, hair, dirt, and pet dander, further protecting the vacuum motor and extending the life of the HEPA filter.



This image details the construction and function of the HEPA, felt, and foam filters.

With H12 efficiency to capture
99.97% of particles as small as
0.3 microns in size



✓ Dust



✓ Mites

✓ Dirt

✓ Hair



✓ Pollen

✓ Etc



This image visually represents how the filters work together to capture various particles, contributing to cleaner air.

6. MAINTENANCE

Regular cleaning and replacement of your filters are essential for maintaining optimal vacuum performance and air quality.

6.1. Cleaning Instructions (Washable & Reusable)

The foam and felt filters are washable and reusable. Follow these steps to clean them:

1. **Rinse:** Rinse the foam and felt filters under running water until the water runs clear.
2. **Remove Excess Water:** Gently squeeze the filters to remove excess water. Do not twist or wring them forcefully.
3. **Air Dry:** Allow the filters to completely air dry for at least 24 hours before reinstalling them into your vacuum. Ensure they are fully dry to prevent mold or mildew growth and damage to the vacuum.

Note: The HEPA filter is generally not washable and should be replaced when dirty.



This image demonstrates the process of washing the reusable foam and felt filters.

6.2. Replacement Schedule

For optimal performance, it is recommended to:

- Clean the foam and felt filters every **1-2 months**.
- Replace the HEPA filter every **6-12 months**, or as needed based on usage and visible dirt accumulation.

7. TROUBLESHOOTING

If you experience reduced suction or notice a decrease in vacuum performance after installing new filters, consider the following:

- **Filter Seating:** Ensure all filters are correctly and securely seated in their compartments. Improper installation can lead to air leaks and reduced suction.
- **Dryness:** If you have recently washed the foam and felt filters, confirm they are completely dry before reinstallation. Damp filters can hinder airflow.
- **Other Blockages:** Check the vacuum's hose, brush roll, and dust cup for any blockages that might be affecting suction.
- **Filter Condition:** If filters are old or heavily soiled, even after cleaning, they may need to be replaced

to restore full performance.

8. SPECIFICATIONS

Feature	Detail
Brand	Artraise
Model Numbers	XFF80, XHF80
Compatible Devices	Shark Navigator DXL (NV60, NV70, NV71, NV80, NVC80C, NV130, NV141, UV420), Shark Rotator Professional XL Capacity (NV90, NV95)
Material Type	Foam, Plastic
Item Weight	5.3 ounces
Product Dimensions	5 x 4.4 x 0.7 inches
Reusability	Foam and Felt filters are reusable
HEPA Filtration Efficiency	99.97% of particles as small as 0.3 microns

9. SUPPORT

If you have any questions, concerns, or require assistance with your Artraise filter replacement product, please contact our customer support. We are committed to providing satisfactory service.

For further information or to report any dissatisfaction, please refer to the contact details provided at the point of purchase or visit the official Artraise store online.