

[Manuals.plus](#) /

› [OttLite](#) /

› OttLite LED Desk Lamp with Dual Head & Bluetooth Speaker User Manual

OttLite NS2009-SHPR

OttLite LED Desk Lamp with Dual Head & Bluetooth Speaker

Model: NS2009-SHPR

INTRODUCTION

Thank you for choosing the OttLite LED Desk Lamp with Dual Head & Bluetooth Speaker. This versatile lamp is designed to provide optimal lighting for various tasks while offering the convenience of integrated audio and device charging. Its unique dual-head design, touch controls, and multiple light modes make it an ideal addition to any workspace, dorm room, or home office.

SETUP

Unpacking

Carefully remove all components from the packaging. Ensure all parts are present: the lamp unit (base, flexible neck, and dual LED heads) and the power adapter. Retain packaging for future storage or transport.

Assembly

The OttLite LED Desk Lamp comes pre-assembled. Simply place the lamp on a stable, flat surface. Connect the power adapter to the DC input port located on the back of the lamp's base, then plug the adapter into a standard electrical outlet. A red indicator light will illuminate, confirming power connection.





Figure 1: OttLite LED Desk Lamp, fully assembled and ready for use.

OPERATING INSTRUCTIONS

Light Controls

The lamp features touch-sensitive controls located on the top surface of the base. These controls allow for easy adjustment of light settings.

- **Power Button ():** Tap to turn the lamp ON or OFF.
- **Brightness Control (*):** Press and hold the power button to seamlessly dim or brighten the light. Release at your desired brightness level. The lamp offers a maximum brightness output of up to 300 lumens.
- **Color Mode Button (M):** Tap this button to cycle through three distinct color modes: Natural Daylight, Bright White, and Warm White.



Figure 2: Touch-activated controls on the lamp base for light and speaker functions.

Adjusting the Dual Heads


The lamp features two independent LED heads that can be adjusted to suit your lighting needs. The flexible neck allows for height adjustment from 14 to 26.5 inches.

- **Pivoting Shades:** Each LED head can pivot independently up to 180 degrees. This allows you to direct light precisely where needed, whether concentrating light on a single area or spreading it across a wider workspace.
- **Flexible Neck:** Gently bend the lamp's neck to adjust the overall height and angle of the light heads.





Figure 3: The dual shades can be independently adjusted for focused or widespread illumination.



Dual Shades

Pivoting shades move independently to provide two individual or one concentrated light source

Figure 4: The flexible neck allows for height adjustments from 14 to 26.5 inches.

Bluetooth Speaker Operation

The integrated Bluetooth speaker allows for wireless audio streaming from your compatible devices.

- **Pairing:** To pair your device, press and hold the Bluetooth pairing button (often indicated by a Bluetooth symbol or a play/pause icon) on the lamp's base until you hear an audible tone and the indicator light blinks. On your device, enable Bluetooth and select "OttLite Lamp" (or similar name) from the list of available devices. Once paired, the indicator light will become solid.
- **Playback Controls:** Use the touch controls on the base to manage audio playback. Tap the play/pause button to start or stop music. Tap the '+' or '-' buttons to skip tracks forward or backward. Press and hold the '+' or '-' buttons to adjust the speaker volume.



Figure 5: Enjoy wireless audio streaming through the integrated Bluetooth speaker.

USB Charging Port

A 5V, 2.1A USB charging port is conveniently located on the back of the lamp's base, allowing you to charge your smartphone, tablet, or other USB-powered devices.

- **To Charge:** Connect your device's USB charging cable to the USB port on the lamp. The device will begin charging automatically.



Figure 6: The 5V, 2.1A USB port provides convenient charging for your devices.

MAINTENANCE

Cleaning

To maintain the appearance and functionality of your lamp, follow these cleaning guidelines:

- Always unplug the lamp from the power outlet before cleaning.
- Wipe the lamp's surfaces with a soft, dry, or slightly damp cloth.
- Do not use abrasive cleaners, solvents, or polishes, as these may damage the finish.

Bulb Replacement

The OttLite LED Desk Lamp utilizes integrated, energy-efficient LEDs that are designed for long-term use and do not require

replacement. Do not attempt to replace the LED components.

TROUBLESHOOTING

If you encounter issues with your OttLite lamp, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Lamp does not turn on.	No power connection.	Ensure the power adapter is securely plugged into the lamp and a working electrical outlet. Check if the outlet has power.
Light is too dim or too bright.	Brightness setting needs adjustment.	Press and hold the power button () to adjust brightness.
Cannot change light color mode.	Incorrect button pressed.	Tap the 'M' button to cycle through color modes.
Bluetooth speaker not pairing.	Speaker not in pairing mode or device not discoverable.	Press and hold the Bluetooth pairing button on the lamp. Ensure your device's Bluetooth is enabled and discoverable. Move device closer to the lamp.
No sound from Bluetooth speaker.	Volume too low or device not connected.	Increase volume on both the lamp (press and hold '+' button) and your connected device. Re-pair the device if necessary.
USB charging not working.	Cable issue or device incompatibility.	Ensure the USB cable is securely connected. Try a different USB cable or device to confirm functionality.

SPECIFICATIONS

Feature	Detail
Model Number	NS2009-SHPR
Brand	OttLite
Light Source Type	LED
Brightness	Up to 300 Lumens
Color Temperature	3 Modes (Natural Daylight, Bright White, Warm White)
Control Method	Touch
Connectivity	Bluetooth, USB
USB Charging Port	5V, 2.1A
Product Dimensions	4.13"D x 4.12"W x 26.5"H (Max Height)
Item Weight	1.5 Pounds
Power Source	Corded Electric

Feature	Detail
Material	Plastic
Certification	UL Listed

WARRANTY AND SUPPORT

OttLite products are manufactured with quality and care. For warranty information, technical support, or to purchase replacement parts, please visit the official OttLite website or contact their customer service department. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, please refer to the contact information provided in your product's original packaging or visit the OttLite support page online.