

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Apexel](#) /

› [Apexel Phone Lens Kits 22x Telephoto / 205° Fisheye / 120° Wide Angle / 20x Macro Lens / Tripod and Remote Shutter for iPhone Samsung, Huawei and Most APL-22XB105 - Instruction Manual](#)

Apexel APL-22XB105

Apexel Phone Lens Kit APL-22XB105 Instruction Manual

Model: APL-22XB105 | Brand: Apexel

1. INTRODUCTION

Thank you for choosing the Apexel Phone Lens Kit APL-22XB105. This versatile 4-in-1 kit is designed to elevate your mobile photography, offering a range of lenses to capture diverse scenes from distant subjects to intricate close-ups. This manual provides essential information on setting up, operating, maintaining, and troubleshooting your lens kit to ensure optimal performance and enjoyment.



Figure 1: Apixel Phone Lens Kit APL-22XB105 Overview

2. PACKAGE CONTENTS

Please verify that all the following items are included in your package:

- 1 x 22x Telephoto Lens
- 1 x 205° Fisheye Lens
- 1 x 120° Super Wide-Angle Lens (screwed with Macro Lens)
- 1 x 20x Macro Lens (screwed with Wide-Angle Lens)
- 1 x Flexible Phone Clip
- 1 x Metal Tripod
- 1 x Bluetooth Remote Shutter
- 1 x Microfiber Cleaning Cloth
- 1 x Zippered Pouch for storage

- Lens Caps for all lenses



Figure 2: Kit Contents and Packaging

3. SETUP INSTRUCTIONS

3.1 Attaching Lenses to Your Phone

1. Unscrew the desired lens from its protective caps.
2. Screw the chosen lens onto the flexible phone clip.
3. Attach the phone clip to your smartphone, ensuring the lens is perfectly aligned with your phone's main camera. For multi-lens phones, slide the clip to align with the primary camera.




Figure 3: Universal Clip Attachment Guide

3.2 Separating Wide-Angle and Macro Lenses

The 120° Wide-Angle Lens and 20x Macro Lens are screwed together upon receipt. To use the Macro Lens independently, gently twist the two lenses apart. To use the Wide-Angle Lens, ensure the Macro Lens is screwed onto it.



Figure 4: Wide-Angle and Macro Lens Separation

3.3 Pairing the Bluetooth Remote Shutter

1. Turn on the Bluetooth remote shutter.
2. On your smartphone, go to Bluetooth settings and search for available devices.
3. Select the remote shutter (usually named