

SKYVIK CL-MC25

SKYVIK SIGNI One 25mm Macro Lens Kit User Manual

Model: CL-MC25

INTRODUCTION

Thank you for choosing the SKYVIK SIGNI One 25mm Macro Lens Kit. This manual provides essential information for the proper setup, operation, and maintenance of your new mobile camera lens. Please read these instructions carefully before use to ensure optimal performance and longevity of the product.

PACKAGE CONTENTS

The SKYVIK SIGNI One 25mm Macro Lens Kit includes the following items:

- SKYVIK SIGNI One 25mm Macro Lens
- Premium Carrying Case
- Cleaning Cloth
- Carrying Pouch
- Universal Detachable Clip
- Light Diffuser (Frost Panel)



Image: Overview of the SKYVIK SIGNI One 25mm Macro Lens Kit components.

SETUP GUIDE

Follow these steps to properly attach and prepare your SKYVIK SIGNI One 25mm Macro Lens for use:

1. **Remove Protective Caps:** Carefully remove the protective caps from both the front and back of the macro lens.
2. **Attach Lens to Clip:** Screw the macro lens onto the universal detachable clip. Ensure it is securely fastened but do not overtighten.
3. **Mount Clip to Phone:** Position the universal clip over your smartphone's main camera lens. Ensure the macro lens is centered over your phone's camera for optimal image quality. The soft rubber on the clip protects your device from scratches.
4. **Attach Light Diffuser:** If needed, attach the light diffuser (frost panel) to the front of the macro lens. This helps in achieving even light distribution and reducing harsh shadows during macro photography.



It offers a super macro capability for capturing intricate details that are unseen by other lenses.

The lens comes with a light diffuser for even lighting and a universal clip to ensure compatibility with various devices.



#seewithsigni

What you Get:
SKYVIK SIGNI One 25mm macro Lens,
Premium Carrying case,
Cleaning Cloth,
Carrying Pouch,
Universal Clip

+
Free light diffuser

Image: The SKYVIK SIGNI One 25mm Macro Lens attached to a smartphone using the universal clip.



Image: The light diffuser accessory for the macro lens.

OPERATING YOUR MACRO LENS

The SKYVIK SIGNI One 25mm Macro Lens is designed for capturing intricate details of small subjects. Understanding its focal length is key to successful macro photography.

- **Focal Length:** The optimal focal length for this macro lens is between 15mm (1.5cm) and 25mm (2.5cm). This means you need to position the lens within this specific distance from your subject to achieve sharp focus.
- **Manual Focus:** This lens operates with manual focus. Your smartphone's camera app may automatically adjust, but for best results, manually adjust your phone's position relative to the subject until it is in sharp focus.
- **Lighting:** Good lighting is crucial for macro photography. The included light diffuser helps to evenly distribute light and minimize shadows, especially in bright conditions.
- **Stability:** For the sharpest images, especially at close distances, consider using a tripod or stabilizing your phone to minimize camera shake.




Image: Examples of detailed macro photographs captured with the lens.

CARE AND MAINTENANCE

Proper care will extend the life and maintain the performance of your macro lens:

- **Cleaning:** Use the provided cleaning cloth to gently wipe the lens surfaces. For stubborn smudges, use a lens cleaning solution specifically designed for optical glass. Avoid using abrasive materials or harsh chemicals.
- **Storage:** Always store the lens in its premium carrying case or pouch when not in use. This protects it from dust, scratches, and impacts.
- **Handling:** Avoid touching the lens glass directly with your fingers. Always handle the lens by its metal barrel.
- **Environment:** Keep the lens away from extreme temperatures, high humidity, and direct sunlight for prolonged periods.

TROUBLESHOOTING

If you encounter issues while using your SKYVIK SIGNI One 25mm Macro Lens, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Images are blurry or out of focus.	Incorrect focal distance; camera shake.	Ensure the lens is 1.5cm to 2.5cm from the subject. Stabilize your phone or use a tripod.
Dark corners (vignetting) in photos.	Lens not perfectly centered over phone camera; phone case interference.	Adjust the clip to center the lens. Remove bulky phone cases if they obstruct the lens.
Poor lighting or harsh shadows.	Insufficient or uneven light.	Use the included light diffuser. Ensure adequate ambient light or use external lighting.
Lens does not fit or function with my phone.	Device incompatibility.	The lens is compatible with most smartphones but is NOT compatible with OnePlus 8 Pro, Vivo S1 Pro, Vivo V15 Pro, Vivo V17 Pro, Mi 10i, and Poco X2. Verify your phone model.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	SKYVIK
Model Name	SIGNI One 25mm Macro Lens
Model Number	CL-MC25
Lens Type	Macro
Focal Length	25 mm
Focus Type	Manual Focus
Lens Coating	Multi-coated Aspherical Glass, Nano AR Coating
Material	Premium Grade Aluminum Alloy
Color	Black
Item Weight	340 Grams
Compatible Devices	All Smartphones (excluding specific models listed in troubleshooting)
Water Resistance Level	Not Water Resistant

WARRANTY AND CUSTOMER SUPPORT

Warranty: The SKYVIK SIGNI One 25mm Macro Lens Kit comes with a worry-free 12-month warranty from the date of purchase. This warranty covers manufacturing defects and ensures product quality.

Customer Support: For any inquiries, technical assistance, or warranty claims, please contact SKYVIK Technologies

customer support:

- **Phone:** 18001238830

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07RX6C8N4>

More documents and user manuals: <https://manuals.plus/>