

- Manuals.plus /
- › FelixKing /
- › FelixKing Office Chair Instruction Manual

FelixKing FK918

FelixKing Office Chair Instruction Manual

Model: FK918 | Brand: FelixKing

INTRODUCTION AND OVERVIEW

The FelixKing Office Chair (Model FK918) is designed to provide ergonomic support and comfort for extended periods of sitting, whether for work, study, or gaming. Its versatile features and durable construction make it an ideal choice for various home and office environments.



Figure 1: Full view of the FelixKing Office Chair, showcasing its ergonomic design and mesh back.

Key Features:

- **Ergonomic Design:** Features a mesh back with adjustable lumbar support that conforms to your spine, reducing pressure and muscle fatigue during long hours of work.
- **Comfortable Material:** The seat is composed of high-density natural sponge for superior comfort and support, complemented by a breathable mesh back for excellent ventilation.
- **Convenient Storage:** Equipped with 90-degree flip-up armrests, allowing the chair to be easily pushed under a desk to save space.
- **Multi-Functionality:** Offers 3.94-inch height adjustment, 360-degree swivel, and a 30-degree rocking tilt adjustment for personalized comfort and relaxation.
- **Durable Construction:** Built with an SGS-certified Class-3 gas lift and a strong, stable metal base, supporting up to 300 pounds. High-quality smooth casters ensure easy movement on various floor types.

SETUP AND ASSEMBLY

Assembly of the FelixKing Office Chair is designed to be straightforward and can typically be completed in about 15 minutes using the included tools and English instructions. For detailed step-by-step instructions, please refer to the official Installation Manual (PDF) provided by FelixKing.

A general overview of the assembly process includes:

1. **Base Assembly:** Attach the five rolling casters to the chair's star-shaped base.
2. **Gas Lift Installation:** Insert the gas lift cylinder into the center hole of the assembled base.
3. **Seat Plate Attachment:** Secure the metal seat plate mechanism to the underside of the seat cushion using the provided screws. Ensure the "FRONT" indicator on the plate aligns with the front of the seat.
4. **Backrest and Armrest Connection:** Attach the backrest to the seat assembly, typically by aligning and securing the armrests to both the seat and the backrest.
5. **Final Assembly:** Place the assembled seat and backrest onto the gas lift cylinder.

For a visual guide, please consult the official Installation Manual (PDF) available for download:[FelixKing Installation Manual](#)



Figure 2: Product dimensions and key features for assembly reference.

OPERATING INSTRUCTIONS

The FelixKing Office Chair offers several adjustable features to customize your seating experience for optimal comfort and support.

Height Adjustment:

To adjust the chair's height, locate the lever on the right side beneath the seat. While seated, pull the lever upwards to lower the chair. To raise the chair, lift your weight off the seat and pull the lever upwards. Release the lever at your desired height.

BREATHABLE MESH & FLIP-UP ARMRESTS



Figure 3: Illustration of the chair's height adjustment lever and range.

Rocking and Tilt Adjustment:

The chair features a rocking function and a 30-degree tilt adjustment. To enable rocking, pull out the lever on the left side of the seat. To lock the chair in an upright position (90 degrees), push the lever inwards. The tension of the rocking motion can be adjusted by turning the round knob located underneath the seat.



Figure 4: Demonstrates the rocking back feature and tilt control.

Flip-Up Armrests:

The armrests can be flipped up 90 degrees. Simply grasp an armrest and lift it upwards until it locks into the vertical position. This feature allows the chair to be tucked neatly under most desks, optimizing space.



Figure 5: The chair with armrests folded up, illustrating its space-saving design.

Lumbar Support Adjustment:

The ergonomic lumbar support can be adjusted vertically by 2 inches to perfectly fit the curve of your lower back. Gently push the lumbar support mechanism up or down to find your ideal position.



Figure 6: Detailed view of the adjustable lumbar support system.

360° Swivel and Casters:

The chair is designed for full 360-degree rotation, allowing for easy movement and access to different areas of your workspace without standing up. The smooth-rolling casters are suitable for various floor surfaces, including carpet, tile, and wood.



Figure 7: View of the chair's sturdy metal base and smooth-rolling casters.

MAINTENANCE

Proper maintenance will extend the life and appearance of your FelixKing Office Chair.

- **Cleaning:** Wipe clean with a damp cloth. For deeper cleaning of the mesh and fabric, use a mild soap solution and a soft brush, then wipe with a clean, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Caster Care:** Periodically check the casters for accumulated hair or debris and clean them to ensure smooth rolling.
- **Fastener Check:** Occasionally inspect all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability and safety.

- **Avoid Overloading:** Do not exceed the maximum weight recommendation of 300 pounds.

TROUBLESHOOTING

If you encounter any issues with your FelixKing Office Chair, refer to the common troubleshooting tips below:

- **Chair Sinks or Loses Height:**
 - Ensure the height adjustment lever is fully engaged.
 - The gas lift may be faulty. Contact customer support for replacement if the issue persists.
- **Chair Does Not Roll Smoothly:**
 - Check casters for hair, dust, or debris accumulation and clean them thoroughly.
 - Ensure the casters are properly inserted into the base.
- **Squeaking Noises:**
 - Tighten all assembly screws and bolts, especially those connecting the seat plate to the seat and the armrests to the backrest.
 - Apply a small amount of silicone lubricant to moving parts if necessary.
- **Backrest Does Not Recline/Lock:**
 - Verify that the rocking/tilt lever is in the correct position (pulled out for rocking, pushed in for locked upright).
 - Adjust the tilt tension knob to ensure it's not too tight.

If these steps do not resolve the issue, please contact FelixKing customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Brand	FelixKing
Model Name	FK918
Color	Black
Product Dimensions	25.2"D x 25.2"W x 40.5"H
Maximum Weight Recommendation	300 Pounds
Material Type	Nylon, Polyurethane, Mesh
Special Features	Adjustable Lumbar Support, Adjustable Height, Flip-up Armrests, Rolling Wheels, Breathable Mesh Back

Feature	Detail
Seat Height	Adjustable (approx. 13.4" to 17.3" from floor)
Swivel	360°
Reclining Position Count	2 (Upright 90°, Rocking up to 120°)
Recommended Uses	Office, Gaming, Home, Studying, Working

WARRANTY AND SUPPORT

- For any questions, concerns, or warranty claims regarding your FelixKing Office Chair, please refer to the following resources:
- **Official User Manual:** A comprehensive user manual is available for download, providing detailed information on assembly, operation, and care. [Download Manual \(PDF\)](#)
 - **FelixKing Brand Store:** Visit the official FelixKing store for product information, FAQs, and customer service contact details. [Visit FelixKing Store](#)
 - **Safety Information:** Always ensure the chair is used within the maximum weight capacity of 300 pounds. For proper assembly, follow the instructions provided. Improper assembly may lead to instability or other safety issues.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B088H3TB42>

More documents and user manuals: <https://manuals.plus/>