

Wessel-Werk WW-UPH-SERIES

Wessel-Werk Upholstery Vacuum Attachment Tool Instruction Manual

Model: WW-UPH-SERIES

PRODUCT OVERVIEW

This manual provides instructions for the Wessel-Werk Upholstery Vacuum Attachment Tool, designed to effectively remove pet hair, lint, and threads from various fabric surfaces. It features integrated red velvet microfiber strips that agitate and lift embedded debris for enhanced cleaning.

SETUP AND INSTALLATION

Attaching the Tool

The Wessel-Werk Upholstery Vacuum Attachment Tool is designed for compatibility with standard vacuum wands.

1. Ensure your vacuum cleaner is turned off and unplugged.
2. Locate the end of your vacuum's hose or extension wand where attachments are typically connected.
3. Firmly push the opening of the upholstery tool onto the vacuum hose or wand until it creates a secure seal.
4. Verify that the attachment is stable and will not detach during use.

Important Note: This tool is designed for standard vacuum wands. Compatibility may vary with specific vacuum models, especially those with non-standard hose diameters or specialized electric connections. Refer to your vacuum cleaner's manual for attachment compatibility.



This image displays the Wessel-Werk Upholstery Vacuum Attachment Tool, separated into its two primary components. The lower part features the red velvet microfiber strips, which are crucial for lifting embedded pet hair and lint from fabric surfaces. The upper part is the vacuum connection.

OPERATING INSTRUCTIONS

General Use


The upholstery tool is effective on various fabric surfaces, including sofas, armchairs, cushions, mattresses, and vehicle interiors.

1. Connect the upholstery tool to your vacuum cleaner as described in the "Setup and Installation" section.
2. Turn on your vacuum cleaner.
3. Gently glide the tool across the fabric surface. The red velvet microfiber strips will agitate the fibers, loosening embedded pet hair, lint, and threads.
4. Use a consistent, overlapping motion to ensure thorough cleaning. For heavily soiled areas, multiple passes may be necessary.
5. Pay attention to seams, crevices, and corners where debris tends to accumulate. The slim profile of the tool is designed to reach these areas.

Pet Hair and Lint Removal

The microfiber strips are specifically designed to attract and lift pet hair and lint. For best results:

- Apply light pressure while moving the tool. Excessive force is not required.
- Work in one direction to gather hair, then vacuum it away.
- For stubborn pet hair, try short, brisk strokes.



A person is shown using the Wessel-Werk Upholstery Vacuum Attachment Tool on a black and white patterned cushion. The tool is being moved across the fabric, demonstrating its application for cleaning furniture.



This image shows a hand holding the Wessel-Werk Upholstery Vacuum Attachment Tool, cleaning a dark grey car seat. The tool's design allows it to effectively clean vehicle interiors.

CARE AND MAINTENANCE

Cleaning the Microfiber Strips

To maintain optimal performance, regularly clean the red velvet microfiber strips.

1. Disconnect the upholstery tool from the vacuum cleaner.
2. Use your fingers or a small brush to remove any accumulated hair, lint, or debris from the microfiber strips.
3. If necessary, the strips can be gently wiped with a damp cloth. Allow them to air dry completely before reattaching the tool to the vacuum.

Storage

Store the tool in a clean, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Tool does not fit vacuum wand	Incompatible wand diameter	Verify your vacuum wand's diameter. This tool is designed for standard sizes, but some vacuums (e.g., certain Miele or Bissel models mentioned in reviews) may have different dimensions.
Reduced suction or ineffective cleaning	Clogged microfiber strips or vacuum filter	Clean the microfiber strips as described in the Maintenance section. Check your vacuum's hose and filter for blockages.
Microfiber strips appear worn or missing	Normal wear and tear or manufacturing variation	While designed for durability, continuous heavy use may cause wear. If strips are missing upon receipt, contact customer support.

For issues not listed here, please refer to the Support section.

PRODUCT SPECIFICATIONS

- **Model Number:** WW-UPH-SERIES
- **Material:** Acrylonitrile Butadiene Styrene, Plastic, Velvet Microfiber
- **Color:** Black
- **Item Weight:** 2.08 ounces
- **Product Dimensions:** 14 x 6 x 4 inches
- **Included Components:** Upholstery Vacuum Attachment
- **Manufacturer:** Wessel-Werk

Note: Specifications are subject to change without notice.

WARRANTY INFORMATION

Specific warranty details for the Wessel-Werk Upholstery Vacuum Attachment Tool are not provided in this manual. For information regarding product warranty, please refer to the original product packaging or contact Wessel-Werk customer support directly. Proof of purchase may be required.

CUSTOMER SUPPORT

For further assistance, questions, or to report issues with your Wessel-Werk Upholstery Vacuum Attachment Tool, please visit the official Wessel-Werk website or contact their customer service department.

Online Support: [Visit the Wessel-Werk Store on Amazon](#)

When contacting support, please have your product model number (WW-UPH-SERIES) and purchase information readily available.

© 2024 Wessel-Werk. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08T8LKYCV>

More documents and user manuals: <https://manuals.plus/>