

[Manuals.plus](#) /

> [Keenstone](#) /

> Keenstone 4000mAh Portable Electric Air Pump User Manual

Keenstone B07L4R5SN7

Keenstone 4000mAh Portable Electric Air Pump User Manual

1. INTRODUCTION

Thank you for choosing the Keenstone 4000mAh Portable Electric Air Pump. This compact and versatile device is designed for quick and efficient inflation and deflation of various inflatable items, such as air mattresses, pool floats, and camping cushions. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your product.



Image: The Keenstone Electric Air Pump is ideal for various inflatable items, enhancing leisure activities.

2. PRODUCT OVERVIEW

Key Features:

- **Wireless and Portable:** Small and lightweight design for easy transportation, ideal for travel and outdoor activities.
- **Powerful & Efficient:** Designed for quick inflation and deflation, maximizing your time.
- **Versatile Nozzles:** Includes three different nozzle sizes (S, M, L) to fit most inflatables.
- **Safe and Rechargeable:** Features a 4000mAh built-in battery, designed for continual operation without overheating.
- **Dual Functionality:** Capable of both inflating and deflating items.



Image: The air pump is suitable for various environments, including pools, homes, camping, and beaches.

Components:

- Keenstone Electric Air Pump Unit
- Small Nozzle
- Medium Nozzle
- Large Nozzle
- USB Charging Cable



Image: The pump includes three interchangeable nozzles for different valve sizes.

3. SAFETY INFORMATION

- Do not use this pump for inflating high-pressure items such as car tires or bicycle tires. This pump is designed for low-pressure, high-volume inflatables.
- Keep the pump away from water and moisture to prevent electric shock.
- Do not block the inflation/deflation ports during operation.
- Ensure the correct nozzle is securely attached before operating.
- Do not leave the pump unattended while in use.
- Keep out of reach of children.
- Avoid prolonged continuous operation to prevent potential overheating, although the pump is designed to maintain a surface temperature below 45°C.

4. SETUP

1. **Charge the Pump:** Before first use, fully charge the pump using the provided USB cable. The indicator lights will show charging status.
2. **Select Nozzle:** Choose the appropriate nozzle (Small, Medium, or Large) that fits the valve of your inflatable item.
3. **Attach Nozzle:** Securely attach the selected nozzle to the desired port on the pump. For inflation, attach to the 'INFLATE' port. For deflation, attach to the 'DEFLATE' port.



Image: Visual guide for attaching the nozzle to the pump.

5. OPERATING INSTRUCTIONS

5.1. Inflation

1. Ensure the correct nozzle is attached to the inflation port.
2. Insert the nozzle firmly into the valve of the item you wish to inflate.
3. Press the power button to start the pump.
4. Monitor the inflation process and turn off the pump once the item is sufficiently inflated. Do not over-inflate.

5.2. Deflation

1. Attach the appropriate nozzle to the deflation port.
2. Insert the nozzle firmly into the valve of the item you wish to deflate.

3. Press the power button to start the pump.
4. The pump will draw air out of the item, allowing for compact storage. Turn off the pump once deflation is complete.



Image: The pump features distinct ports for inflation and deflation.

5.3. Charging

The pump is equipped with a 4000mAh rechargeable battery. To charge, connect the provided USB cable to the 'USB In' port on the pump and to a suitable USB power source (e.g., wall adapter, power bank, computer USB port). The indicator lights will show the charging progress. A full charge ensures optimal performance.



Image: The pump's 4000mAh battery can be conveniently recharged via USB.

6. MAINTENANCE

- **Cleaning:** Wipe the exterior of the pump with a soft, dry cloth. Do not use abrasive cleaners or immerse the pump in water.
- **Storage:** Store the pump and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the battery is partially charged before long-term storage.
- **Nozzle Care:** Keep nozzles clean and free from debris to ensure a proper seal during use.

7. TROUBLESHOOTING

- **Pump not turning on:**

- Ensure the battery is charged. Connect to a power source and check indicator lights.
- Verify the power button is pressed correctly.

- **Slow inflation/deflation:**

- Check if the correct nozzle size is used and securely attached.
- Ensure the valve on the inflatable item is fully open and not obstructed.
- Confirm the battery has sufficient charge.

- **Pump overheating:**

- Allow the pump to cool down if it feels excessively warm. Avoid continuous operation for extended periods.
- Ensure air vents are not blocked.

- **Nozzle does not fit:**

- Try a different size nozzle from the included set.
- Some inflatable items may require specialized adapters not included with this pump.

8. SPECIFICATIONS

Specification	Detail
Model Number	B07L4R5SN7
Brand	Keenstone
Color	Black
Item Weight	380 Grams
Power Source	Electric (Rechargeable Battery)
Operation Mode	Automatic
Battery Capacity	4000mAh
Nozzles Included	3 (Small, Medium, Large)

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact Keenstone customer service directly. Keep your purchase receipt as proof of purchase.

Keenstone Customer Service: Please visit the official Keenstone website or refer to the contact information provided with your product for assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B098KWQC4Y>

More documents and user manuals: <https://manuals.plus/>